

English only

COGITO™ POP™

Quick Start Guide



COMMAND

Set time

Pull 1/2 way and turn to set the time

POWER

Power on/off > 3sec

Check connection Short press

Pairing: Press **COMMAND + POWER** > 3 sec until 2nd beep and all icons blink in every 2 sec.

Reset the watch: Press **COMMAND + POWER** at the same time > 12 sec until 2nd beep to reset the watch.



Step 1: Download the CONNECTED WATCH app

For iOS users: Search for the "CONNECTED WATCH" app in the App Store.

Compatible with iOS7 devices that support Bluetooth 4.0 **Smart** such as the iPhone 5s, iPhone 5c, iPhone 5, iPhone 4s, iPad, iPad mini, iPad (3rd and 4th generation), and iPod touch (5th generation).

The CONNECTED WATCH app is available for selected Android 4.3 and Android 4.4 devices that support Bluetooth 4.0. See www.cogitowatch.com for a full compatibility list.

For Android users: Download the CONNECTED WATCH app from the Google Play store.

Step 2: Pair and connect the COGITO watch with your mobile phone or tablet

- Place the watch into PAIRING mode by pressing the **COMMAND + POWER** > 3 sec until 2nd beep and all icons blink in every 2 sec.
- If you are an **iOS7 user**, open your Bluetooth settings and select "COGITO POP" in the device list. Press "PAIR" when prompted.
- If you are **Android user**, open the CONNECTED WATCH app and tap the Device List icon at the bottom left. The App will search for your watch. Select "COGITO POP" in the device list to connect.

Step 3: Customize your COGITO watch's notification settings.

Tap the Notification Settings icon at the top right of the CONNECTED WATCH app (iOS7 and Android) and select which notifications you wish to receive on your COGITO watch.


To acknowledge the notification - press any button



To send a command - press the **COMMAND** button (command action please refer to the setting of the app)

To check connection - press the **POWER** button - if the watch beeps and the icons turn ON for 1sec then connection is active. If they blink 3 times, then the connection is not active.

Replacing the connected system battery:




model CR2032

- Open the back case of the watch using a screwdriver to remove the back cover and old battery.
- Insert the new battery.
- Carefully replace the back case of the watch ensuring that the o-ring is correctly seated (for a water tight seal) and tighten the screws. **WARNING:** Do not over-tighten the screws.



Replacing the analog movement battery:



model SR626SW

- Open the back case of the watch using a screwdriver and remove the CR2032 cell button battery.
- Remove the protective sticker and carefully set it aside.
- Remove analog system battery located beneath the protected sticker. (model SR626SW, battery life lasts up to 3 years**)
- Carefully replace the protective sticker.



- Insert the CR2032 connected system battery and carefully replace the back case of the watch ensuring that the o-ring is correctly seated (for a water tight seal) and tighten the screws.

** Battery life may vary depending on the volume of the notification, brand and condition of battery

One year free limited warranty

Register your product by setting-up a CONNECTEDDEVICE account in the CONNECTED WATCH app. You will need to keep your original receipt as proof of purchase.

To keep your watch in good condition and to avoid voiding the warranty:

- Do not expose the watch to excessive pressure, impact, dust, open flames, or extreme temperatures.
 - Operating temperature: -20 to +55C, (-4 to +131F)
 - Always ensure the case back O-ring is correctly in place and the watch is tightly sealed before exposing the watch to any moisture or liquid.
 - Avoid submerging the watch for an extended period of time.
 - 10 ATM of water resistance means that your COGITO watch can be worn for most indoor or outdoor activities, including most water sports. Do not wear it while bathing, snorkeling or scuba diving.
 - To maintain water resistance, do not press any buttons or pull out the crown while under water.
 - Keep the front glass away from sharp or hard objects to prevent scratches.
-
- Do not attempt to repair or modify the watch yourself. Service and maintenance should be performed by authorized technicians.
 - Exposure to high or low temperatures or frequent successive alerts may shorten battery life.
 - Keep the watch, accessories, and any small parts out of the reach of children.



For support, please email us at support@cogitowatch.com

COGITO™ POP™

For more information about the watch and CONNECTED WATCH app, visit cogitowatch.com

Thank you for supporting COGITO™

702-00236-02A_EN

Front

Back