

REMOTE UNIT



Inserting batteries

The remote unit uses two "AA" batteries. To install or replace the batteries, please follow these steps:


1. Remove kickstand base.
2. Unscrew the screw on the back of the compartment and remove the cover.
3. Insert the batteries observing the correct polarity.
4. Replace the battery cover on the unit and seal by re-screwing tightly.
5. When a "Low Battery" symbol  appears on the part of Outdoor Temperature, please replace batteries of the remote unit.
6. At few occasions (interfered by environment, for instance), the LCD display might be abnormal, and then reload the corresponding batteries until it is ok.
7. After installation of the new batteries, the setup procedures need to be performed. (See Setting the remote transmitter(s))

Setting the remote transmitter

Upon power up the temperature RF signal is sent from the transmitter to the main unit automatically. Please place the transmitter outside in a dry, shaded area. Try relocating the transmitter if the main unit does not display the outdoor temperature after 3 minutes.

There are 2 buttons inside the back of remote.

- 1) $^{\circ}\text{C}/^{\circ}\text{F}$ --- To change the remote displays Centigrade or Fahrenheit
- 2) TX --- To test communication between remote and main unit



SAFETY INSTRUCTIONS

Do not expose the appliance to strong temperature variations, humidity, direct sunlight or dust.

Keep the remote out of reach of small children.

Attention! Batteries can be life threatening, if swallowed.

Therefore, keep batteries and clock out of reach of small children. If a battery has been swallowed, seek medical advice immediately. The batteries provided must not be charged or re-activated by any other means, taken apart, thrown into fire or short-circuited. Batteries need to be properly disposed of. For this purpose, shops selling batteries provide special containers for environmentally friendly disposal. Also, empty batteries will be taken at public waste collection points.

LIABILITY DISCLAIMER:

1. The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.
2. This product is not to be used for medical purposes or for public information.
3. The specifications of the product may change without prior notice.
4. This product is not a toy. Keep out of the reach of children.
5. No part of this manual may be reproduced without written authorization of the manufacturer.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: QL5AC2012TX13

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.