



Setup the unit




Table of Contents

Introduction	2
ATA Telephony Base BT41	2
Usage Requirement	2
Product information	3
Appearance	4
Setup the unit	6
Pairing	7
Operating BT41	8
Making outgoing call	8
Receiving incoming call	8
Troubleshooting	9
Important Information	10
Warranty	11

FCC Statement
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected!
- Consult the dealer or an experienced radio TV technician for help.

Warning: You are cautioned that any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions :
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

To comply with FCC RF exposure requirement, this device and its antenna must be co-located or operating in conjunction with any other antenna or transmitter.

Pairing

To use BT41 with a Bluetooth wireless headset, you must first pair the two devices.

- After power on BT41, the indicator light will turned green.
- Set the Bluetooth headset in pairing mode.
- Press the pairing button of BT41 for one second and the indicator light will turned from green to a blinking blue. Now BT41 is ready to be paired.
- Blue light will stop blinking when paired and now both units enter ready mode.

Introduction

ATA Telephony Base BT41

Thanks you for purchasing Bluetooth Telephony Base BT41. BT41 telephony Base is designed and manufactured in accordance with Bluetooth specification v1.1.

Bluetooth wireless technology is a global specification for personal area wireless connectivity to ensure communication compatibility worldwide. It connects any portable and stationary communication devices with Bluetooth enabled devices easily without a single inch of cable.

BT41 Telephony Base accepts calls from both your desktop and mobile phones. It will also let you make call / answer from either your desktop phone via your Bluetooth wireless headset.

This User's Guide will show you how to connect and operate BT41 Telephony Base.

Usage Requirement

You can use the Bluetooth Telephony Base with any desktop phone and Bluetooth wireless headset that is compatible with Bluetooth wireless technology and supports the Headset Profile (as audio gateway).

This User's Guide is published by ATO without any warranty. Improvements and changes to this User's Guide necessitated by typographical errors, inaccuracies of current information ,or improvements to programs and /or equipment, may be made by ATO at any time and without notice.

Headset / Handsfree Profile-Defined by the Bluetooth Special Interest Group (SIG), it describes how manufacture should implement the various features supported by a Bluetooth Headset.

The Bluetooth trademarks are owned by Bluetooth SIG, Inc.USA.

Operating BT41

Making outgoing call

- Press the number you want to call from the desktop phone pad (as you normally will do when trying to make a call with the desktop phone).
- Press Bluetooth headset TALK button and wait for a dial tone (indicator light will turned blue).
- After the call is connected, user may talk with the headset.
- When the call is finished, press the TALK button again to end.

Receive incoming call

- When there is incoming call (ringing sound can be heard in both headset and the desktop phone), press the headset TALK button to receive the call.
- To hang up, press the headset TALK button once again.

Production information

What's in the box

- BT41 Telephony Base main body
- Stand
- Power adapter with cord
- Connection cord
- User's Manual

Troubleshooting

This section lists some problems that you might encounter while using your headset.

No sound contact between headset and other device
The headset and the device you are using with it have to be paired to recognize each other. They also have to be within range of each other. Make sure the headset and the device you are using are no more than 10m./30ft.apart with no solid objects in between.


No Indicator of charging is shown
If your headset battery is empty, or has mot used for a long time, it may take several minutes before a light to indicate charging (a steady red light) appears.

Pairing Unsuccessful
If pairing has not been succeeded for a few times, you may have to reset the headset first before pairing.


To Reset BT41
Disconnect the power source from the unit and then reconnect again. The unit is now reset.

Appearance


Front view



Back view



Bottom view



Important Information

Please read all this information before using the Bluetooth headset

- Check for any exceptions or rules, due to national / local requirements or limitations, in usage of this Bluetooth Telephony Base or any other Bluetooth devices.
- Check also the laws and regulations on the use of mobile phones and handsfree equipment in the areas where you drive.
- Please note that only the ATA authorized dealer or service partner should remove and/or replace the unit, or any other components.
- Please use ATA original accessories only. Use of non-ATA original accessories may result in damage, loss of performance to the product, injury, electric shock or even fire.
- Please do not expose the product to extreme high or low temperatures, moisture or fluid.
- Please do not drop, throw or bend the product as rough treatment will damage it.
- If BT41 will not be used for a while, please store it in a place that is dry, free from moisture, dust, and extremes temperature.
- Some medical electronic equipment may not be shielded from RF energy. Therefore, please so not use the headset near medical equipment without permission.
- Please turn off the headset before boarding any aircraft. To prevent any interference with communication systems, please do not use the headset while the plane is in the air.
- Please turn off the headset in the blasting areas or any area with a potentially explosive atmosphere.
- Please do not allow children to play with the unit since it contains small parts.

Note:Important - the unit connected to the headset or any electronic device using radio frequency signals, which cannot guarantee connection under all conditions or circumstances. Therefore, please never rely solely upon the headset for essential or emergency communications.

Warranty

Telephony Base BT41

Thank you for purchasing BT41 Telephony Base. Within the warranty period, if the product fails to operate under normal use and service, due to improper workmanship or material, the authorized dealers will, at their option, either replace or repair the product in accordance with the following terms and conditions:

- The warrnaty is valid only if the original receipt issued to the original purchase by ATA authorized dealer is presented with the product to be replaced or repaired. The date of purchase and serial number shall be specified in receipt. For the replacement and repair policies and procedures in the countries / provinces which the product is purchased, please refer to the local ATA authorized dealer.
- The warranty does not cover any failure of product due to normal tear and wear, or misuses, including but not limit to use in other than the manner according to the instructions for operation and maintenance of the product. The warranty also does not cover any failure of the product due to modification, adjustment, accident, acts of God, or any improper use or storage.
- The warranty does not cover product failure due to improper repair, modification, adjustment, installation, or service by a non authorized ATA services partner.
- The warranty does not cover product failures caused by the use of non ATA original accessories.
- ATA shall not be liable for any losses, damages whatsoever, including but not limit to any lost of profits, damage to property, personal injury and death, arising under or related to the use of the product and/or the accompanying software, written material or from errors, deficiencies or fault, whether such loss or damage is caused by negligence or otherwise.
- The warranty terms and conditions will be subject to change without prior notice.