

**User Manual**  
**Product:SUM**  
**Brand:CS**  
**Model:CS1**  
**FCC ID:QLPCS1**

# 1, User Guide for SUM\_CS1

**Product Name** : SUM

**Product Applications** : Wireless control and color LED flashing

**Sostark Model Number:** CS1

**Manufacturer** : Sostark Pte Ltd

Blk20, Sin Ming Lane, #08-52  
Midview City  
Singapore 573968

Office: +65 9478 3438  
Email: [support@sostark.com](mailto:support@sostark.com)

- (1) Put the battery in to the frame (CR2032 x 2)
- (2) Press the button: 9 working mode (8 pattern modes, 1 audio-sync mode), LEDs will flash accordingly
- (3) Product reset: press and hold for 5 second
- (4) After a while, the wristband will enter to sleep mode, LEDs will off; it only wakes up if the button is pressed again or receive TX wake-up signal
- (5) New battery lasts max for 3 days without LED flashing; Flashing the LEDs last max for 8 hour

## 2. INTRODUCTION

The SUM\_CS1 offers users a small accessory with colorful LED flashing wristband which can flash according to the music or by phone or pad app.

### (1) APPEARANCE



### (2) GENERAL SPECIFICATION

- Chipsets: Silabs(RF) and TI(LED drive)
- Frequency Band: 903.88~923.88MHz
- Modulation: GFSK
- RF Power: -1.3dBm follow 15.249
- Power Source: 2X Primary CR2032, DC3V, 220mAh

## IMPORTANT REGULATORY INFORMATION

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference that is received, including any interference that may cause undesired operation.

### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.