

Coolpad Quattro[®] II 4G

User Manual

Table of Contents

YOUR PHONE	10
FUNCTIONS OF KEYS	11
CONVENTIONS USED IN THIS GUIDE.....	12
1. GETTING YOU STARTED.....	13
<i>Charging the battery.....</i>	<i>13</i>
<i>Power phone on & off.....</i>	<i>14</i>
<i>Touch screen & typing directions</i>	<i>14</i>
<i>Other touch tips</i>	<i>15</i>
2. MORE BASICS.....	16
<i>How your phone looks</i>	<i>16</i>
<i>Screen-lock security options</i>	<i>17</i>

<i>Modifying phone sounds</i>	18
<i>Changing other settings</i>	18
<i>Screenshots</i>	18
3. PHONE APPS MADE SIMPLE	19
<i>Making a call</i>	19
<i>Answering & redirecting calls</i>	19
.....	20
<i>Exploring the call log</i>	20
<i>Checking your voicemail</i>	21
4. TEXTING & KEYBOARD USE	22
<i>Entering & editing text</i>	22
<i>Next-word suggestions</i>	22
5. CUSTOMIZING & USING YOUR COOLPAD QUATTRO® II 4G PHONE APPS	24

<i>Customizing your Home screen</i>	24
<i>Contact Book</i>	24
<i>Setting up & using Gmail</i>	25
<i>Controlling your calendar</i>	27
<i>Operating the alarm</i>	28
<i>Managing your downloads</i>	28
6. PHONE SET-UP AND PHONE MANAGEMENT	30
<i>Privacy settings & accounts</i>	30
<i>Managing location history</i>	31
<i>Managing sound, screen & sleep settings</i>	31
<i>Notifications</i>	32
<i>Airplane mode</i>	32
7. WIRELESS NETWORK SETTINGS	33

<i>Turning on Wi-Fi</i>	33
<i>Modifying network settings</i>	34
<i>Adding on a Wi-Fi network</i>	34
<i>Setting Wi-Fi advanced options</i>	35
8. CONNECT TO BLUETOOTH	36
<i>Powering Bluetooth on/off</i>	36
<i>Changing your phone's Bluetooth name</i>	36
<i>"Pairing" your phone with a Bluetooth device</i>	37
<i>Connecting to a Bluetooth device</i>	38
<i>"Un-pairing" or aligning a Bluetooth device</i>	38
<i>Monitoring your phone's data usage</i>	39
9. CREATING & SHARING VIDEOS, PICTURES	40
<i>Creating a video</i>	40

<i>Taking a photo</i>	40
<i>Sharing a video or photo</i>	41
10. DATA USAGE SETTINGS	42
<i>Manage your data usage settings</i>	42
<i>Setting a data usage limit warning</i>	43
<i>Setting your data usage limits</i>	43
11. GOOGLE PLAY STORE	44
<i>Accessing Play Store</i>	44
<i>Google Play Settings</i>	45
12. USB FILE TRANSFERS	46
<i>Windows transfer</i>	46
<i>Mac OS transfer</i>	47
13. OPTIMIZE YOUR PHONE'S BATTERY LIFE	48

<i>Battery settings</i>	48
14. STAY CONNECTED & GET UPDATES	50
15. COOLPAD QUATTRO® II 4G SPECS & HARDWARE	51
<i>List of In-Box Contents</i>	53
<i>Declaration of Hazardous Substances</i>	54

A Message From Coolpad:

Thank you for purchasing your Coolpad Quattro® II 4G mobile phone! Please follow these simple - but *important* - instructions for optimal use of your new phone:

Before using your phone for the first time, please carefully read this User Guide, especially the security information.

Note: Products or services of the vendor or carrier are subject to change within this User Guide without prior notice.

Application features and functions may vary among countries, regions or hardware specifications, and any third-party application malfunctions are the responsibility of those manufacturers.

Use care if editing User Registration Settings as this may cause functional or compatibility problems for which Coolpad will not be responsible.


Most of all, we want you to thoroughly enjoy your new Coolpad Quattro® II 4G phone and get the most out of all of its remarkable features!

Trademarks and copyrights

Copyright © 2013 Coolpad Technologies, Inc. All Rights Reserved. All materials in this document including, without limitation, the design, the text, and any and all marks (unless otherwise indicated) are the property of Coolpad Technologies, Inc. Coolpad and the Coolpad logo are registered trademarks of of Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. Google, Android, Gmail, Hangouts, Google Play, YouTube. Additional related marks are trademarks of Google Inc. Swype is trademarks or registered trademarks of Nuance Communications, Inc.

Attention: Picture shown is for illustration purpose only and do not represent actual devices.

Your Phone



Functions of Keys

Keys	Functions
Menu Key	Tap the option interface to enable the Menu pop-up.
Home Key	Application interface returns to the Desktop.
Back Key	Return to the previous interface.
Volume Key	Adjust the volume of calls, ringtone, music and videos.
Power/Screen Lock Key	Tap to turn off the background light. Tap to re-activate the phone. Press and hold to turn on or off the Power.

Note: Touch Screen Menu, Home and Back are tap keys .

Conventions used in this guide

- This indicates some important tips of using the phones, such as what to do and what to avoid to keep good condition of the phone.
- ✓ This explores different functionalities of an app or a setting.

Note: This is a note or notification gives you additional information on operating your phone.

1. Getting you started

Get off to a running start with your new Coolpad Quattro® II 4G


Charging the battery

1. First, connect one end of the data cable to the USB/Power Port. This is located at the bottom of your phone.
2. Connect the other end to the travel adapter.
3. Connect the travel adapter to an electrical outlet & fully charge your phone.



Note: *Your phone has a built-in UICC card.*


- Use the travel adapter that accompanies your phone; using other adapters may damage your phone.



- Charging your phone through a USB cable that is attached to a laptop takes more time than charging it with the travel adapter.

Power phone on & off

- The **Power Button** is located on the upper, side of your phone. Press and hold the **Button** for a few seconds to turn on your
- To turn off your phone, press and hold the **Button** to enable the Menu pop-up, and **Power Off**.



Touch screen & typing directions

1. Tap selected icon or other items in order to select or activate them.
2. For typing a message, select **Message icon** at bottom of your phone and the keypad will appear.
3. For Swype-typing, which can be an easier method of typing by swiping, select **Yes** at prompt

asking whether you'd like to use Swype Technology.




4. Otherwise, type as normal for messaging, and also for Google searches.

Other touch tips

- ✓ Touch & continuously hold an object on your phone screen without lifting your finger, you can then reorganize your apps layout or drag apps to the home screen .
- ✓ To drag something, touch & hold an object without lifting your finger, then move your finger on the screen until you reach the object.
- ✓ Slide or swipe by quickly gliding your finger across the surface of the screen without pausing. Lift your finger before spelling a new word or name.
- ✓ To zoom in/enlarge, double-tap by tapping two times on a screen object (such as Google Maps). Tap again two times to zoom out.
- ✓ Some apps allow you to zoom in & out by placing two fingers on the screen, pinching them towards each other or spreading them apart to zoom in or out, respectively.

2. More basics

How your phone looks

1.  Back Key: Return to your prior screen.
2.  Home Key: Opens home.
3.  Menu Key: Pull up setting menus.
4. Close or open recent apps: holding down the home key opens a list of your recent apps. Tap an app to open it or remove an app from the list by swiping left or right.

Screen-lock security options

1. To lock your phone, press the **Power Button** (on the phone's right side) briefly, and let go.
2. To unlock, press **Power Button** on, let go & slide the Padlock icon to the right.



Modifying phone sounds

Go to **System Settings > Device > Sound** to modify your phone's notification sounds.

Adjust Volume by pressing buttons on the side of your phone.

Changing other settings

To modify your phone's Brightness or Font size, go to **System Settings > Device > Display**

To Customize wallpaper


Go to **System Settings > Device > Display > Wallpaper**

Screenshots

1. To take a screenshot, focus on the image so it displays on your phone screen.
2. Press the **Power Button & Volume Down keys** at the same time.
3. The image will be auto-saved in your phone's Gallery.

3. Phone apps made simple

Making a call

- Tap the Phone icon on your Home or All Apps screen to make a call.
- Calls can also be made from the Phone app or any other widgets or apps that contain your contact information, by simply tapping the phone number.
- Once you are in the Phone app, there are three tabs at the top. Tap any one of them for making calls.
- The **Call log icon** displays your recent calls. Tap  to return the call.
- The **Contacts icon** displays frequently called numbers along with your contacts. Tap to dial.
- Touch the red **Phone icon** at the bottom of your phone to hang up.

Answering & redirecting calls

1. The **Incoming Call screen** pops up when a call is coming in, along with the caller ID & other

information you've entered in your Contact Book.

2. Any missed calls are logged in the Call log, along with a notification.
3. Press the **Volume Down key** on side of phone to mute the ringer.
4. There are various options for when a call comes in. To answer a call, slide the **Unlock key** over to the answering key on the right.



You may:

- ✓ Answer the call
- ✓ Start talking to the caller
- ✓ Send to voicemail
- ✓ Send a message by opening quick text responses & then tap one of them.

Note: To modify these standard text responses, tap **Menu > Settings > Call Settings > Quick responses**.

Exploring the call log

- The Call log contains your history of calls received, missed or made.

- Tapping the number will reveal more information about the call.
- Tapping the phone icon beside the number returns the call.
- Tap to send a text message.
- Tap the **People icon**  for contact info.
- Tap to  add New Contact.
- To clear your Call log, tap **Menu > Clear Call Log**.

Checking your voicemail

Have a new voicemail? The Voicemail icon will pop up on your screen.

- Read your voicemail by swiping to reveal notifications.
- Voicemail notification shows number of unread messages & a number to dial.
- Check with your carrier to find out the default voicemail dial in number for your phone.

4. Texting & keyboard use


Entering & editing text

Enter text by using the screen's keyboard. To open your phone's keyboard, simply tap where you want to type.


- Otherwise, some apps will open the keyboard for you!
- To close the keyboard, tap the **Back key** below the keyboard.



Next-word suggestions

1. Tap where you want to type text.
2. Begin typing a word. Choose one of the words displayed above the keyboard.
3. If you don't want to use those words, type the next word without using the space bar.
4. Your phone will continue to present word choices while you




type.

5. To turn Next-word suggestions on or off, go to **Swype Settings** (Tap and hold press Swype symbol  will direct you to Swype setting page)
6. Check the box adjacent to **Next-word prediction**.



5. Customizing & using your Coolpad Quattro® II 4G Phone Apps

Customizing your Home screen

1. Go to the Home screen where you want to position an app.
2. Tap the **All App icon** .
3. Swipe right to locate your app (or widget), then touch it until the Home screen comes up.
4. After sliding the app into place, lift your finger.
 - ✓ To move an app (or widget icon) to a different place on a Home screen, touch & hold the icon, and then slide your finger to its new position.
 - ✓ To move between Home screens, swipe toward the edge of the screen. Move an icon out of the way by sliding slowly into it & lifting your finger. The icon will then fall into the new spot.

Contact Book

- The Contact Book easily saves all of your important contact information including contact names, numbers and email addresses.
- It also supports an assortment of other communication operations.
- To search your Contacts, tap the **Search key** in Contact List, enter search characters in the search box & the Coolpad system will automatically reveal matching results.
- To add a New Contact, tap **Add Contact** on the Contact List & select the storage location of the New Contact.
- Type the contact information in **Edit Contact** & save **New Contact** in your Contact List.



Setting up & using Gmail

1. Tap the **Gmail icon** for reading and composing emails.
2. To open it, tap the **Gmail icon** on a Home or All Apps screen. Here Gmail has various uses. For instance, utilize your Gmail account for signing in to all Google apps & services, including, but not limited to:
 - ✓ Calendar
 - ✓ People, keeping track of Contacts



✓ Google Drive


Getting familiar with your Email App:


1. Tap the icons and menu along the top of the screen to archive, delete, label, or enable other message actions.
2. Swipe left or right to read prior or new email conversations.
3. Check the box next to a message in order to select it.
4. Tap the menu & icons at the top of your phone screen to manage your messages.
5. Enter your current email address, or add a new one, followed by your password.
6. Press & hold the email account for a pop-up menu to customize your Email Settings.
7. Upon turning on your phone & signing into a Google account, current contacts from that account are auto-synced with your People app.

Note: If you are using Microsoft Exchange, that contact info can also be synced with your People app.

Controlling your calendar

To open your calendar, tap the **Calendar icon** on a Home or All Apps screen.

- If you have synced your Gmail account, the first time you open the Calendar app on your phone, it will show your current calendar events.
- To modify the Calendar view, choose Day, Week, Month or Agenda from the top of the screen by tapping on the month/year.
- View event details by tapping an Event.
- Tap blank square on the calendar screen until  shows up, tap it to add new events; or click an existing event to edit it on a new window.



Operating the alarm

For powering alarm On/Off, tap alarm & swipe to the left.

- > Tap **Time**, which will take you to Set Time.
- > Once your alarm is set, you may add a label to it & choose your Ringtone (or Vibrate) by selecting within the drop-down menu under Set Alarm.

**Managing your downloads**

- Tap the **Downloads icon** on the All Apps screen.
- To enjoy music, movies, etc., from Google PlayStore, Google servers stream your favorites from Google servers while you're playing them.
- Although they are not designed to occupy phone space, you can pin (aka download) books, movies, and other media in order to access everything offline.
- You can also download files from Gmail or other areas.
- Going to the Downloads app, tap an item to open it.
- Tap headings for earlier downloads to view them.

- Simply check what you'd like to share by tapping the **Share icon** & choosing a sharing method from the drop-down menu.
- Check any downloads that you want to delete, & then tap the **Trash icon**.
- Tap **Sort by size** or **Sort by date** at the bottom of your phone.
- If you are connecting your phone to a PC or laptop, view the Download directory for available files contained in the Downloads app. Here you may copy files as well.

6. Phone set-up and phone management

Privacy settings & accounts

These settings control your phone's Google Search privacy features & search-related confidentiality selections for your Google account.

Menu > System Settings > Accounts > Google > Search > Privacy & accounts.

From your phone's main Settings app:

System Settings > Accounts > Google > Search.

Tap the Google Search setting to learn more.

Managing location history

1. Open **Google Maps settings** in order to turn on/off Location settings & Location reporting.
2. Google Location settings enable location access to be turned on/off.

Managing sound, screen & sleep settings

Sound settings: Go to **System Settings > Device > Sound > Volumes**.

- Swipe the slider for volume levels on Music, videos, games, & other media.
- Or you can always press the volume control up/down on the left side of your phone.

Screen settings: Go to **System Settings > Device > Display > Brightness**.

Sleep settings: Go to **System Settings > Device > Display > Sleep**. Tap one of the options to select.

Ringtone settings: Go to **System Settings > Device > Sound > Phone ringtone** (or select Vibrate when ringing).

Notifications

- On top left of your phone, status icons will pop up displaying which apps have sent you notifications.
- For finding notifications, use one finger to pull the notification shade down from the top of your phone screen, or swipe up, then to the right.
- The Quick Settings menu reveals your settings for Bluetooth, WIFI, etc.

Airplane mode

Airplane mode is ideal for in-flight phone status, where no signal or Wi-Fi is connected.

System Settings > Wireless & Networks > More...> Airplane Mode

7. Wireless network settings

Turning on Wi-Fi

At initial phone set-up, Wi-Fi is turned on automatically.

1. To turn Wi-Fi on/off, go to **System Settings > Wireless & networks > Wi-Fi**.
2. To manage data usage and set mobile data limit, go to **System Settings > Wireless &**



Note: If you've been connected to a prior Wi-Fi network & your phone can locate it, you will be auto-connected.

- networks > Data usage.**
3. Swipe the **Wi-Fi switch** to On for enabling your phone to scan for available Wi-Fi networks. It will show the network(s).
4. Tap desired network name to connect, entering your password if necessary.


Modifying network settings

To modify a network's settings, press & hold a particular network name in order to change the network's settings.

Adding on a Wi-Fi network

1. A Wi-Fi network may be added so that your phone will recognize it along with any of its security credentials, and then it will auto-connect.
2. Always add a Wi-Fi network if the network name is not transmitted (SSID), or when you are out of range.
3. Tap the **Plus icon** on the top of your phone's screen.
4. Enter the SSID network name.
5. Tap **Save**. Your phone will auto-connect to this network whenever you return to its range.

Setting Wi-Fi advanced options

Go to Wi-Fi Settings screen, tap **Menu**  **> Advanced.**

- You will receive Wi-Fi notifications for available networks in your status bar. To disregard notifications, uncheck this option.
- To save your phone's data usage, your phone will remain connected to Wi-Fi when your screen sleeps.

8. Connect to Bluetooth

Bluetooth has the capacity to connect several mobile devices at once, enabling superior synchronization while reversing challenges and problems that would otherwise occur. Use Bluetooth to maximize your Coolpad Quattro® II 4G's awesome phone capabilities & functions!



Powering Bluetooth on/off

Tap **System Settings > Wireless & networks > Bluetooth** and then slide the switch for Bluetooth to on (or off).

Changing your phone's Bluetooth name

Your phone contains a random Bluetooth name which will be visible to other Bluetooth devices during connection attempts. By changing the Bluetooth name, it will be more identifiable.

1. Go to **System Settings > Wireless & networks**, and be certain Bluetooth is turned on.
2. Tap **Bluetooth**.
3. Within the Bluetooth screen, tap **Menu > Rename phone**.

4. Now enter a new name & tap **Rename**.

“Pairing” your phone with a Bluetooth device

When initially using a new Bluetooth device, it will be necessary to “pair” it with your phone, which is crucial in order to connect.

Now both devices save the connected record and will auto-connect for you next time.

If the device to pair with isn't contained on the list, confirm that it is turned on and that it is set to be detectable.

1. Go to **System Settings > Wireless & networks** and ensure Bluetooth is turned on.
2. Tap **Bluetooth**. Your phone will begin seeking for nearby Bluetooth devices.
3. If your phone stops scanning before your Bluetooth device is ready, tap Search for devices.
4. Within the list, tap the ID of the Bluetooth device so as to pair with it. Follow the instructions to complete the pairing.
5. If necessary, enter a regular passcode such as 0000 or 1234. Likewise, consult the documentation that came with the device.

Connecting to a Bluetooth device

Now that your phone is paired with a Bluetooth device, it can be connected to it manually.

1. Go to **System Settings > Wireless & networks > Bluetooth**, ensuring that Bluetooth is turned on.
2. Within the devices list, tap a paired and unconnected device.
3. The list will indicate that the device and the phone are connected.

“Un-pairing” or aligning a Bluetooth device

Some Bluetooth devices have multiple profiles. Profiles can include the ability to transmit your conversations, play music in stereo, or transfer files or other data.

You can select which profiles you want to use with your phone. You can also change the name of the Bluetooth device as it appears on your phone.

1. Under **System Settings > Wireless & networks > Bluetooth**, ensure that Bluetooth is turned on.
2. Within Bluetooth settings, tap the **System Settings icon** next to the connected Bluetooth device for which you are configuring.

3. You will now be offered the choices to either change the name, un-pair it or select profiles.
4. When you're done, tap the **Back key**.

Monitoring your phone's data usage

Although subject to your device and wireless plan, extra fees may be incurred when your data usage surpasses your plan's limit.

Therefore, it is imperative to monitor the data you've uploaded or downloaded on to your phone. Do this by going to **System Settings > Wireless & networks > Data usage**.

9. Creating & sharing videos, pictures

Creating a video

1. To capture a video, simply tap the **Camera icon** from your Home screen.
2. Next, tap the **Video Camera icon** on the lower portion of your screen.
3. Now tap the red **record key** while using the screen in order to see your video while you're recording it.
4. Tap the **red key** once again to stop recording.



Taking a photo

1. To snap a picture, tap the **Camera icon**.
2. Tap the **Camera icon** once again on the lower part of your phone.
3. Focus on your subject by looking through your phone screen.
4. Press the **blue key** to take a picture.

Sharing a video or photo

1. To share a video or photo, first be sure to name it.
2. Then go to **App > Gallery**.
3. Tap your selected video & Share icon to the right of the video title/name.
4. From the drop-down options, select your method of sharing by tapping on it.
5. Tap **Gallery** to view and manage all of your videos and pictures.

It really is that easy! Your new Coolpad Quattro® II 4G makes it that way.

10. Data usage settings

Manage your data usage settings

Here data usage settings for your new Coolpad Quattro® II 4G are described, but they are carrier-specific.

The following instructions will assist in tracing data usage, which may or may not help avoid possible additional charges.

Note: Be sure to check with your carrier for further information.

1. Go to **System Settings > Data usage > Slide Mobile data to On.**
2. Here you will see a graph. The white lines that are vertically displayed present a time period within the data usage phase.
3. Touch and drag the white lines in order to change a data usage time period.
4. Your actual data usage is shown underneath the graph.

Setting a data usage limit warning

Touch and drag the **orange line** on its right side to the point where you wish to receive a data usage warning notification.

Setting your data usage limits

1. Go to **System Settings > Data usage > Slide Mobile data to On**.
2. Activate the **red line** at the top of the graph by checking Set mobile data limit.
3. Touch and drag the **red line** on its right side to the point where you wish to set the limit. Your data will automatically switch off when your usage limit has been reached.
4. Various phone features will not work correctly and a notification will pop up at this time.

11. Google Play Store

Google Play Store is all-in-one entertainment point with music, movies, books and apps on the web.



Accessing Play Store

1. To access your Play Store app, tap the **Play Store icon** in your Favorites tray on your Home screen.
2. By tapping the **Menu** icon in any section, My Apps, My Wishlist, etc., will pop up which will display your content for that part of Google Play.
3. Your Google Play content can be retrieved this way (from the Play Store app) even if you have acquired it through another phone.
4. Sign in to play.google.com to access your entertainment from any location.

Google Play Settings

1. Modify your Google Play settings by choosing the option you want from the Menu in the top right corner.
2. The Google Play settings screen enables you to:
 - ✓ Control game & app updates' notifications.
 - ✓ Setting for auto updates for apps and widgets
 - ✓ Clear search history.
 - ✓ Manage user controls.

12. USB File Transfers

- By using a USB cable, you may transfer pictures, music, and other data files from your Coolpad Quattro® II 4G on to your PC or laptop, & vice versa.
- For transferring files to Mac OS X, the Android File Transfer application can be utilized. (Refer to instructions below.)

Windows transfer

1. First, connect your phone to the computer's USB port. Its USB storage drive will show on the computer screen.
2. Begin copying files between your phone & the computer.
3. When you finish, eject the phone from within Windows before unplugging the USB cable.

Mac OS transfer

1. Install Android File Transfer <http://www.android.com/filetransfer> and follow the directions. Double-click for first-time use. (Auto-connect will occur thereafter.)
2. Connect your phone to the computer using a USB cable.
3. The Android File Transfer will begin, including a window pop-up showing your phone contents & other pertinent information.
4. Here you can open & close folders, create new folders, & drag files.
5. Disconnect the USB cable upon completion.

13. Optimize your phone's Battery life

Battery settings

Prolong your phone battery life by turning off apps that aren't being used or aren't needed.

Go to **System Settings > Device > Battery**.

Here you may monitor how apps, other data and your phone system all consume battery power.

- Turn off **Wi-Fi, Bluetooth** or **GPS** with the **Settings app**.
- For the GPS setting, go to **System Settings > Personal > Location services**.
- Turn off **Navigation** or **Maps** when not in use.
- Dim your phone's screen brightness: **System Settings > Device > Display**.
- Consider turning off auto-sync for all apps. Go to **System Settings > Accounts > Google account-name**.

Note: If auto-sync is turned off, you must manually sync to check emails, and notifications will no longer pop up.

- Assessing battery level and usage, Go to **System Settings > Device > Battery**.

- Battery usage for each app is displayed near the bottom of your phone screen.
- Get more details by tapping an app. For some apps, you may modify power usage settings, or halt the app entirely.

*Note: If you stop some apps or services completely, your phone may not operate correctly.
The battery status & battery levels are indicated at the top of your phone screen.*

14. Stay connected & get updates

- ✓ Get updates, user guides, PC software and accessories for your Coolpad Quattro® II 4G at www.coolpadamericas.com.
- ✓ Discover what's going on right now in cell phone news, trends, techniques & other cool stuff by connecting with us at:



www.facebook.com/user/CoolpadAmericas



www.youtube.com/CoolpadAmericas



www.twitter.com/CoolpadAmericas

15. Coolpad Quattro® II 4G specs & hardware

Specifications		
Dimensions	5.2 x 2.6 x 0.43 (inches)	
Form Factor	Bar, Touchscreen	
Antenna	Built-in	
SIM Card	Micro SIM	
Network Mode	CDMA (EVDO) + LTE	
Camera	Front camera: VGA; Rear camera: 5.0 MP	
Earphone Jack	CTIA Standard earphone jack	
Screen Parameters		
Type	Dimensions	Resolution
QHD	4.5 inches	960x540
Accessories		

Battery	Battery Type	Lithium Ion Polymer Rechargeable Battery
	Rated Capacity	1800 mAh
	Nominal Voltage	3.7 V

Prompt: The battery capacity changes with battery upgrade.

List of In-Box Contents

No.	Name	Quantity
1	Phone	1
2	Battery	1
3	Travel Charger	1
4	USB Charger Data Line	1
5	Micro SD Card	1

Prompt: The accessory items are as per the final transaction.
Please contact the dealer for further details.

Declaration of Hazardous Substances

Parts Name	Toxic or hazardous substances or elements					
	Plumbum (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium VI (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB Board and Accessories	x	o	o	o	o	o
Plastics	o	o	o	o	o	o
Metals	x	o	o	o	o	o
Battery	x	o	o	o	o	o
Other	x	o	o	o	o	o

o: indicates that the content of the toxic or hazardous substance in all homogeneous materials is within the limit of the SJ/T11363-2006 standard.

x: indicates that the content of the toxic or hazardous substance in some homogeneous materials exceeds the limit of the SJ/T11363-2006 standard.



The Environmentally Friendly Use Period of this product is 20 years, as shown by the symbol on the left.
The Environmentally Friendly Use Period of replaceable parts, such as battery, may be different from that of the product. The Environmentally Friendly Use Period is valid only when the product is operated under the conditions defined in this User Guide.

FCC Regulations:

This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Note:

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528. This device has been tested and meets the FCC RF exposure guidelines when tested with the device directly contacted to the body.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: R38YL801ES.

For this device, the highest reported SAR value for usage against the head is 0.70 W/kg, for usage near the body is 1.58 W/kg.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 10 mm between the unit and the human body. Carry this device at least 10 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 10 mm between this device and your body.

RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.

FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices

On July 10, 2003, the U.S. Federal Communications Commission (FCC) Report and Order in WT Docket 01- 309 modified the exception of wireless phones under the Hearing Aid Compatibility Act of 1988 (HAC Act) to require digital wireless phones be compatible with hearing-aids. The intent of the HAC Act is to ensure reasonable access to telecommunications services for persons with hearing disabilities. While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than


others to this interference noise, and phones also vary in the amount of interference they generate. The wireless telephone industry has developed a rating system for wireless phones, to assist hearing device users to find phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box. The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to generate less interference

to hearing devices than phones that are not labeled. T4 is the better/ higher of the two ratings.

Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise. The hearing aid and wireless phone rating values are then added together. A sum of 5 is considered acceptable for normal use. A sum of 6 is considered for best use.



In the example to the above, if a hearing aid meets the M2 level rating and the wireless phone meets the M3 level rating, the sum of the two values equal M5. This should provide the hearing aid user with

“normal usage” while using their hearing aid with the particular wireless phone. “Normal usage” in this context is defined as a signal quality that’s acceptable for normal operation.

The M mark is intended to be synonymous with the U mark. The T mark is intended to be synonymous with the UT mark. The M and T marks are recommended by the Alliance for Telecommunications Industries Solutions (ATIS). The U and UT marks are referenced in Section 20.19 of the FCC Rules. The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

When you're talking on a cell phone, it's recommended that you turn the BT (Bluetooth) mode off for HAC.

This phone meets the M4/T3 level rating.

For information about hearing aids and digital wireless phones

Wireless Phones and Hearing Aid Accessibility

<http://www.accesswireless.org/Home.aspx>

FCC Hearing Aid Compatibility and Volume Control

http://www.fcc.gov/cgb/consumerfacts/hac_wireless.htm

Some content and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and/or other intellectual property laws. Such content and services are provided solely for your personal noncommercial use. You may not use any content or services in a manner that has not been authorized by the content owner or service provider. Without limiting the foregoing, unless expressly authorized by the applicable content owner or service provider, you may not modify, copy, republish, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner or medium any content or services displayed through this device.

“THIRD PARTY CONTENT AND SERVICES ARE PROVIDED “AS IS.” NEITHER COOLPAD NOR ANY AFFILIATE THEREOF (COLLECTIVELY, "COOLPAD") WARRANT IN ANY MANNER CONTENT OR SERVICES

SO PROVIDED, EITHER EXPRESSLY OR IMPLIEDLY, FOR ANY PURPOSE. COOLPAD EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. COOLPAD DOES NOT GUARANTEE THE ACCURACY, VALIDITY, TIMELINESS, LEGALITY, OR COMPLETENESS OF ANY CONTENT OR SERVICE MADE AVAILABLE THROUGH THIS DEVICE AND UNDER NO CIRCUMSTANCES, INCLUDING NEGLIGENCE, SHALL COOLPAD BE LIABLE, WHETHER IN CONTRACT OR TORT, FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, ATTORNEY FEES, EXPENSES, OR ANY OTHER DAMAGES ARISING OUT OF, OR IN CONNECTION WITH, ANY INFORMATION CONTAINED IN, OR AS A RESULT OF THE USE OF ANY CONTENT OR SERVICE BY YOU OR ANY THIRD PARTY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.”

Third party services may be terminated or interrupted at any time, and Coolpad makes no representation or warranty that any content or service will remain available for any period of time.

Content and services are transmitted by third parties by means of networks and transmission facilities over which Coolpad has no control. Without limiting the generality of this disclaimer, Coolpad expressly disclaims any responsibility or liability for any interruption or suspension of any content or service made available through this device. Coolpad is neither responsible nor liable for customer service related to the content and services. Any question or request for service relating to the content or services should be made directly to the respective content and service provider.