

FCC NOTICE

WARNING : The antenna must be installed in a manner that ensures a minimum separation distance of 20 centimeters between the antenna and human beings.

.RF Radiation Exposure

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

.Warning ! No user serviceable parts

Alteration or modification to any part of this equipment, without the prior written consent of the manufacturer,

will invalidate all manufacturer approvals and warranty. No adjustments can be undertaken except by qualified

and licensed persons as defined by the FCC Rules and Regulations. Operation of altered equipment can result

in fines, imprisonment, and /or confiscation of such equipment.

User Manual

1. Send message - individual

LCD display = Enter Pager no.

Press pager number and press "send"

2. Send message - to all pagers group

LCD display = Enter Pager no.

Press 9111 and press "send"

3. Set time

Press "set up"

LCD display = Set Current Time

Press times and minutes, and press any numeric buttons to choose AM or PM.

If everything is correct, press "select" to set up.

If any mistakes, press "Enter"

You can change times, minutes and AM or PM.

Once corrected, press "select" to set up.

4. Password

LCD display = Input Password?

Press password and press "Enter"

The master password is "0852".

If new password, 'Type again' will appear and you need to press the new password twice.

5. Adding new pager

LCD display = Add New Pager

Num > Cap code > Cnt

Num = 1st pager you want to program

Cap code = The cap code of the 1st pager you want to program.

Cnt = Total number of pagers you want to program.

After completion, press "select".

6. Erasing Pager

LCD display = Erase Pager

Num > Cap code > Cnt

Num = 1st pager you want to erase

Cap code = It skips because the cap codes are already programmed.

After completion, press "select".

7. Setting Group Call

LCD display = Set Group Call no.

9111 > 0010000

Press group number you want to use and press "enter".

The group number has been changed now.

If possible not to change it because it may create confusion unless you use the same Tx for very close two hospitals or churches.

8. Go to initial mode.

Press "cancel" any time and you can go to the initial mode any time.