


| Model | Configuration | Label | Remark |
|-------|---------------|-------|-----------|
| HA4YA | Standard | ASUS | ASUS Logo |
| HA4YA | Standard | ASUS | ASUS Logo |
| HA4YA | Standard | ASUS | ASUS Logo |
| HA4YA | Standard | ASUS | ASUS Logo |

A Cover LABEL LOCATION




No need label

B Cover LABEL LOCATION



| | |
|---|--|
| | |
| CPU Label for IP series H0-00000000 H0-00000000 | H0-00000000, H0-00000000 H0-00000000, H0-00000000 |

C Cover LABEL LOCATION



Label 位置 請參閱圖 1 及圖 2
Label align to the top edge of Touch Pad


Label 位置 請參閱圖 1 及圖 2
Bottom edge of Label should align to the bottom edge of Touch Pad

| | | | | | |
|---|--|--|---|--|---|
| | | | | | |
| CPU Label H0-00000000 H0-00000000 | ENERGY LABEL H0-00000000 H0-00000000 | H0 Label H0-00000000 H0-00000000 | TUV Label H0-00000000 H0-00000000 | VESA Label H0-00000000 H0-00000000 | DVI Label H0-00000000 H0-00000000 |

區域 1 Label

| | | | | |
|---|--|--|---|---|
| | | | | |
| INTEL RECYCLE LABEL H0-00000000 H0-00000000 | ENERGY LABEL H0-00000000 H0-00000000 | WARRANTY LABEL H0-00000000 H0-00000000 | J-CALL CENTER LABEL H0-00000000 H0-00000000 | DVI LABEL H0-00000000 H0-00000000 |
| 意大利 | 越南 | 巴西 | 日本 | 南非 |

D Cover LABEL LOCATION



區域 1 Label

| | | | | |
|---|--|--|---|---|
| | | | | |
| INTEL RECYCLE LABEL H0-00000000 H0-00000000 | ENERGY LABEL H0-00000000 H0-00000000 | WARRANTY LABEL H0-00000000 H0-00000000 | J-CALL CENTER LABEL H0-00000000 H0-00000000 | DVI LABEL H0-00000000 H0-00000000 |
| 意大利 | 越南 | 巴西 | 日本 | 南非 |

區域 2 Label

| | | |
|--|--|---|
| | | |
| ENERGY LABEL H0-00000000 H0-00000000 | WARRANTY LABEL H0-00000000 H0-00000000 | J-CALL CENTER LABEL H0-00000000 H0-00000000 |