

This item is specifically addressed on page 4 of the technical report as follows;

“The controls that adjust the power level on this device are not accessible to the user. The professional installer of the device will adjust the power level at the time of installation”