

Human interface drive

USER'S Manual

MaGer PKI

N-Line System Co., Ltd.

#519, Yeungjin B.I.C, Pukgu , Daegu, Korea

Contents

- 1. What's MaGer Setup?**
- 2. Check point before you make an installation**
- 3. Installation**
- 4. Usage of MaGer Utility**
- 5. FCC Compliance Statements**

1. What's MaGer Setup?

This MaGer Setup program can't work without USB Token(MaGer Key) which looks like key typed H/W. And it can use to MaGer PKI and Auth product as additional features like showing key infomation, changing PIN password, MaGer Plus feature including Screen Lock and Automatic Web Browsing.

2. Check point before you make an installation

1. You can download and install MaGerSetup.exe program from the web site (<http://www.n-line.co.kr>).
2. Plugin in USB Token to the USB Connector at the back of PC or USB extension cable.

Caution: You must follow above sequence, if you don't, there might be an error when system detect its driver.

3. Installation

Install program(MaGerSetup.exe) at the web site contains below 3 stuff.

- o DLL library
- o MaGer Utility
- o Korean & English version of README

A. Install program

If you downloaded a self-extracting setup file(MaGerSetup.exe), just run the executable. Before you execute it, close all of IE(Internet Explorer).

B. Change PIN

You can use MaGer Utility to know the key information and to change PIN. The PIN is kind of password to access token. The initial PIN is set as "12345678" which is constrained as 13 letters.

C. System Requirement

- o Windows 98/Me/NT4/2000/XP or higher.
- o IE 5 or higher for browser feature (optional).

4. Usage of MaGer Utility

After you installed MaGer Setup program, You can run MaGer Utilitiy with double-clicking MaGer Utility tray icon at the right bottom. There are 3 tab in it.

Caution: You must plugin USB Token if you want to set it up.

A.General Info Tab

You can look in general information about USB Token as following.

Token Type, Token Name, Serial Number,
Driver Version, Firmware Version, Used by Header,
Free Memory, Used Memory, Total Memory

B.Change PIN Tab

You can change PIN password stored in USB Token and default value is "12345678".

C. MaGer Plus Tab

There are splended 2 more features in MaGer Plus.

1) Screen Lock

There are 3 way of lock the system when user plug out USB Token.

- Immediate Lock
- Lock after [] minutes
- Schedule Lock

2) Automatic Web Browsing

It can automatically connect to the site that user specifies when you plug in USB Token.

5. FCC Compliance Statements

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Warning : Your are cautioned that any change or modifications to the equipment not expressly approved by the party responsible for compliance could void your authority to operate such equipment.