

## Headset – Hands Free User's Guide

### .Feature

- . include Headset Profile
- .include Hands Free Profile
- . 3 key operation (Volume up ,Volume down,on/off /answer call /end call)
- . Microphone Mute function
- .Voice dialing function

### Led Indicator :

- Stanby mode : Green led flash every 3 second
- Pairing mode : Green Led on ,Red Led flash every 0.5 second
- Link mode :Green Led flash every 1 second
- Voice talking mode : Green Led toggle every 0.5 second
- Battery low: Red Led flash every 3 second
- Charging mode : Red led on
- Off mode : Red Led and Green Led off.

### .Turn on:

- in off mode Press and hold “on key” 1 second
- Speaker beep 2 tones(short tone+short tone) and Led indicate as stanby mode

### .Turn off:

- in on mode Press and hold “on key” 1.5 second
- Speaker beep 2 tones :( long tone +short tone)

### .Enter pair mode (pair as Headset mode):

- step 1 : enter off mode
- step 2: Press and hold “on key” 3 seconds
  - Speaker beep 2 times:
    - First time: beep same as turn on beep tones. (after press and t hold key 1 second)
    - Second time : beep 4 short tones (after press and hold key 3 second)
    - Delay 3 second Led indicate as pairing mode
  - Search device by phone with bluetooth feature.
  - Enter Pin Code : 1234

### .Enter pair mode (pair as Hands free mode):

- step 1: enter Headset pair mode
- step 2: press “on key” Speaker beep 2 short low tones
  - delay 3 seconds led indicate as pairing mode

Exit pair mode:

In Hands free mode press “on key” delay 3 seconds Led indicate as Stanby mode

Voice Dial : in stanby mode press “on key”

Microphone Mute: in voice talking mode press “volume up and down key”

Speaker will beep a short low tone every 3 seconds

Press “volume up and down key” again exit mute mode.

Volume up : press “volume up key” if reach maximum volume speaker beep 2 short tones

Volume down : press “volume down key” if reach minimum volume speaker beep 2 short tones

Battery Charge:

Battery in Charging mode : Red Led always on


Battery charged full mode : Red led off.

Battery Low:

If battery low in stanby mode led indicate as battery low

In voice talking mode speaker beep short high tone every 30 second

Operation mode flow:



## **Federal Communications Commission (FCC) Statement**

### **Note 1**

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Note 2**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

### **FCC RF Radiation Exposure Statement:**

This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.