

Product Overview


This product is a new intelligent lighting Bluetooth 4.1 desk speaker, with Speaker and Desktop functions, smart APP control, Highlighting energy saving LED source, built-in unique anti-glare filter, makes the light more soft, protect your eyes. In order to operate it normally, please read our user manual carefully.

Packaging contents


In the package box, you can find:

1. A set of bluetooth speaker
2. A bar of audio cable
3. A set of power adapter
4. A manual book

I. Schematic diagram of the product




- 1. Function keys
- 2. Microphone
- 3. Indicator light
- 4. Left and right loudspeaker
- 5. Bass vibration assistor
- 6. Illuminating lamp




- 7. USB socket
- 8. Power switch
- 9. DC charging socket
- 10. AUX socket
- 11. Power Indicator

II. Product (adjustable angle lighting) instruction



(1)



(2)



(3)

Movable range of the lamp arm and lamp shade: (see schematic diagram)

1. When adjusting the angle of the lamp arm, please press the base.
2. The adjustable range of the lamp arm is 140° (excessive adjustment of the product's movable joint will lead to the damage to the function of joint).
3. Do not put hands outside the lamp base during adjustment of the lamp shade, so as to avoid clamping your hands.

Normal range of lighting: (see schematic diagram 2)

1. Usable range of the front of the lamp is 85° , while the back is 75° .
2. When adjusting the angle of the lamp arm, please press the base.


The lamp shade can be rotated to the desired angle of illumination. (See schematic diagram)

Adjustment range: about 90° on left and right (excessive adjustment of the product's movable joint will lead to the damage to the function of joint).

III. Operation Instruction




Power on before use this product, after power on red indicator LED bright

Power button: power main switch, press to turn on, re-press to turn off. (as sketch map).






Remark: this product need to plug random power adapter before use.

1. Definition of touch key-press

- “▶||/◀” KEY: Music mode, pressed shortly, music will be paused or played.
Hold on this button, between AUX mode and Bluetooth mode switch.
- “▶▶/+/+” KEY: Short press to PLAY the next song, while long press to increase the volume.
- “◀◀/-/” KEY: Short press to PLAY the previous song, while long press to decrease the volume.
- “” KEY: Short press is the switch of illuminating lamps.
- “” KEY: Short press to increase the brightness of illuminating lamps.
- “” KEY: Short press to decrease the brightness of illuminating lamps.

2. Lighting mode operation instruction

Press power switch, illuminating lamp is turn on, short press “” button to control lighting turn on and turn off, short press “” or “” to adjust the brightness of lamplight.

3. Bluetooth mode operation instruction

Pair Bluetooth speaker

- ① Press the power switch to turn on, it enter the Bluetooth pairing mode, blue indicator light is flashing.
- ② Enable the function of cell phone searching for equipment. On the function of cell phone searching for equipment, please refer to the instruction manual of the cell phone. When the cell phone completes searching, the cell phone displays all devices found.
- ③ Select ID Z88 number from the list of the devices found, make confirmation depending on your cell phone.
- ④ When the connection is success, the blue indicator light flashes.
- ⑤ Now you can listen music and pick up incoming call with lamp Bluetooth speaker.

Communication by bluetooth speaker


- ① Answer calls: when the phone call is incoming, press “▶||/◀” KEY to answer calls. Repeat press “▶||/◀” KEY to hang up calls. If the opposite side first hangs up the call, there is no need of such operation.
- ② Reject calls: when the phone call is incoming, if you do not want to answer the call, please long press “▶||/◀” KEY for two seconds to reject the call.
- ③ Re-dial telephone: double click “▶||/◀” button, it will be automatically redial the last called phone number.

Play music by bluetooth speaker

- ① To listen to music, please connect the speaker to a compatible music player that can support A2DP bluetooth mode. Available music functions depend on your music player.
- ② When listening to music, if incoming the call or making the call, the music is paused until the call is hanged up.
- ③ For music play / pause, please short press “▶||/◀” KEY to pause or recover PLAY.
- ④ To select “NEXT” “NEXT” or “PREV” to play in the playback, please short press “▶▶/+/+” or “◀◀/-/” KEY.

4. Operating instruction of AUX mode

1. To insert the plug of audio cable into the corresponding interface of the machine, the machine will automatically enter the AUX mode, and then you can use it to listen to MP3, MP4, mobile phone, ipad, computer and other songs. (See schematic diagram)
2. You also can hold on "▶||/◀" switch to AUX mode, hold on "▶|/V+" or "◀|/V-" to adjust volume






5.App operation:

Android apply download: enter into **Google Play Store** to search "JBSmartPro", then download and install this application program. (supports Android 2.3.3 and aboved edition)

iPhone apply download: enter into App store to search "JBSmartPro", then download and install this application program. (supports ios 7.0 and aboved edition)

APP connection

Android device: Turn on the APP, click on the  icon and search for Z88 to connect, you can use mobile phone to control the light ON/OFF, the brightness of the light, set the alarm clock, timer option to turn ON/OFF music or light after connection, (The device will automatically set up the connection between the APP and mobile phone when run the APP)

IOS device: Before connecting the APP, make sure the bluetooth device is connected, then, turn on the APP, click on  icon search for Z88 to connect. you can use mobile phone to control the lights ON/OFF also the brightness of the light, set the alarm clock, timer option to turn ON/OFF music or light after connection (For IOS devices, need to manually to connect the device into the APP by click on  icon)

Remark: Some functions of the download APP does not support the device for the time being.

IV. Problems of bluetooth speaker

If the cell phone is unable to connect to the bluetooth device, please implement the following operations:

1. Make sure the machine is turned on and the cell phone has created pairing. And make sure that the bluetooth function of the cell phone is start up.
2. Check whether the distance between the machine and the cell phone is more than 10 meters, and whether both of them have a wall or electronic device interference and obstacles.
3. Re-open the machine, and then operate for cell phone search and pairing.
4. Please switch to bluetooth mode and then do pairing.

In the process of communication, the sound will be off and on. Please implement the following operations:

1. Make sure that the machine and cell phone can be used within the effective and normal communication range (within 10 meters)

V. Maintenance of bluetooth speaker

1. Please keep the device dry. Rainwater, dampness and various kinds of liquids or moisture may contain minerals and corrode electronic circuits. If the device gets wet, please use it after the device being dry completely.
2. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the machine.
3. Do not use or store the device in dusty and dirty places. It will damage its adjustable angle lighting and detachable parts and electronic components.
4. Do not store the device in superheated areas, because high temperature will shorten the life of electronic devices, damage batteries, and warp or melt certain plastic parts.
5. Do not store the device in supercooled areas, otherwise when the temperature of the device is raised to its normal temperature, the moisture can be formed inside to damage circuit boards.
6. Do not attempt to disassemble or alter your device, because rough handling can damage the internal circuit boards and fine structure.
7. If the device is not used for a long time, please first charge the device before use.



Caution



Don't adjust the lamp arm overrange, in case of the damage of the Lamp arm joint

Don't disassemble the product by yourself

Don't put in humidity environment or expose to the rain.

Warranty card

Product model: _____ Purchased date: _____
User name: _____ Contact phone number: _____
Contact address: _____ Postal code: _____

According to country's new 3 guarantees of regulations, part of goods carries out 3 guarantees of time stipulated as follows:

1. The product within 7 days from the date of sold, performance failures occur, consumers can choose to return, exchange or repair. Returned goods, the seller should refund full payment according to the goods invoice.
2. The product within 15 days from the date of sold, performance failures occur, consumers can choose a replacement or repair. For replacement, the seller should free change the same model with the specifications of the products for consumers.
- (3) in 3 guarantees of period of validity, repaired twice, still can't use, after provide repair records and proof by repairer, the seller should be free of changing the same model with the specifications of the products for consumers.
4. In 3 guarantees of period of validity, as producers did not supply spare parts, from the date of repairing of more than 90 days are not repaired, repairer should indicated in the repair of status, the seller should be free of changing the same model with the specifications of products according to receipt for consumers.
5. Calculating Depreciation from the date of invoice until the end of the return date, which shall be deducted repaired and to be repaired time.
6. Maintain the credibility of producers and sellers, not be allowed with product technology requirement is incongruent spare parts. Carefully make record the fault and the status of the product after the repair, to assure the goods can be normal use after repair more than 30 days.
7. For consumers usage, maintenance, improper safekeeping damaged, non undertake 3 guarantees repairer for damage goods, without 3 guarantees proof and effective invoice, 3 guarantees of poof model not tally with repaired model or alter the model.

The irresistible force of damaging nonperformance 3 guarantees, but implement charging for repairing

Website: www.dongzhili.com

After sales customer service telephone: 400-0081979

Shenzhen Dongzhili Electronics Co., Ltd

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.