Documan

Documan is a portable security storage device installed with word processing software and other programs in 256MB and 512MB USB Drives which can be plugged into a USB port.

Product Standards

Model	Documan
Data Capacity	256MB/512MB
Interface	Log-on
Security	USB Spec 1.1/USB Spec 2.0
Transfer Speed	12Mbps
Power Voltage	USB bus-powered(4.5V 5.5V)
Operating Temperature/ Storing Humidity	0°C 45°C/5% 95%

Any standards and exteriors of Documan may be changed for quality improvements without any notice.

Features

User's Guide, Installation CD, USB Connection Cable, Portable Necklace

Operating System

All the program of Documan may be used in Windows98/98SE/ME/2000/XP.
When Documan is used as a removable storage device, it may be used in Windows98/98SE/ME/2000/XP.

Windows Me/2000/XP

To Use Documan
 Plug Documan into a USB port on your system.
  System will automatically detect Documan and install the driver. (on very first use)
  Status light on Documan will blink and turn off when operated properly.
  Documan will be properly detected as a removable disk, if you click the "passmanx.exe' file and input the password. (the initial password is '00000000').
  To use the program, double-click the Menu.exe file from Documan.
  Data can be read or written as same as in hard disk.

To Remove Documan
  Close all Documan programs or files.

On Windows taskbar, click the Safely Remove Hardware icon.
In   Safely   Remove   Hardware,   double-click   USB   Mass   Storage   Device.

Unplug Documan from a USB port.

*When red light on Documan blinks, do not remove Documan. It may damage data or FAT table.

Windows 98/98SE

To Use Documan

To use Documan in Windows 98/98SE, the USB Driver from the Installation CD has to be installed.

Plug Documan into a USB port on your system.

The New Hardware installation wizard will open.

Install Documan as directed from the dialog box.

Windows 98 Installation Driver is included in the 98Driver folder from the Installation CD.

To Remove Documan

Close all Documan programs or files.

When the light on Documan is NOT red, unplug from a USB port.

Before Installing Program

Documan requires the following system configuration:

Operating System	Windows Me/2000/XP	USB Driver Not Needed
	Windows 98/98SE	USB Driver Needed
CPU	Pentium or higher	
RAM	64MB or higher (recommended)	

*System must meet minimum requirements in order to run Documan.   Speed may differ depends on users' system and operating system environments.

*In case of reinstallation, you will need original Installation CD and serial number. Please store original Installation CD and serial number in a safe place.

Installing Programs on Documan

Installing in Windows

When program on Documan was removed, you may reinstall the program using the following methods.

If your computer is turned off, turn on your computer.

Plug Documan into a USB port on your system.

Insert the Installation CD into the CD-ROM Drive with label facing up.

Installation program will be prompted automatically.

If installation does not start, open Windows Explorer, and then double-click the Install.exe file from the CD-ROM Drive.

The License Agreement dialog box will open. Click the Agree option, and then click Next.

Enter User Name, Organization and Serial Number on the User Information dialog box. Serial Number is included in the purchased package.

In License Agreement, choose installation type, and then click Next.

In User Information, click Install to install program on Documan.

FCC Information

This device complies with Part 15 of the FCC Results. Operation is subject to the following two conditions:

(1) This Device may not cause harmful interface, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for CLASS B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

    1.1. Reorient or relocate the receiving antenna.

    1.2. Increase the separation between the equipment and receiver.

    1.3. Connect the equipment into an outlet on a circuit different from that to which receiver is connected.

    1.4. Consult the dealer or experienced radio/TV technician for help.

WARNING

Changes or modifications not expressly approved by the manufacturer could void the user's authority operate the equipment.