



While some believe gaming has descended into the shadows of despair, secretly desiring more, hope is not lost. The calling has been answered. Messiah is here to deliver an experience so powerful that it will course through your veins with every beat of your heart. Limitless, spreading infectiously, multiplying until it consumes you to the depth of your very soul.

The reign of Messiah has begun!

FEED YOUR ADDICTION™




**GENERATION
NEX**
BRINGING GAMING BACK TO LIFE™



MESSIAH'S GENERATION NEX IS A TRIBUTE TO ALL THAT IS CHERISHED ABOUT GAMING, A TIME IN GAMING HISTORY LONG GONE, BUT NOT FORGOTTEN. MESSIAH HAS BROUGHT YOU BACK IN TIME TO 1985, A TIME IN GAMING HISTORY WHERE GRAPHICS AND SOUND DID NOT MATTER.... A TIME WHEN GAME PLAY WAS MOST IMPORTANT AND FUN WAS THE FOCUS.

THE GENERATION NEX CONSOLE IS A BLEND OF PAST, PRESENT, AND FUTURE....TAKING AN OLD BUT INCREDIBLY FUN PRODUCT AND UPDATING IT WITH TODAYS TECHNOLOGY. GET READY, BECAUSE MESSIAH IS....

BRINGING GAMING BACK TO LIFE™



PRECAUTIONS

- 1) This is a precision product and should be handled with care.
- 2) It should not be stored in areas of extreme heat or extreme cold.
- 3) Do not take the Generation NEX console or accessories apart.
Doing so voids your warranties.
- 4) Avoid touching the connectors, do not get them wet or dirty.
Doing so may damage the controller or your Generation NEX console.
- 5) Do not clean with benzene, paint thinner, acetone, alcohol, or other such solvents. To clean the external parts of your system or controllers, use water only on a soft, slightly damp cloth.
- 6) Only use the original AC power plug provided with your Generation NEX.
- 7) Turn off the power switch before changing a game cartridge.
- 8) Once you have finished playing for the day, power off the system and remove the game cartridge from the console.
- 9) Avoid touching game cartridge contacts with your fingers.
- 10) Always keep games stored in a clean game jacket when not in use.

1

- 13) Do not pull or force the Generation NEX cables or game cartridges. When disconnecting cables, pull from the plugs and not from the wires.
- 14) Store the Generation NEX in a clean and dry place.
- 15) Do not abuse the Generation NEX or accessories.
- 16) Do not insert dirty game cartridges into the Generation NEX.
Doing so can damage the connection & void your warranty.

WARNING

FAILURE TO PROPERLY SET UP, USE, AND CARE FOR THE GENERATION NEX CONSOLE CAN INCREASE THE RISK OF ELECTRICAL SHOCK OR FIRE. TO REDUCE THE RISK OF SERIOUS INJURY OR DEATH, OR DAMAGE TO THE GENERATION NEX CONSOLE, READ THIS USER MANUAL CAREFULLY AND FOLLOW ALL INSTRUCTIONS.

2



WARNING



Dangerous voltage is present inside the Generation NEX console whenever it is connected to power, whether it is turned on or off. Contact with dangerous voltage can cause serious injury or death from electric shock. It can also lead to fire or damage to the Generation NEX.

DO NOT remove the protective warning label covering the charging ports unless you have a wireless product where the instruction manual instructs you to do so.

DO NOT plug any devices or cables into the charging ports you are not instructed to do so by a product instruction manual. Plugging a device or cable not intended for the charging ports can cause serious injury or damage to the device or cable.

3

As with other electrical devices, failure to take the following precautions can result in serious injury or death from electric shock or fire, or damage the Generation NEX console.

Avoid damaging the power cord.

DO NOT overload an extension cord, wall outlet, or other type of receptacle.

Unplug the Generation NEX during lightning storms or when unused for long periods of time.

Prevent the Generation NEX from overheating.







This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.





This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the Instruction Manual.

4









11



12