


EUT SETUP PHOTOS

CE-Front View (NLS-NQuire1500)




CE-Side View (NLS-NQuire1500)



CE-Front View (NLS-NQuire500)




CE-Side View (NLS-NQuire500)



CE-Front View (NLS-NQuire700)




CE-Side View (NLS-NQuire700)



CE-Front View (NLS-NQuire1000)



CE-Side View (NLS-NQuire1000)



RE_NLS-NQuire1500 (9kHz~30MHz)



RE_NLS-NQuire500 (9kHz~30MHz)



RE_NLS-NQuire700 (9kHz~30MHz)




RE_NLS-NQuire1000 (9kHz~30MHz)




RE-Front View_NLS-NQuire1500 (30MHz~1GHz)




RE-Back View_NLS-NQuire1500 (30MHz~1GHz)



RE-Front View_NLS-NQuire500 (30MHz~1GHz)



RE-Back View_NLS-NQuire500 (30MHz~1GHz)



RE-Front View_NLS-NQuire700 (30MHz~1GHz)



RE-Back View_NLS-NQuire700 (30MHz~1GHz)



RE-Front View_NLS-NQuire1000 (30MHz~1GHz)



RE-Back View_NLS-NQuire1000 (30MHz~1GHz)

