


BATTERY PACK CARE/CAUTIONS:


- If you do not plan to use the car for several days, remove the batteries from the transmitter and charger.
- Do not mix old and new batteries. Do not mix alkaline, standard(carbon zinc), or rechargeable(nickel-cadmium) or Ni-MH batteries.
- Dispose of old batteries promptly and properly ; do not bury or burn them.
- Insert batteries with the correct polarity.
- Keep the package and owner's manual since it contains important information.

- 5 Place the antenna into hole position as the picture indicated. Turn clockwise to secure the antenna into controller. Stop to screw when turn the antenna in MAX. position.




How Mini car operation


- 1 Open the mini window cover and place the mini car on the charging stand as the secure position.
- 2 The charging LED will light up when the mini car is properly secured. Wait for around at 45 seconds. After charging done, the LED will off automatically. When fully charging, the mini car can operate in around 5 - 10 minutes (Depends on whether old or new battery to be installed in remote controller)



- 3 Four buttons with having fully controlling the Mini car in different direction; Forward and Backward with turn left and right side. The operating LED will light up when mini car is in use.
- 4 Place the mini car for battery recharging when the operating LED becomes dimmer.
- 5 To archive the mini car in best performance, make sure the Antenna is fully extended.




- 6 When found the mini car can't run in linear operation, user can make correction by turning the magnifier tuner at the mini car bottom side.




CARE:

- The following suggestions will help you care for your vehicle so you can enjoy it for years:
- Never drive the vehicle on a wet floor, on sand, or in mud, rain, or snow. These can damage it.
- Do not expose the vehicle to extreme temperatures.
- To protect the vehicle's wheel mechanisms from lint and hair, do not drive it on carpet.
- Recommend to recharge the RC unit once in every two months to keep the RC batteries last longer.


- 1 Turn the clear Dome cover in counterclockwise to open.
- 2 Slide the Battery cover in side direction



- 3 To release the Mini car by screw driver as picture indicated.



- 4 Place two "AA" size Alkaline batteries into remote controller. (When battery replaced, don't mix up with old and new.)



INSTRUCTION

WARNING:
CHOKING HAZARD
NOT FOR CHILDREN
UNDER 8 YEARS

FCC STATEMENT:

“Modifications not authorized by the manufacturer may void users authority to operate this device”

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: SPF99999999Q

MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.