




Left Hand Touch Cheek Position




Left Hand Tilt 15 Degree Position




Right Hand Touch Cheek Position




Right Hand Tilt 15 Degree Position




Back Side, the distance from handset to the bottom of the Phantom is 15mm




Front Side, the distance from handset to the bottom of the Phantom is 15mm



Back Side, the distance from handset to the bottom of the Phantom is 10mm



Front Side, the distance from handset to the bottom of the Phantom is 10mm



Left Side, the distance from handset to the bottom of the Phantom is 10mm



Right Side, the distance from handset to the bottom of the Phantom is 10mm



Top Side, the distance from handset to the bottom of the Phantom is 10mm



Bottom Side, the distance from handset to the bottom of the Phantom is 10mm