



Picture 14: Left Hand Touch Cheek Position



Picture 15: Left Hand Tilt 15 Degree Position



Picture 16: Right Hand Touch Cheek Position




Picture 17: Right Hand Tilt 15 Degree Position



Picture 18: Back Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 19: Front Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 20: Left Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 21: Right Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 22: Top Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 23: Bottom Side, the distance from handset to the bottom of the Phantom is 10mm