



Left Hand Touch Cheek Position



Left Hand Tilt 15 Degree Position




Right Hand Touch Cheek Position



Right Hand Tilt 15 Degree Position



Back Side, the distance from handset to the bottom of the Phantom is 10mm



Front Side, the distance from handset to the bottom of the Phantom is 10mm



Left Side, the distance from handset to the bottom of the Phantom is 10mm



Right Side, the distance from handset to the bottom of the Phantom is 10mm



Top Side, the distance from handset to the bottom of the Phantom is 10mm



Bottom Side, the distance from handset to the bottom of the Phantom is 10mm



Back Side with Earphone, the distance from handset to the bottom of the Phantom is 10mm



Front Side with Earphone, the distance from handset to the bottom of the Phantom is 10mm