

ZTE CORPORATION

Software change clarification


For disable some frequency bands:

Modem software protocol stack will block all unwanted bands and only leave required bands.

For disable SIM2:

From hardware perspective, UIM2 won't power on; from modem software UIM task perspective, UIM2 won't be activated; from Android software perspective, UIM2 won't be reported so UI won't show UIM2 icon. The UIM2 turns to be a TF displayed on the UI.

APPROVED BY: Min Zhang



Company: ZTE Corporation