

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE PLAYING AND RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

#### RADIO CONTROL FREQUENCY

For interference-free results, do not operate this vehicle with other radio-controlled toys not included in this set within transmission range.

#### TRANSMITTER AND RECEIVER

Since radio waves control this vehicle and in order to avoid interruption, do not operate this vehicle near electrical or telephone lines, CB interference, CD players, mobile phones, elevators, steel girders, other electronic devices and near highways.

#### INSTALLING THE BATTERIES

- Remember to set the "ON-OFF" switch at bottom of the vehicle to "OFF" position before inserting the batteries.
- Unscrew battery compartment cover to insert batteries in the vehicle as shown in diagram. Make sure all batteries are at the correct polarity.
- Close the cover and tighten the screw.
- To insert battery in the controller, open battery compartment cover to insert battery as shown in diagram.
- Close the cover.
- Do not leave batteries in the vehicle and transmitter when the toy is not in use.
- Do not mix old and new batteries together.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Non-rechargeable batteries are not to be recharged.
- Remove used batteries from the toy.
- To prevent supply terminal are short-circuit, keep battery compartment free of all materials except batteries.
- For best performance, alkaline batteries are recommended.
- Do not dispose of batteries in fire. Batteries may explode or leak.
- Batteries contain mercury, don't put in trash. Recycle or dispose as hazardous waste.

#### OPERATING THE VEHICLE

- For your safety, never play with this toy on the street.
- Turn the "ON-OFF" switch at the bottom of the vehicle to "ON" position, then the vehicle will be idle.
- Pull the trigger downward on the transmitter, the vehicle will respond in going forward.
- Release the trigger, the vehicle will stop.
- Push the trigger upward on the transmitter, the vehicle will turn in reverse.

#### OPERATION TIPS

- Operate only on smooth (but not slippery), dry and clean surface.
- Do not play with this toy on grass, sand or carpet.
- Do not drive the toy through water.
- Always point the controller antenna upward for better transmission.
- Do not make any physical contact with the controller antenna while operating.
- Keep the toy in a dry and cool place after playing. Do not leave it directly under sunlight.

CONFORMS TO TOY SAFETY STANDARDS ASTM F963-07

POR FAVOR, LEA TODAS LAS INSTRUCCIONES ANTES DE JUGAR Y CONSERVE ESTAS INSTRUCCIONES PARA REFERENCIA EN EL FUTURO.

#### RADIOFRECUENCIA

Para evitar interferencias, no utilice este juguete con otros juguetes con radiocontroles que no se incluyen con este juego al alcance de la transmisión.

#### TRANSMISOR Y RECEPTOR

No utilice este juguete cerca de postes eléctricos o telefónicos, interferencia BC, lecturas de CD, teléfonos celulares, elevadores, vigas de acero, otros dispositivos electrónicos o autopistas ya que las ondas de radio controlan este vehículo.

#### INSTALACIÓN DE LAS PILAS

- Acuérdese en apagar el interruptor antes de insertar las pilas.
- Abra la cubierta del compartimiento de pilas para insertar las pilas como se muestra en el diagrama. Asegúrese que todas las pilas están con la polaridad correcta.
- Cierre la cubierta y apriete el tornillo.
- Para insertar la pila en el controlador, abra la cubierta del compartimiento de pilas y la inserte como se muestra en el diagrama.
- Cierre la tapa.
- No deje las pilas en el vehículo y transmisor cuando no use el juguete.
- No mezcle pilas viejas y nuevas.
- No mezcle pilas alcalinas, estándar (carbono-zinc) o pilas recargables (níquel-cadmio).
- Las pilas no recargables no deben recargarse.
- Retire las pilas usadas.
- Para evitar de ponerse las terminales en corto, mantenga el compartimiento de pilas libre de todos materiales excepto las pilas.
- Para mejor rendimiento, se recomienda usar pilas alcalinas.
- No deseche las pilas en el fuego. Las pilas pueden explotar o tener fugas.
- Las pilas contienen mercurio. No las coloque en la basura. Reciclela o manéjela como desperdicio peligroso.

#### PARA USAR EL VEHÍCULO

- Para su seguridad, nunca juega con este juguete en la calle.
- Coloque el interruptor de ENCENDIDO/APAGADO (ON/OFF) en "ON" y después el vehículo marcha al ralenti.
- Oprima el gatillo abajo en el transmisor y el vehículo va adelante.
- Suelte el gatillo y el vehículo para.
- Oprima el gatillo arriba en el transmisor y el vehículo vuela en reverso.

#### CONSEJOS DE OPERACIÓN

- Utilice sólo en superficies suaves (pero no resbalosas), secas y limpias.
- No juega con este juguete sobre el pasto, arena o alfombras.
- No lo use en agua.
- Siempre apuntar arriba la antena del controlador para mejor transmisión.
- Evite el contacto con la antena del controlador mientras opere el juguete.
- Manténgalo en un lugar fresco y seco después de jugar. No lo dejes en sol directo.

COMPLE CON LAS NORMAS DE SEGURIDAD DE JUGUETES ASTM F963-07

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

#### BATTERY INSTRUCTION DIAGRAMS

DIAGRAMAS DE INSTRUCCIONES PARA LAS PILAS



USES 4 X 1.5V "AA" SIZE BATTERIES (NOT INCLUDED)  
UTILIZA 4 PILAS "AA" DE 1.5V (NO INCLUIDAS)



USES 1 X 9V SIZE BATTERY. (NOT INCLUDED)  
UTILIZA 1 PILA DE 9V. (NO INCLUIDA)