

User guide

- 1.1. Installs the battery to the Wii Remote or the WAND, and turns on the Wii , on-line arrives Wii Remote or the WAND to the main engine which opens.



- 1.2. According to the Figure 1 presentation plug, Insert the Wii Remote or the WAND into the Keyboard card slot inside, Such as the figure 3; The Dongle inserts the Wii host USB position, Such as the figure 2. Press reverse side the key of SYNC in Keyboard, Can let Control and Dongle lead-in signal linked, The above blue color in the key of SYNC LED instructions to be given out light by flicker to change into at the same time often bright, Such as the figure 4, The this time Control and Dongle is already normal to correspond by letter the work, That will can begin to play the game.



Figure 1





Figure 2




Figure 3



Figure 4

- 1.1. Enter 《Animal Crossing》 of the Wii game, Passing the Keyboard to match with the Wii Remote (or the WAND) can operate the game, Such as the figure 5.




Figure 5

FCC NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.