

## Operation description

Connect HDMI input signal and DC power adapter to the FS-S2301F. Powered on with On/Off switch, then Power is supplied to Main Board. MCU(SH7085) controls all I/O port including GH357A inverter, and Scaler(GF9450) outputs generated signal to the LCD Panel through the LVDS chip. Then LCD panel displays the image.

Touch control power is supplied from SYSTEM through the USB cable. The touch driver should be installed to be operated the touch screen.

