

***** Caution *****

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes of modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



WIRELESS OPTICAL MOUSE

Features:

- 27 MHz Frequency insures worldwide compatibility
- Perfect for travel use – eliminates cumbersome wires
- Works up to 4 feet from your notebook or desktop computer
- The mouse automatically goes into a rest mode after being idle for eight minutes to conserve battery power
- 800dpi

- 2 AA batteries

Package Includes:

- Wireless Optical Mouse
- USB Receiver

System Requirements

- Windows® 98, 2000, Me or XP
- USB port
- PC 486 or higher


Rf Device Use Is Prohibited On Aircraft

Wireless Optical Mouse Operation Instructions:

1. Insert two 2 AA batteries in compartment on bottom of mouse. Make sure positive and negative ends on batteries match connectors.
2. Insert USB plug on receiving device into USB port on computer. Red light on receiver will light up when installed correctly.
3. Press button on receiver and red light will blink on and off for a few seconds. Immediately turn mouse over, hold near receiver, press connect button on the bottom of the mouse, release it while light is blinking on receiver. Devices will search for and find each other.
4. Turn mouse right side up and place on solid tabletop or mouse pad and mouse will work correctly.
5. When mouse is idle for more than 8 minutes, it will go into "rest" mode. Wake the mouse by pressing either the right or left hand button.

For best operation, keep mouse within 4 feet of receiver inserted into USB port on computer. Certain objects such as electronic fans, fluorescent lamps, large metal objects, and radios, can cause interference in connection between mouse and receiver. For best results keep items 12 inches from the receiver.

Computer or Laptop with USB port



USB Receiver

Wireless Mouse

