



Battery 4 (Wireless Battery)







Battery 5 (1x)







USB TYPE A to TYPE C cable








USB TYPE C to 3.5mm audio connector





3.5mm Earphone





Rugged Headset





USB TYPE C Earphone









Trigger Handle







Soft Holster







TC53/TC58 RUGGED BOOT



