


VEHICLE



WARNING:

1. Rechargeable batteries are to be removed from the toy before being charged.
2. Rechargeable batteries are only to be charged under adult supervision.
3. Nonrechargeable batteries are not to be recharged.
4. Different types of batteries or new and used batteries are not to be mixed.
5. Only batteries of the same or equivalent type as recommended are to be used.
6. Batteries are to be inserted with the correct polarity.
7. Exhausted batteries are to be removed from the toy.
8. The toy's terminals are not to be short-circuited.
9. Do not touch wheels or tires when they are in motion.
10. Do not collide with humans or any animals to avoid accident from occurring.

CUSTOMER INFORMATION

- Packaging has to be kept since it contains important information.
- **WARNING:** Not suitable for children under 36 months. Small parts.
- Where applicable, remove all packaging before giving the item to your child.
- Contents may vary in style, colour, shape and decoration from images shown on package or in advertising.
- Please ensure to TURN OFF the product after play.
- Please remove the batteries when not using the product for a long period of time.

BATTERY REPLACEMENT:

- To replace batteries refer to the following directions & illustration:
1. Use a Phillips screwdriver to loosen the screws of the battery compartment door.
 2. Remove the battery compartment door.
 3. Remove old batteries and replace with new "AA" battery / batteries.
 4. Cover the battery compartment door and tighten the screws.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


The device must not be relocated or operating in conjunction with any other antenna or transmitter.



Alkaline batteries are recommended.
Batteries should be installed by adults only.



HOW TO OPERATE (TRANSMITTER)



GRANDEX
GDX02010624S
GUANGDONG, CHINA
2024
Distributed By:
Variety Wholesale, Inc
218 S. Garrett Street
Henderson, NC 27536
MADE IN CHINA

Grandex R/T Development Ltd.
3/F East Ocean City, Guang He Rd,
TST, Hong Kong.
NO: 96247
MADE IN CHINA
8 83788 96247 6