



# Configuration Mode

— = Hold Button  
● = Press Button


## Clear Settings:



## Assign Pump as Master:



## Assign Pump as Slave:




Cycle power to pump after setting master/slave groups to complete programming


# Operational Modes

Mode      Set

## Single Pump Mode or Master Modes:



## Slave Pump Modes:



## Feed Mode:

Hold to enter  
and exit

Blinking  
White

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

EcoTech Marine  
FCC ID: VKB271828  
IC: 7349A-271828  
Model: MP40w



Made in the USA