

The Nozzle Reader reads the vehicle information from the RFID FuelOpass and transmits it to the WGT over wireless channel and from there the data is sent to the station automation system for allowing/rejecting fueling.



Nozzle Reader (NR) installed on ZVA Nozzle