

## EUT EXTERNAL PHOTOGRAPHS

EUT –View



EUT –Front View




EUT –Front View






Antenna location



**Antenna Connector: Reverse SMA Male**



## Equipment Antenna Connector: Reverse SMA Female



## EUT –Adapter View

