

Bluetooth stereo headset User Guide

Model Number: HL9999

Bluetooth Introduction:

The Bluetooth headset is a portable headset solution based on Bluetooth wireless technology.

Bluetooth wireless technology is a short-range radio communication technology intended to replace the cables connecting electronic devices. The technology uses a globally available frequency range intended to ensure communication compatibility worldwide.

You can connect your headset to your mobile phone or any device with Bluetooth wireless technology that supports the Headset profile or the Handsfree profile. When the headset is connected to your mobile phone, you can handle incoming and outgoing calls, listen to music, and adjust the volume, using the buttons on the headset.

The inbuilt Bluetooth Headset in motorcycle helmet contain Bluetooth Cell Discreteness, Control Buttons and Earphone. The Bluetooth Cell Discreteness contain Inserted Bluetooth, Battery and Shell.




Figure 1

Caution:

Do not let your battery, charger, and headset get wet.

Listening at full volume to music or voice through a headset may damage your hearing.

BlueToothHeadSet Control Buttons:

BUTTON_MFB Multifunction Button

BUTTON_VOL+ Volume Increase

BUTTON_VOL- Volume Decrease

Bluetooth headset supports profiles and functions:

Hands-Free Profile(HFP), HeadSet Profile(HSP), Advanced Audio Distribution Profile(A2DP), Bluetooth Intercom function.

To use your headset, your phone or music device should

support the following Bluetooth profiles:

Profile	Description
HFP(Hands-freeProfile)	Providing a wireless means for both remote control of the Mobile Phone by the Hands-Free device and voice connections between the Mobile Phone and the Hands-Free device.
A2DP (Advanced Audio Distribution Profile)	Stereo music streaming.

Bluetooth Interference Issues:

The quality of Bluetooth transmission may also be affected by the position of your music device. Should you experience choppy or distorted audio, move the position of your music device or phone to a different location until the signal improves.

Getting started:

Before you can use your headset, you should first:

Charge the headset battery.

Pair the headset with a device, for example, a mobile phone.


Charging:

The headset comes with a built-in rechargeable battery. We recommend that you charge the battery before using the headset for the first time.

Connect the charger to the headset and to the mains.

The charging time is about 4 hours. During charging, the indicator shows a steady red light. When the battery is fully charged, the indicator red light will switch off. When you use the headset, if you hear a cadent tone, and the indicator red light flashes rhythmically, battery needs recharging.


To charge, please use the handle on Charging Port Rubber Cover gently pull out the Cover, and circumgyrate about 180 degrees. Expose the Charging Port and Plug the Charger Plug into the BlueTooth headset's Charging Port. At this time near the Control Buttons the indicator light turns red when the battery is charging. As Figure2 and Figure 3 shown.



Charging Port

Charging Port Rubber Cover

Figure 2



Charging Plug

Figure3

To turn the headset on:

Press and hold the **Multifunction Button(BUTTON_MFB)** for approximately 2 seconds until you hear a short low tone followed by a short high tone. The headset indicator light flashes yellow. When turned on, the headset automatically establishes handsfree phone and streaming music connections with the last connected Bluetooth devices (phone and/or music devices).

To turn the headset off:

Press and hold the **Multifunction Button(BUTTON_MFB)** for about 5 seconds until will hear a short high tone followed by a short low tone. The headset indicator lights both switch off.

To pairing the headset with a phone:

Before using the headset,you should pair the headset to your mobile phone.

The phone enter the searching BlueDevice mode and with the headset turned off, press and hold the **Multifunction Button(BUTTON_MFB)** for about 5 seconds until the indicator lights yellow and red on the **Control Button** flashes alternately.

Operate the phone to discover and connect the headset. The headset passkey is 0000. If pairing success the headset indicator blue light flashes slowly and indicator red light is off. Pairing, done only once. Each time you use your headphones, it will be automatically connected to your phone.

Note:Before enter pairing mode,please make sure other BlueDevices are closed.

Using the headset

Listening to music:

Your headset allows you to listen to stereo music from your Bluetooth streaming music source.

Note: When placing or receiving calls, music playing from a Bluetooth music source is automatically paused. When the call is finished, music playing is resumed.

To answer a call using the call handling button Or answer

automatically by headset:

When the headset rings, press the **Multifunction Button(BUTTON_MFB)** to answer the incoming call .Or headset will automatic answer the call after 3 seconds.

Terminate call:

Press the **Multifunction Button(BUTTON_MFB)** to terminate call.

To reject a call:

When the headset rings, press and hold the **Multifunction Button(BUTTON_MFB)** until you hear a long beep.

Note: this function valid only if your phone support Hands-Free Profile.

LastNumberRedial:

If headset in idle time, press and hold the **Multifunction Button(BUTTON_MFB)** until you hear a long beep,then release.

Adjusting Volume:

To increase speaker volume, press the **BUTTON_VOL+**once can increase a volume level , repeatedly, until you reach the desired volume level.

To decrease speaker volume, turn the **BUTTON_VOL-** once can decrease a volume level , repeatedly, until you reach the desired volume level.

You can adjust the headset speaker volume during a call, or the ring volume when you are not engaged in a call.




Figure 4

To transfer the sound to the phone:

During a call using your headset, press and hold the **Multifunction Button(BUTTON_MFB)** for about 2 seconds. If your headset works with HeadSetProfile, you just need turn down your headset.

Transferring sound from phone to headset:

If you make a call using your phone, you can transfer the sound to the headset if the headset is on, press and hold the **Multifunction Button(BUTTON_MFB)** about 2 seconds.

How to use Bluetooth Intercom function

First-Time Use:

First time to use Bluetooth Intercom function, before two headsets want to make intercom call, they should be pair each other. If pair succeed and link message not lost, they can use Intercom function to call just needn't pair again.

How to pair for Intercom:

Headset power on status, press the **BUTTON_VOL+** (or **BUTTON_VOL-**) about 5 seconds until the indicator lights yellow and red on the Control Buttons flashes alternately, and headset(master role) enter Inquire mode. Then headset(slave role) should press and hold the **BUTTON_MFB** about 5 seconds to enter Pair mode. In suitable radio range, they can finish the pair process automatically.

If pair completed, both indicator lights yellow slowly. And headset(master role) will make a intercom call to headset(slave role) automatically. About 3 or 4 times ring rang, headset(slave role) can answer the call automatically. During call, each one can press the **BUTTON_MFB** to terminate the call.

How to make a Intercom Call:

Master Role:

Not active call status, press the **Multifunction Button(BUTTON_MFB)**, headset will enter Intercom mode. Headset will initiate a intercom call to the last paired headset automatically, so it works as master role.

- 1) If headset (master role) connected to others devices(for example mobile phone), so it will disconnect automatically, then it connecting to object headset(slave role). After connected, headset(master role) make a intercom call to headset(slave role) soon. Headset (master role) can press the **Multifunction Button(BUTTON_MFB)** to terminate the call. And if headset (master role) play A2DP music from phone before enter Intercom mode, while end up Intercom call, headset (master role) will reconnect to mobile phone and play music go on (But for some manufacturers Bluetooth phone's issue, headset can't restart music playing, for this issue, you need restart headset playing manually).
- 2) If headset(master role) not connect to any device, it will connect and make a intercom call to

headset(slave role) directly.

Slave Role:

- 1) If headset (slave role) connected to others device(for example mobile phone), so it will disconnect automatically, then it accept the connection request from headset(master role). About 3 or 4 times ring rang, headset(slave role) will answer the incoming call automatically. Or you can press the **Multifunction Button(BUTTON_MFB)** to answer the incoming call manually. Headset (slave role) can press the **Multifunction Button(BUTTON_MFB)** to terminate the call. And if headset (slave role) play A2DP music from mobile phone before Intercom call, while end up Intercom call, headset (slave role) will reconnect to phone and play music go on (But for some manufacturers Bluetooth phone's issue, headset can't restart music playing, for this issue, you need restart headset playing manually).
- 2) If headset(slave role) not connect to any device, it will accept connection request and handle incoming intercom call directly.

Replace battery:

Need to replace battery, please turn off the BlueTooth Headset first , then open the Shell's cover. As Figure 5 shown ,follow the instructions direction to push the Clasp handle, you can open the cover to expose the battery in Shell as Figure 6 shown .

Hold the handle, you can take out battery as Figure 7 shown..

Put a new battery into same position will finish replacing.Then close the cover last.




Figure 6



Figure 7

Replace Inserted BlueTooth:

For special requirements must be replaced Inserted BlueTooth, please follow the instruction have shown to open the Shell's cover, you will see the exposed Inserted BlueTooth, as Figure 6 shown. Use a screwdriver ,follow the instruction of the Figure 8 ,take out the Inserted BlueTooth as Figure 9 shown.

Be careful when you install the Inserted BlueTooth ,the Guideway of the Inserted BlueTooth should insert the Guideway of the Shell,and insert deeply.




Figure 8




Figure 9

**Note : no special need should not take out the Inserted
BlueTooth.**