







NTNV-n77(3450-3550)-PC2-30-25-L-DFT-BPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-25-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-25-L-DFT-QPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-25-L-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-25-H-DFT-BPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-25-H-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-25-H-DFT-QPSK-Edge_1RB_Right-PAS
SS



NTNV-n77(3450-3550)-PC2-30-25-H-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-30-L-DFT-BPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-30-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-30-L-DFT-QPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-30-L-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-30-H-DFT-BPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-30-H-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-30-H-DFT-QPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-30-H-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-40-L-DFT-BPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-40-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-40-L-DFT-QPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-40-L-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-40-H-DFT-BPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-40-H-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-40-H-DFT-QPSK-Edge_1RB_Right-PAS
SS



NTNV-n77(3450-3550)-PC2-30-40-H-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-50-L-DFT-BPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-50-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-50-L-DFT-QPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-50-L-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-50-H-DFT-BPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-50-H-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-50-H-DFT-QPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-50-H-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-60-L-DFT-BPSK-Edge_1RB_Left-PAS
S


NTNV-n77(3450-3550)-PC2-30-60-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-60-L-DFT-QPSK-Edge_1RB_Left-PAS
S



NTNV-n77(3450-3550)-PC2-30-60-L-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-60-H-DFT-BPSK-Edge_1RB_Right-PA
SS



NTNV-n77(3450-3550)-PC2-30-60-H-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-60-H-DFT-QPSK-Edge_1RB_Right-PA
SS



NTNV-n77(3450-3550)-PC2-30-60-H-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-70-L-DFT-BPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-70-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-70-L-DFT-QPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-70-L-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-70-H-DFT-BPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-70-H-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-70-H-DFT-QPSK-Edge_1RB_Right-PAS
SS




NTNV-n77(3450-3550)-PC2-30-70-H-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-80-L-DFT-BPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-80-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-80-L-DFT-QPSK-Edge_1RB_Left-PAS
S




NTNV-n77(3450-3550)-PC2-30-80-L-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Edge_1RB_Right-PA
SS




NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Edge_1RB_Right-PA
SS




NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Outer_Full-PASS


NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Edge_1RB_Left-PAS
S




NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Outer_Full-PASS


NTVN-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Edge_1RB_Left-PAS
S





NTVN-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Outer_Full-PASS


NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Edge_1RB_Right-PAS
SS





NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Outer_Full-PASS


NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-PAS
SS


NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Edge_1RB_Left-PA
SS

NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Edge_1RB_Right-P
ASS




NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Outer_Full-PASS


NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Edge_1RB_Left-PA
SS

NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Edge_1RB_Right-P
ASS


NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Outer_Full-PASS

Conducted Spurious Emission


Test Graphs




NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Left-0.00
9-0.15-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Left-30-1
000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS


NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS


NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS


NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Right-300
0-6000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Right-60
00-20000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-BPSK-Inner_1RB_Right-200
00-40000-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Left-0.15-
30-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Left-300-0-6000-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Left-200-00-40000-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Right-0.0-09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Right-1000-PASS




NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Right-3000-PASS




NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Right-6000-PASS



NTNV-n77(3450-3550)-PC2-30-10-L-DFT-QPSK-Inner_1RB_Right-20000-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Left-0.015-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Left-0.15-PASS





NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Left-3000-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Left-10000-PASS


NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Left-600
0-20000-PASS

NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS


NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-BPSK-Inner_1RB_Right-2000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS


NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Left-20
000-40000-PASS

NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Right-0.0
09-0.15-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Right-30
-1000-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS


NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Right-6
000-20000-PASS

NTNV-n77(3450-3550)-PC2-30-10-M-DFT-QPSK-Inner_1RB_Right-20
000-40000-PASS


NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS

NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS

NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS

NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS