



Photographs of EUT



Antenna with Cover



Antenna






External ports



(located at Bottom of Antenna)



Label drawing:





CNX-BB (Customer Network Exchange)








CNX-BB (Customer Network Exchange)



Customer Network Exchange I/O port



Label



AC Adapter for CNX-BB

