

 <p>© Copyright 2021 Hampton Direct Inc. Calabasas, CA 91302 USA 11-802-876-1500</p>				<b>project name:</b> Door Security Bar Alarm & Receiver <b>product code:</b> 7960 <b>item number:</b> 80260-HS <b>running change:</b>	<b>specs:</b> <b>8.5" X 11"</b>
<b>designer:</b> tlee					
<b>Concept</b>	<b>Review / Approval</b>	<b>Sample / Proof</b>	<b>FINAL for Production</b>	<b>department:</b> marketing / creative	
<b>version:</b> 4		<b>date:</b> 9.28 .21		<b>email:</b> tlee@hamptondirect.com	

# Door Security Bar Alarm & Receiver


## INSTRUCTIONS

**WARNING: THIS IS NOT A TOY. KEEP AWAY FROM CHILDREN. KEEP CLEAR OF PINCH POINTS.**

**REQUIRES (6) AAA BATTERIES. BATTERIES NOT INCLUDED. USE ALKALINE BATTERIES ONLY. DO NOT MIX OLD AND NEW BATTERIES OR BATTERY TYPES.**

PLEASE NOTE: The Door Security Bar Alarm & Receiver is not intended to be the main locking device for your doors or windows. It is intended as added security together with your existing hardware.


### All Purpose Door & Window Security Bar Assembly



**For Assembly Video Go To:**  
[ProductTrend.com/Door-Security-Bar](http://ProductTrend.com/Door-Security-Bar)

### Transmitter & Receiver When door is pushed, both the transmitter and receiver are activated and sounds off.

Take the portable receiver anywhere indoors. The portable receiver receives a signal anywhere inside the house, kitchen, living room, bedroom, and bathroom.



### Sliding Doors & Sliding Windows Installation NOTE: The sliding window track must be at least 27" long.



Remove the key to separate the u-shaped top from the security bar. Reinsert the key back to lock in place.



Adjust the length to fit the sliding door or window track using the push button. Repeat steps above on how to adjust the bar length. Leave some space to easily remove the security bar.

### Constructed of 40 gauge steel to withstand up to 350 pounds of force

Steel construction for instant security on hinged doors and sliding doors/windows.

#### FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:  
**Hampton Direct, Inc.**  
 26025 Mureau Road, Suite 220  
 Calabasas, CA 91302  
 1-855-215-3288

- Trade Name: Door Security Bar Alarm & Receiver
- Model Number: 80260-HS
- FCC ID: YLW-600606-80260

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The test result has been evaluated by

  
 Calabasas, CA 91302 USA  
 ©2021 Hampton Direct, Inc. All Rights Reserved.  
 Product Trend® is a trademarks of HIP Innovations, LLC.


FOR ANY PRODUCT QUESTIONS OR CONCERNS, PLEASE CONTACT US:  
 By email: [customerservice@hamptondirect.com](mailto:customerservice@hamptondirect.com) or Call: 855-215-3288

INST-7960-80260-092821  
 MADE IN CHINA

### Door Installation Fits Most Standard Hinged Doors. Works on all floor types – wood, carpet, tile and linoleum.



Open battery cap on the transmitter and insert (3) three "AAA" batteries (not included).  
 Slide the switch on the transmitter to turn ON and activate the alarm.  
 Place the base against the floor and u-shaped top under the doorknob.  
 Push the padded base toward the door until it is secure.



Adjust the bar length.  
 Push the button and twist bar slowly to the desired length. Then twist the bar back until the button pops out of the selected hole.



Make sure the u-shaped top is tightly against the bottom of the doorknob.  
 Open the battery cap on the receiver and insert (3) three "AAA" batteries (not included). Slide the switch on the receiver to turn ON and activate the alarm.  
 Slide the switch on the transmitter and receiver to turn OFF and deactivate the alarm.  
**NOTE:** The distance and angle of this security bar may vary, depending on the height of the doorknob from the floor.