GlowCaps[™] Setup Guide

PLUG IN

Plug in your Vitality Night Light where you will see it, near your medications. Your Night Light will scan back and forth while connecting to the cellular network.





Pulsing orange means take your pill

FILL UP

If needed, label the bottle with the enclosed sticker.



HOW IT WORKS

Each day your GlowCap and Night Light will pulse orange, then start playing melodies to remind you.



To change your dose time or preferences, you can

- call 1-866-389-8686,
- email support@vitality.net, or
- log on to my.vitality.net.



Vitality can even call or text you so you don't forget.



Every week you'll get an email update

INFORMATION TO USER

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.