



# 使用手冊

# User Manual

**RAINBOW LEAF**

COPYRIGHT@ ZOPTOP CO., LTD.

## Package Contents

7" Tablet PC 1 set

USB Cable 1 set

AC Adaptor 1 set

User manual 1 set

## Product overview <1>



## **Power On/Off**

**Power On:** Slide and hold the power button 3 seconds.>>Tap and slide “unlock icon” to the other side.

**Power Off:** Normal power off- Slide and hold the power button 3 seconds.>>Tap “Power off”.>> OK to confirm the power off.

### **Sleep Mode On/Off (power save mode):**

Device can turn sleep mode on/off with sliding & releasing the power button when user wants to save the battery power.

Disable the sleep mode: User can slide the power button, and then slide the Unlock bar on screen.

## **Volume buttons**

Enlarge or silent down the volume of speaker.

## **HDMI**

Connect with HDMI input of other device.

## **LED indicator**

**Status:**

**LED off :**

1. Device off
2. Device on
3. Fully charged

**Red LED on:**

1. Device on or off
2. Charging

**Green LED on:** Turn device on

## **Touch-Screen Navigation**

The touch-screen allows for visual, easy and touchable navigation to activate all of applications.

### **Activating methods:**


**Tap:** touch and release by finger.


**Touch and hold:** touch an application icon with finger and hold in same place until the application respond.


**Touch and drag:** touch and hold an application icon with finger, and drag to where you want it stay, and then release your finger.


**Slide:** slide and release with finger


## **Function Buttons**


Home : Return to home page<sup><2></sup> of device from applications.


Menu : Activate function menu to set up device or application's functions.


**Back** : Return to previous page or exit application.


**Search** : Launch search function which has search function support.

 **Add** allow to add shortcut of applications and folders to your home page. If **Add** is not available, the reason could be the home page is full. Please remove application or folder to add new one. This removing will not delete application from device.

 **Manage Apps** display current status and uninstall of applications from device.

 **Wallpaper** Change the image of background of home page.

 **Search** Perform quick search which support application search function.

 **Notifications** View the pending list of notificatons. (*example: email, new events, downloads, etc.*).



**Settings** Set up functions of application and device. Meanwhile, view the information of this device.

### **DC jack**

Charge the device. Plug the AC adapter into an electric socket, and connect with the device.

### **Mini USB**

Connect with PC or other device. This port can reach internal and outside storage.

### **Micro SD slot**

Plug in microSD card to save data and applications.

### **Front/Back Camera**

Take picture or perform video function.

### **Microphone**

Collect voice and sound into this device.

### **Earphone jack**

Plug earphone. Receive voice and sound via earphone.

## **Speaker**

Output voice and sound via speaker.

## **Stylus**

Touch screen to activate applications.

## **Strap hold**

To bind the favor strap.

## Applications



AppInstaller: Install and uninstall applications.



Browser: Connect with the internet.



Calculator: Perform the basic math equations.



Calendar: State event, appointments and schedules



Camera: Take picture and video shot.



Clock: View time and alarm setting.



Downloads: Display the history of downloads, and operate the activating and deleting applications.



Email: Perform sending and receiving email function.



FW update: Renew the firmware of device.





Gallery: Display and manage photos and files of this device.



Music: Play and manage audio data.



Search: Perform quick search which support application search function.



Settings: Set up functions of application and device. Meanwhile, view the information of this device.



Video Player: Play and manage video data.



Yozone office: allow to edit, view and manage documents(doc,xls,pdf,ppt).

## **License Agreement & Terms of Use**

Before activating and using this device, you hereby consent and agree to our License Agreement and Terms of Use as outlined in the device User Guide.

2OPTOP, Co., Ltd.; all rights reserved. 2OPTOP and the 2OPTOP logo are trademarks of 2OPTOP Co., Ltd.; all rights reserved. microSD™ is a trademark of SD Card Association; all rights reserved. Yozosoft Ltd.; all rights reserved.

<1> The physical color and home page could be different by device using. The outside printing of box is only imitating picture.

<2> Home page: it means the home page of this device, not website's home page.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
**IMPORTANT NOTE:** To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

The Federal Communication Commission Radio Frequency Interference Statement includes the following paragraph:

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- The user should not modify or change this equipment without written approval  
 Form ZOFTOP CO.,LTD Modification could void authority to use this equipment.

To comply with the FCC RF exposure compliance requirements, the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. No change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.



Model: 2GOSML721

FCC ID. :Z4F2GOSML721

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Product Specifications (規格表)**

LCD	7" 600 x 800 4:3
CPU	ARM Cortex-A9 process 800 MHz
Memory	DDR2 512MB
Storage	2G
TF Card	Card Reader, up to 32GB
Touch screen	Resistance / Dual touch
WIFI	802.11 b/g/n
G-Sensor	Rotator Screen
Camera	0.3MP/2MP ( front/back)
HDMI	HD video output
USB	Mini USB 2.0 Host/OTG
Speaker	8Ω/1W x 2 Earphone jack 3.5mm
Battery	3000mAh
Adapter	Input: 100-240V 50/60Hz 0.3A Output: 5VDC 2.1A