



ITEM NO. 3107

# AIR SOFT JUSTICE DEALER

FULL-FUNCTION RADIO CONTROL  
4 WHEEL DRIVE VEHICLE



16  
YRS.+



Manufactured & Distributed by  
© 2011, Cache Sales, LLC  
Logan, UT 84321 www.ignite-rc.com  
All rights Reserved MADE IN CHINA

## OPERATING INSTRUCTIONS

**\*IMPORTANT:** IF VEHICLE DOES NOT RESPOND PROPERLY, PLEASE REPLACE BATTERIES IN VEHICLE (6-AA NOT INCLUDED) AND BATTERY IN CONTROLLER (1-9V NOT INCLUDED).

**\*\* NOTE:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

**\*\*\*FCC NOTE:** THE PROVIDED ANTENNA IS A UNIQUE TO THIS VEHICLE. BY INSTALLATION OF UNAUTHORIZED ANTENNA TO THIS EQUIPMENT. SUCH UNAUTHORIZED INSTALLATION COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:  
1. This device may not cause harmful interference, and  
2. This device must accept any interference received, including interference that may cause undesired operation.

**PLEASE DO NOT RETURN TO STORE**  
For more information or questions, please email Consumer Services:  
[help@cache-sales.net](mailto:help@cache-sales.net)

PATENT PENDING.

VEHICLE IS DUAL OPERATED. VEHICLE CAN USE REGULAR BATTERIES OR RECHARGEABLE BATTERIES.

IGNITE RECHARGEABLE BATTERY PACK SOLD SEPARATELY. CHECK STORE FOR PRODUCT.

DO NOT MIX ALKALINE, STANDARD (CARBON ZINC) OR RECHARGEABLE (NICKEL CADMIUM) BATTERIES.

DO NOT MIX OLD AND NEW BATTERIES.

DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.

USES 6AA BATTERIES IN VEHICLE (NOT INCLUDED) AND 1 9V BATTERY IN CONTROLLER (NOT INCLUDED).

COLORS AND DECORATIONS MAY VARY. ACTUAL PRODUCT MAY VARY SLIGHTLY AS WE STRIVE IN BETTER PRODUCT DEVELOPMENT. KEEP CONTENT DETAILS FOR FUTURE REFERENCE.

**FCC** Tested To Comply With FCC Standards  
FOR HOME OR OFFICE USE.


**WARNING:**  
CHOKING HAZARD-Small parts.  
Not for children under 3 years.



Manufactured & Distributed by  
© 2011, Cache Sales, LLC  
Logan, UT 84321 www.ignite-rc.com  
All rights Reserved MADE IN CHINA

## FUNCTIONS

Diagram #4



To turn the Vehicle "ON," turn the switch to the appropriate battery option, Left for regular batteries, and Right for the 7.2V rechargeable battery batteries. Then select a band from the top switch (Remote and Vehicles bands must match in order to run).


### NOTE:

Operating multiple Vehicles with the same frequency in close proximity will cause interference and poor performance. Multiple frequency bands are available to play 4 at the same time.

Works best away from high voltage power lines, large building and walls.

## HIGH AND LOW GEARS


Diagram #5



For top terrain performance, turn both switches to high or low gear accordingly.

## STEERING TRIM

Diagram #6




Adjust Steering Trim for precise running alignment

If vehicle begins to pull to the Left, adjust the control towards the Right. If vehicle begins to pull to the Right, adjust the control towards the Left.


## CONTROLLER & FIRING INSTRUCTIONS

Diagram #7




Band on vehicle must match band selection on controller. Controller must be in 'ON' position and antenna must be extended

Diagram #8




To shoot BBs, press both top red buttons at the same time.

Diagram #9




Use either of these middle buttons to control the angle of the turret. Buttons control up and down movement for precision aiming.

Diagram #10



These bottom buttons rotate the turret left and right for precision aiming.

## CONTENT LIST




**NOTE:**  
To prevent damage, the contents of the package that are listed above have been packed in the tray and may be out of plain sight. Please remove all contents from the tray.

**\*\*\*FCC NOTE:** THE PROVIDED ANTENNA IS A UNIQUE TO THIS VEHICLE. BY INSTALLATION OF UNAUTHORIZED ANTENNA TO THIS EQUIPMENT. SUCH UNAUTHORIZED INSTALLATION COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

## ANTENNA INSTALLATION

Diagram #1




### ANTENNA NOTES:

A) Make sure the batteries have been inserted correctly (+ or -) into vehicle and Controller.  
B) If the Vehicle does not respond properly, please replace the alkaline batteries in the Vehicle and/or controller battery.

Remember to take out all the batteries from the vehicle and the controller if the vehicle will not be used for a long time.

## VEHICLES REGULAR BATTERY INSTALLATION

Diagram #2




DO NOT MIX ALKALINE, STANDARD (CARBON ZINC) OR RECHARGEABLE (NICKEL CADMIUM) BATTERIES.

DO NOT MIX OLD AND NEW BATTERIES.

DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.

## VEHICLES RECHARGEABLE BATTERY INSTALLATION

Diagram #3



VEHICLE IS DUAL OPERATED. VEHICLE CAN USE REGULAR BATTERIES OR RECHARGEABLE BATTERIES.

IGNITE RECHARGEABLE BATTERY PACK SOLD SEPARATELY. CHECK STORE FOR PRODUCT.

### PLEASE NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

## TROUBLE SHOOTING

PROBLEMS	REASONS	SOLUTIONS
RUNNING PROBLEMS	The batteries inside the radio controller are too weak.	Replace with new alkaline batteries inside the control unit, or recharge battery pack.
	There is a weak or low reception for the radio control.	
	The batteries inside the vehicle are too weak.	
OPERATION PROBLEMS	A small object obstructs movement of the tire or axle.	Use tweezers to remove obstruction
	The vehicle was driven on the carpet and has fabric threads caught in the axle.	Playing on the carpet is not recommended
OTHER	The vehicle does not respond to the radio control.	Try playing in another location.
	The vehicle control's frequency is disrupted by something around the environment.	Some other equipment using the same radio wave may disrupt the radio control. Either play in another location or turn off the other equipment.

## LOADING BB'S INSTRUCTIONS

Diagram #11



### WARNING:


ONLY USE 6mm plastic BBs in this airsoft vehicle. Use of any other ammunition can cause injury to you or damage to the airsoft vehicle.

### WARNING:

DO NOT re-use plastic BBs because they could possibly cause damage to your airsoft vehicle.

## UNLOADING BB'S INSTRUCTIONS

Diagram #12



### WARNING:

Never assume that because the airsoft vehicle no longer fires a BB and/or the chamber is empty or removed, that a BB is not lodged in the barrel. Always treat the airsoft vehicle as though it is loaded and with the same respect you would a firearm.

### Warning Statement:

You and others with you should always wear eye protection to protect your eyes. Read all instructions and warnings in this manual before using this airsoft vehicle. Buyer and user have the duty to obey all laws about the use and ownership of this airsoft vehicle.

Please read this owner's manual completely. Remember to treat this airsoft vehicle with the same respect you would a firearm. Always carefully follow the safety instructions found in this owner's manual and store in a safe place for future reference.

## IMPORTANT INFORMATION

### Aiming and Firing Safely

- You and others with you should always wear eye protection designed for airsoft to protect your eyes.
- Always point your airsoft vehicle in a SAFE DIRECTION.
- Do not shoot at hard surfaces or at the surface of water. The plastic BBs may bounce off or ricochet and hit someone or something you had not intended to hit.
- DO NOT re-use plastic BBs because they could possibly cause damage to you or your airsoft vehicle.
- Your airsoft vehicle is designed for target shooting and is suited for both indoor and outdoor use. Always remember to place your target carefully. THINK about what you will hit if you miss the target.
- Your airsoft vehicle is fully automatic. It will continue to fire as you hold in the triggers.

### Reviewing Safety

- Do not ever point the airsoft vehicle at any person. Do not ever point the airsoft vehicle at anything you do not intend to shoot.
- Always treat the airsoft vehicle as though it is loaded and with the same respect you would a firearm.
- Always aim in a SAFE DIRECTION, Always keep the muzzle of the airsoft vehicle pointed in a SAFE DIRECTION.
- Always check to see if the airsoft vehicle is "OFF" and unloaded when getting it from another person or from storage.
- Always keep your fingers off the triggers until ready to shoot.
- You and others with you should always wear eye protection to protect your eyes.
- Always wear eye protection designed for airsoft over your regular glasses.
- Use 6mm plastic BBs only.
- Do not re-use plastic BBs because they could cause possible damage to your airsoft vehicle.
- Do not shoot at hard surfaces or at the surface of water. The plastic BBs may bounce off or ricochet and hit someone or something you had not intended to hit.
- Replace the backstop if it becomes worn. Place the backstop in a location that will be safe should the backstop fail.
- Your backstop should be checked for wear before and after each use. All backstops are subject to wear and will eventually fail. Replace your backstop if the surface is worn or damaged or if a ricochet occurs.
- Do not attempt to disassemble or tamper with your airsoft vehicle.
- DO NOT MODIFY OR ALTER YOUR AIRSOFT vehicle. Attempts to modify the airsoft vehicle in any way may make your airsoft vehicle unsafe to use, cause serious injury or death and will void the warranty.
- Using unauthorized repair centers or modifying the function of your airsoft vehicle in any way may be unsafe and will void your warranty.
- Do not put the airsoft vehicle away loaded. Make sure ALL of the plastic BBs are unloaded from the airsoft vehicle.
- Always store this airsoft vehicle in a secure location.