

User manual

1. Directions

- 1) For Safety purposes, the lamp fixture must be powered off before being installed, changed or being cleaned
- 2) This ballast cannot be operated with dimmer device. In order to keep the lamp's high performance it should be used in defined voltage.
- 3) This ballast can be performed under environmental areas in temperature from -18° C to 45° C, it can be used in enclosed fixture, but cannot be used in wet location.
- 4) Please check the power, voltage and contacts of the lamp incase the lamp performs abnormal signs such as the light blinking or the light turns off suddenly
- 5) The rated lamp bulb is F25T8, please use correct lamp model according to ANSI Specificatoin

4. Warning:

This device complies with Part 18 of the FCC Rules.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45–30 MHz. If this occurs, please change outlet or move the lamp far away from other appliance.

GUANGDONG GANGFENG ELECTRICAL APPLIANCE CO LTD
LONGJIANG TOWN, SHUNDE DISTRICT, FOSHAN CITY, GUANGDONG, CHINA