包装信息	型号：WM622 成品尺寸：75*95MM 材质：80g书写纸，骑马钉 工艺：四色印刷 版本号：V1.0-20250102
备注信息	**保密等级：一般** 封面封底背面留白 英德日 软V1.0_20241231版本修改了第8/20/32页文案。

背面

正面

Model：WM622/WM622A

maono

Hey Beat Making
Internal Microphone Worldwide

To get technical support please scan the QR code

Technical support:
support@maono.com

Made in China

Hereby, Maono declares that this product is in compliance with the essential requirements and other relevant provisions of the Directive 2014/53/EU. The entire Declaration of Conformity can be found at the following Internet address: www.maono.com/ce

The CE/UKCA Mark and applicable CE Mark for sale within the European Economic Area (EEA) and Switzerland and UK (GB) are affixed on the product or its packaging, and are also displayed on the product's instruction manual and warranty card. For more user manuals, please access to https://www.maono.com

UK REP
Cosmos Sol Network Services Ltd.
Suite 2, 3rd Floor, 5 Jubilee Place, London, SW3 3TD, United Kingdom
Tel: +44(0)203 868 0880
Email: uk-rep@cosmos-sol.com

EC REP
Cosmos - Sun Link Sp. z o.
Aleksandra Lubomirska 2/6, 01-466 Warszawa, Poland
Tel: +48 (22) 653 89 84
Email: ec-rep@cosmos-sol.com

P/N:200000

maono

Hey Beat Making
Internal Microphone Worldwide

Maono(中文名称：麦风)，"MAONO"，Kickstarter，the No.1 Beat Making Internet Microphone Worldwide Brand that products are sold well in 152 countries worldwide. With the beautiful vision of becoming a global leading brand of Internet audio products that deliver a pleasant sound experience, Maono is always working with audio professionals, influencers, and users to make the world's best microphones and audio products.

Wave Ti mini
AI Wireless Lavalier Microphone
Quickstart Guide

CONTENTS

English..... 01-12
Deutsch..... 13-24
日本語..... 25-36

1. TX Type-C Receiver (For Connecting Devices)

Can be connected to devices such as cell phones/tablets/computers/sports cameras with Type-C ports.

2. RX Lightning Receiver (For Connecting Devices)

Can be connected to devices such as iphone 7 series & phone 8 series & phone 13 series & phone 14 series & Pro and other Apple phone/tablets with lighting interfaces.

3. RX 3.5mm TRS Receiver (For Connecting Devices)



4. TX Transmitter (Microphone)

5. Pairing (Cold Phone Version)

The transmitter and receiver have been paired successfully before leaving the factory, and will be connected automatically after powering on TX and RX plus lights are always on.

If the dual lights flash, the pairing process has not succeeded, you can perform the following pairing procedure.

After paired, both the transmitter and receiver indicator lights will stays on.

6. Connection Pairing (Camera Version)

The transmitter and receiver have been paired successfully before leaving the factory and will be connected automatically after power on TX and RX lights are always on. If the lights are flashing or the connection or unsuccessful, you can perform the following pairing procedure.

7. How to turn on the noise reduction (Cell Phone Version)

Click the transmitter power button under the state of successful power on pairing:

Turn on the noise reduction	1 → 3
Turn off noise reduction	3 → 1

Turn on the noise reduction mode, you can judge the noise reduction level according to the indicator:

Close	
One Times	switch to the first step of noise reduction (low gear: light flashes 1 time
Twice	switch to the second step of noise reduction (medium gear: light flashes 2 times)
Three Times	switch to the third step of noise reduction (strong gear: light flashes 3 times)
Four Times	switch to level 4 noise reduction (super strong) gear: light flashes 4 times

Click the reverse noise reduction button in sequence to cycle through the noise reduction levels.

8. How to turn on the noise reduction (Camera Version)

Click the transmitter power button under the state of successful power on pairing:

Turn on the noise reduction	1 → 3
Turn off noise reduction	3 → 1

Turn on the noise reduction mode, you can judge the noise reduction level according to the indicator:

Close	
One Times	switch to the first step of noise reduction (low gear: light flashes 1 time
Twice	switch to the second step of noise reduction (medium gear: light flashes 2 times)
Three Times	switch to the third step of noise reduction (strong gear: light flashes 3 times)
Four Times	switch to level 4 noise reduction (super strong) gear: light flashes 4 times

Click the reverse noise reduction button in sequence to cycle through the noise reduction levels.

9. How to open the AI voice change (Cell Phone Version/Camera Version)

Inserted into the phone port, you can also set "Uncle", "Goddess", "Baby Voice", Peacock Voice"A kinds of voice change mode through APP.

If you are not sure whether to turn on AI voice change and the current voice change mode, you can re-plug the receiver to restore the original sound

10. How to charge (Cell Phone Version)

Place the transmitter into the charging case to charge:

Charge the charging case with the including Type-C to USB-A charging cable

Power Indicator
The indicator light flashes white slowly when the charging case is charging, and the white light stays on when fully charged.

When the charging case is not charging, the indicator light flashes white for a especially and then turns off after taking the to out. It indicates that the charging case is in hibernation.

11. How to charge (Camera Version)

Place the transmitter and camera receiver into the charging case to charge.

The charging indicator white light flashes slowly when charging, and the white light is always on when fully charged.

Charge the charging case

①Charging port Type-C
Charge the charging case through the Type-C connector.
②Battery indicator
Display the current battery level information of the charging box, see the following for details:

The power indicator can be used to display the power level during charging and discharging, the indicator is defined as follows:

- ⓪ Indicates that the LED is always on during the indication process.
- ① Indicates that the LED is always off during the indication.
- ② Indicates that the LED is off.



Charging Case indicator

LED1	LED2	LED3	LED4	Charging indicator(battery charging, LED stay on or turn)
⓪	⓪	⓪	⓪	1g-49%
⓪	⓪	⓪	①	50-70%
⓪	⓪	①	①	71-90%
⓪	①	①	①	>90%
LED1	LED2	LED3	LED4	Power indication(non-charging status)
⓪	⓪	⓪	①	1g-50%
⓪	⓪	①	①	51-70%
⓪	①	①	①	71-90%
①	①	①	①	>90%

12. How to charge with magnetic charging cable

APP Download
Scan the official QR code to download Maono Link APP or download "Maono Link" in the App Store or Google Play. After the Bluetooth connection, you can easily set microphone gain (volume), noise reduction level, AI voice changer, microphone upward switch, AI noise changer and other user settings through APP.

*The camera version needs to purchase a USB Type-C to USB Type-C or USB Type-C to Lightning cable to connect the mobile phone to use APP

Important safety precautions

1. Please read the manual carefully and follow all instructions and terms and pay attention to all precautions.
2. Do not disassemble the product or replace phone charger to charge this product. To avoid product damage, do not use a charger exceeding 5V to charge this product. Do not use the product in a place where electronic equipment is the environment, the package is no longer equipped with a waterproof function.
3. Do not plug in hit the microphone, which will damage the microphone pickup and affect the sound quality.
4. Do not use this product in high humid environments, such as outdoor rainy or wet basements, it is forbidden to use the battery when it is soaked in water.
5. Do not expose this product to liquid splashing or dripping areas, and do not place objects filled with liquid on the product.
6. Do not use this product in heat source, high temperature, etc, such as near the sources, sun exposure areas, radiators, heaters and other equipment. Do not place it in a place where the temperature exceeds 40°C. Do not charge to prevent lightning high voltage from breaking through the circuit of the product.
7. When going out or not using this product for a long time, please unplug the charger and turn off the switch.
8. Do not place this product near strong magnetic or strong interference equipment, such as radio concentration area, RFID readers, high voltage power lines, electromagnetic ovens, microwave ovens, etc.
9. Do not use any acidic alkaline or corrosive detergents to clean the product, which may cause irreversible damage to the appearance. When cleaning this product, please use a dry cloth or a cloth dipped in a small amount of neutral detergent to wipe the surface.
10. Please use the USB charging cable to prevent it from being stepped on or the cable from being entangled and torn off.
11. Do not disassemble the product without permission, such as severe heating, odor, etc., please unplug the USB charger immediately and cut off the power supply.
12. Do not disassemble and repair the machine without authorization. If the machine is damaged or a fire is caused, Maono will not take any responsibility.

1. RX Type-C受信機（デバイス接続用）

Type-Cポートを持つスマホ/タブレット/パソコンなどのデバイスに接続可能。

2. RX Lightning受信機（デバイス接続用）

iphone7、iphone8、iphone X5、iphone11、iphone12、iphone13 Pro、iphone14、iphone14 Pro などのLightning端子を備えたApple製スマホやタブレットなどのデバイスに接続可能。

3. RX 3.5mmTRS受信機（デバイス接続用）

4. TX1-送信機（マイクロホン）

5. ペアリング（スマホペアリング）

送信機と受信機は工場出荷前にペアリングが成功しており、電源をオンにすると、両方の表示ライトは常時点灯するはずです。

もし、ライトが点滅している場合は、ペアリングが成功しておらず、以下のペアリング操作を行うことができます。

*ペアリングが完了すると、送信機と受信機のインジケーターランプは点灯したままになります。

6. ペアリング（カメラペアリング）

送信機と受信機は工場出荷前にペアリングが成功しており、電源をオンにすると、両方の表示ライトは常時点灯するはずです。ライトが点滅している場合は、以下のペアリング操作を行うことができます。

7. ノイズキャンセリング機能をオンにする方法。（スマホペアリング）

電源オンペアリング成功の状態で、送信機の電源ボタンをクリック：

ノイズキャンセリングのオフ	1 → 3
ノイズキャンセリングのオン	3 → 1

ノイズキャンセリングモードをオンにすると、インジケーターランプ（ノイズキャンセリングレベルを示す）が点灯。

タップ：

1回	レベル1（弱）ノイズ低減に切り替えるには、緑色ライトが1回点滅
2回	レベル2（中）ノイズ低減に切り替えるには、緑色ライトが2回点滅
3回	レベル3（強）ノイズ低減に切り替えるには、緑色ライトが3回点滅
4回	レベル4（最強）ノイズ低減に切り替えるには、緑色ライトが4回点滅

8. ノイズキャンセリング機能をオンにする方法。（カメラペアリング）

電源オンペアリング成功の状態で、送信機の電源ボタンをクリック：

ノイズキャンセリングのオフ	1 → 3
ノイズキャンセリングのオン	3 → 1

ノイズキャンセリングモードをオンにすると、インジケーターランプ（ノイズキャンセリングレベルを示す）が点灯。

タップ：

1回	レベル1（弱）ノイズ低減に切り替えるには、緑色ライトが1回点滅
2回	レベル2（中）ノイズ低減に切り替えるには、緑色ライトが2回点滅
3回	レベル3（強）ノイズ低減に切り替えるには、緑色ライトが3回点滅
4回	レベル4（最強）ノイズ低減に切り替えるには、緑色ライトが4回点滅

9. AIボイスチェンジャーの方法（スマホペアリング）

ボイスチェンジャーをセットアップしたり、ノイズリダクションの切り替わりをする「叔母」、「おじさん」、「子供の声」、「孔雀ボイスチェンジャー」の5種類。

ボイスチェンジャーに関係のないボイスチェンジャーをしないために、ヒントがない場合、受信機を再に差すとボイスチェンジャーを切ります。

10. 充電方法（スマホペアリング）

充電ケースの送信機をカバーに充電します。

付属のType-C - USB A充電ケーブルで充電ケースを充電します

充電インデーター
充電中は、充電ケースの電源インジケーターは白色の点滅を遅くします。満充電になると白色のインジケーターは点灯します。充電ケースが充電中でないときは、インジケーターは白色の点滅を1回、電源オフ/スリープ状態のときは1回点滅します。ケースが長時間放置されてから初めて充電されたときは、充電ケースの電源が点灯しています。

充電ケースのインデーター

⓪	⓪	⓪	⓪	1g-49%
⓪	⓪	⓪	①	50-70%
⓪	⓪	①	①	71-90%
⓪	①	①	①	>90%
LED1	LED2	LED3	LED4	電源インデーター（非充電状態）
⓪	⓪	⓪	①	1g-50%
⓪	⓪	①	①	51-70%
⓪	①	①	①	71-90%
①	①	①	①	>90%

11. 充電方法（カメラペアリング）

充電ケースの送信機を充電ケースに入れると充電します。

充電中は充電インジケーターの白色ライトがゆっくり点滅し、満充電になると白色ライトが常に点灯します。

充電ケースのポート

1. 充電ポート（Type-C）
Type-C ポートを通じて充電ケースを充電します。
2. 電源インデーター
電源インデーターの電源情報を表示します。詳細は以下の表を参照してください。

電源インデーターは、充電及び放電プロセスの電源を表示するために使用されます。インジケーターの定義は以下の通りです：

- ⓪ LED インジケーター常時点灯
- ① LED インジケーター点滅
- ② LED インジケーター消灯

充電ケースインデーター

⓪	⓪	⓪	⓪	充電インデーター（充電中、LEDが常に点灯します）
⓪	⓪	⓪	①	1g-49%
⓪	⓪	⓪	①	50-70%
⓪	⓪	①	①	71-90%
⓪	①	①	①	>90%
LED1	LED2	LED3	LED4	電源インデーター（非充電状態）
⓪	⓪	⓪	①	1g-50%
⓪	⓪	①	①	51-70%
⓪	①	①	①	71-90%
①	①	①	①	>90%

12. 充電ケースのための充電方法

APPダウンロード
公式のQRコードをスキャンしてMaono Link APPをダウンロードするか、App StoreまたはApple App StoreでMaono Link APPを検索してください。ペアリングが成功すると、ユーザーは簡単にマイクゲイン（ボリューム）、ノイズリダクションレベル、アップ・ムーブ、ノイズスピーカー、AIボイスチェンジャーなどのユーザー設定を管理できます。

*カメラバージョンでは、USB Type-C to USB Type-C ケーブルまたはUSB Type-C to Lightningケーブルを購入して携帯電話に接続し、APPを使用する必要があります。

重要な安全上の注意事項

1. 本マニュアルをよくお読み、すべての指示と条件に従い、すべての注意事項に注意してください。
2. 本製品の分解や充電器の使用は禁止。製品の損傷を防ぐため、5Vを超える充電器を使用して本製品を充電することはできません。本製品は電子機器の環境下で使用する場合、パッケージは防水機能を備えていません。
3. 本製品を強く叩いたり、ぶつけたりしないでください。マイクピックアップを損ない、音質に影響を与えます。
4. 本製品を高湿度の環境（屋外の雨天時や地下室など）で使用することは禁止されています。水に浸かっている状態でバッテリーを使用することは禁止されています。
5. 本製品を液体飛散・滴下エリアに近づけないでください。液体で満たされた物体を本製品の上に置かないでください。
6. 本製品を熱源、高温などの環境（直射日光、ラジエーター、ヒーター、その他の機器の近くなど）に使用しないでください。本製品を40℃を超える場所に置かないでください。雷撃による高電圧が製品の回路を破壊するのを防ぐため、充電しないでください。
7. 外出中や本製品を長時間使用しない場合は、充電器のプラグを抜いてスイッチを切ってください。
8. 本製品を強磁場や強干渉の機器、例えば、電波集中エリア、RFIDリーダー、高圧電線、電磁オーブン、電子レンジなどの近くに置かないでください。
9. 酸性アルカリ性や腐食性の洗剤を使用しないでください。外観に不可逆的な損傷を与えるおそれがあります。本製品を清掃する際は、乾いた布または中性洗剤を少量浸した布を使用して表面を拭いてください。
10. USB充電ケーブルを使用すると、ケーブルが踏まれたり引きちぎられたりするのを防ぐことができます。
11. 本製品を無断で分解しないでください。過熱臭などを感じた場合は、すぐにUSB充電器を抜き、電源を切ってください。
12. 無許可で機械を分解・修理しないでください。機械が損傷したり火災が発生した場合、Maonoは責任を負いません。

FCC Requirement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.