A18



ANC and ENC Headphones

User Manual

V02 20250409

Product Description



❶ ANC Button
❷ Microphone
❸ 3.5mm AUX Audio Jack
❹ Connect Indicator Light
❺ USB-C Charging Port
❻ Charging Connect Indicator Light
❼ Earmuff
❽ Play/Pause/Power Button
❾ Volume +/Previous Track
❿ Volume -/Next Track
⓫ Adjustable Headband

Note: The power button shares the same function as the play/pause button. Long press (2.5s) this button to power the headset on or off, and single click it to control media playback or calls.

Customer Service

After-sales Service Phone Number: **+1 (781) 430-4818 Mon.-Fri.**
(If you have any issue, please feel free to contact us, and we will reply within 48 Hrs)

Product Specifications

Model No.	A18
Product Name	Wireless Headset
Input	5V ⎓ 1A
FCC ID	2AWUL-A18
Stereo Mode	ANC / Transparency
Battery Capacity	3.7V 750mAh, 2.775Wh
Support Mode	Music/Game Mode
Speaker Size	Φ 40mm
Connect Range	33Feet/10m
Charging Time	1.5Hrs
Charging Cable	Type-C
Supported Profiles	A2DP, AVRCP, HSP, HFP
Support Device	Smartphones, PC, Laptop, Computer, Watch, TV

Packaging List

A18 Headphones x1 | Type-C Charging Cable x1 | 3.5mm Audio Cable x1 | Headphone Pouch x1 | User Manual x1

Reminder:
Before using headphones for the first time, please fully charge it using a standard compliant charger. It is recommended to use a 5V/1A charging adapter. The Type-C Charging cable comes with the package.

Power On & Off

Power On:
Press and hold the Play/Pause button (▶II) for about 2S. The indicator light turns blue 1S with a prompt sound "Power On".

Power Off:
Press and hold the Play/Pause button (▶II) for about 2s until the indicator light turns white and turns off

Note: If no device is connected within 3 minutes after powering on, the headphones will automatically power off. Indicator light will turn white for 1S before shutdown.
If headphones is disconnected from the device, the indicator light will start flashing blue. If no reconnection occurs within 3 minutes, the headset will automatically power off.

ANC & Transparency Mode Switching

With Transparency Mode, you can stay connected to your surroundings while enjoying your music. Whether you're jogging on busy streets or waiting for a flight announcement, this feature lets in ambient sounds for added safety and awareness.

Advanced ANC technology reduces unwanted ambient sounds, allowing you to fully immerse yourself in music, calls, or podcasts. Whether you're on a noisy commute, in an office, or on a plane, ANC creates a quieter, more focused listening experience.

Pairing the Headset with Your Device

For first-time use, press and hold the power button (▶II) for 7 seconds to power on the headset. The indicator light will flash blue and red, and the headset will enter Bluetooth pairing mode. On your device, search for "A18" in the Bluetooth settings and click to connect. Once successfully connected, the indicator light will turn off and the headset will prompt"connected". After the initial pairing is completed, it will automatically reconnect to the last paired device (as long as Bluetooth is enabled and the device is within range).

Reset Headphones

While the headset is powered on, press and hold both the "+" and "–" buttons for 5 seconds. The headset will clear all pairing records and re-enter pairing mode. The indicator light will flash blue rapidly for 3 seconds to indicate the reset.

Button Control

Music Controls

Pause/Play: Single Click Power Button — 1x
Increase Volume: Single click "+" — 1x
Decrease Volume: Single click "-" — 1x
Next Track: Double clicks "+" — 2x
Previous Track: Double clicks "-" — 2x

Call Controls

Answer Call: Single Click Power Button — 1x
End Call: Long Press Power Button for 2 Seconds — 2s
Reject Call: Long Press Power Button for 2 Seconds — 3x

Voice Assistant

Activate: Triple clicks power button — 3x
End Voice Assistant: Triple clicks power button — 3x

Wired Mode & AUX Audio Support

This headset supports AUX wired connection. A 3.5mm audio cable is included. When the battery is low or Bluetooth is unavailable, connect the headset to your phone, computer, or tablet via the audio cable to use it as a standard wired headphone—no power-on or pairing required.

Note: Active Noise Cancellation (ANC) is not available in wired mode.

Music/Game Mode

This headset supports switching between Game Mode and Music Mode. While the headset is powered on and connected, quickly press the ANC button 4 times to toggle between modes:

Game Mode: Ultra-low latency for enhanced audio-visual sync in gaming

Music Mode: High-fidelity audio optimized for music and media playback

Troubleshooting

The charging light doesn't turn on or headset won't charge.

A Check the cable and adapter. Use a standard 5V/1A charger. Try cleaning the charging port and reconnecting.

The headset cannot connect to a Bluetooth device.

A Ensure the headset is in pairing mode (indicator light flash blue). If not, press and hold the power button to re-enter pairing. Also make sure Bluetooth is enabled on your device.

The headset disconnects randomly.

A Ensure the device is within the 10-meter Bluetooth range and that there are no major obstructions. If it happens frequently, reset the pairing and reconnect.

ANC mode doesn't switch or respond.

A Make sure the headset is powered on and connected. Press and hold the ANC button for 3 seconds. If unresponsive, try restarting the headset.

Why does the battery seem to drain quickly when I first use the headset?

A The battery may not be fully charged after storage or shipping. If used without first fully charging, or left on in pairing/standby mode, it may drain quickly. For best performance, fully charge the headset before first use and power it off when not in use.

Battery Warning

Using the wrong battery can cause fire and other hazards (for example, in the case of some lithium battery types).

1. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

2. Do not leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

3. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian Information on RF exposure and compliance.

Le présent appareil est conforme àgnés exposen de ce matériel aux conformité ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Caution

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

The symbol indicates DC voltage

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE).
This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.
This product can be used across EU member states.
The device is low power device, it can meet the requirement of the RF exposure.

NOTED:
1.High Sound Pressure
2.Hearing Damage Risk
3.Do not listen at high volume levels for long periods.

Made in China

A18说明书
尺寸：142x178mm
材质:108g铜版纸
风琴折