92mm

62mm

CATALOGUE

01 How to wear headphones correctly 3
02 Product Introduction 8
03 Touch Operation 9
04 Item list 18
05 Warranty Statement 21

Welcome to MINISO Wireless Earphones

Take out and pair it

When using for the first time, please remove the left and right sides Blue headphones at the same time. When the headphone indicator light flashes red and blue alternately, the left and right headphones will enter automatic pairing mode.

How to wear headphones correctly

Product Description

Long Press

Wake up voice assistant

When using both ears, press and hold the left ear multifunction button for 2 seconds to enter the voice assistant. When using one earphone, press and hold the left or right earphone for 2 seconds to activate the voice assistant.

Phone mode

Press and hold the left or right ear multifunction button for two seconds call rejection

Triple Press

Music mode

Triple press on the left ear: Previous song

Triple press on the right ear: next song

Clear Bluetooth pairing history

When both ears cannot be paired, you need to clear all connected records and delete the left and right earphones 5 times at the same time.

Wireless pairing mode

1. When there is no pairing record for the left and right earphones, the left and right earphones will automatically pair after they are turned on. After successful pairing, there is no sound prompt.

2. When the left and right headphones have paired before, after they are turned on, they will automatically pair when they are turned on, and the prompt will sound: "Pair".

Switch between game mode and music mode

Game mode

Press and hold the multifunction button on the left ear for 2 seconds

Music mode

Press and hold the multifunction button on the right ear for 2 seconds

Note 1: When using one headphone, you cannot switch between game mode and music mode.
Note 2: The factory setting defaults to music mode

Item list

Headphones *1



Charging case *1

Instruction *1

Charging cable *1

FCC ID: 2BHJR-8M23

FCC Statement:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

US REP
Name: MINISO INTERNATIONAL (US) LLC
Address: 3670 HIGHLAND ST. TORRANCE, CA 90505, United States
Contact Name: Henry Wang
Phone number: 626-757-8888
Email: ecustomer@miniso.com

Charging Indicator

Type-c Interface

Specification of Product

Model of Product: 8M23	Charging Case Input: 5V=250mA
Version: V5.4	Charging Case Output: 5V=60mA
Effective Distance: Approx. 10m	Earphone Battery Capacity: 30mAh
Speaker Diameter: 6+12mm	Charging Case Battery Capacity: 250mAh
Impedance: 32Ω	Duration: Approx. 4 Hr (Earphone)
Frequency Response: 20Hz-20KHz	Earphone Charging Time: Approx. 1.5 Hr
Microphone Sensitivity: -42dB±3dB	Charging Time of the Charging Case: Approx. 1 Hr
Earphone Input: 5V=30mA	

Touch Operation

Connect with Bluetooth device

Open the Bluetooth settings option of the Bluetooth device to be paired, enter the options and find the Bluetooth pairing name of the headset "MINISO-8M23". Click the pairing name to pair.

Indicator Light Description

- When the headset is turned on: The white light and ice blue light alternately flashes.
- When the headset is turned off: The white light flashes rapidly 3 times and then goes off
- Pairing status:The main ear white light and ice blue light alternate flashing, and the auxiliary headphone light is off
- Connection successful: ice light

- When the headset is in use: Charging case indicator light is always white, and the headset white light is always on. After the headset is fully charged, the white light turns to ice blue and then goes out, and the Charging case indicator light goes out at the same time.

- Charging of the Charging case: The ice blue light of the Charging case indicator light is always on. After the case is fully charged, the indicator light of the Charging case is always on.

Power On:
Automatic power on: The earphones are in the charging case, and after the charging case opens, the Earphone will be powered on.
With the prompt sound of "Du".
Manual power on: Long press for 3 seconds, the Earphone will be powered on.
With the prompt sound of "Du".

Power Off:
Auto power off: Put the Earphone in the charging case, close the charging case,(note:the Earphone will be automatically powered off after the prompt "Du")
Manual power off: Long press for 5 seconds, the Earphone will be powered off, with the prompt sound of "Du".

Note: When the Bluetooth connection is lost, the Bluetooth pairing time is limited, it will automatically shut down after 5 minutes, and the Bluetooth device, it will automatically power off after 3 minutes, with the prompt sound of "Du".

Once Press

Music mode

Play/Pause

Phone mode

Call Answer/End

Double Press

Music mode

Double press the left ear: Volume decreases

Double press the left ear: Volume increases

Warranty statement

MINISO
product warranty card

Product name			
User info.	Name		Phone number
	Telephone		
	Address		
	Postal number		
Sales and information	Name	Dealer	
	Address		
	Telephone		

The above guarantee does not apply to the following situations

1. The validity period of the three guarantees has exceeded.
2. Failure of the product to function normally due to exceeding the product itself.
3. Failure of products caused by misuse, abuse or improper transportation, use, maintenance or storage.
4. Failure of damages caused by force majeure (such as earthquake, war, fire, etc.) or accident.
5. Failure of products caused by unauthorized disassembly and repair.
6. Difficulties or loss caused by overheating.
7. Any damage caused by sharp objects.
8. Any damage caused by improper operation and lower logging.
9. Damage caused by unauthorized dismantling and modification.
10. Aging, discoloration, wear, cracking and other losses that occur during normal use of the product.
11. Any other losses that are not the responsibility of the manufacturer and seller.
The completeness and appearance of the product and accompanying materials are not covered by the warranty. You should inspect the product on the when receiving it and raise objections to any transportation damage.

MINISO Product service policy

If you encounter a problem, please contact our customer service to solve it.
After-sales email: 7MINI-service@yeme.com

Warranty Policy

Hardware:
This manual does not come with any form of warranty,guarantee expression or other implication. The content of this manual is subject to change without notice. If there is any change in the referred only, and the content will be updated on the website at any time without prior notice.

Warranty statement:
1. This product is guaranteed to make for the products attached in this document. If the product is damaged due to quality defects under normal use within twelve(12) months from the date of your purchase (the date of purchase is based on the date recorded on the invoice or other proof of purchase), we can confirm that it cannot be repaired, it will be replaced free of charge, the repaired product will continue to be guaranteed for the remaining warranty period of the original product, or a refund will be issued. The purchase date will be based on the order invoice date. If the purchase date cannot be determined, the warranty period shall be calculated as starting12 months from the product production date.
2. Please keep the invoice or other proof of purchase, as it is required for any warranty claim or repair. When applying for a warranty, you are required to provide a valid sales invoice that is accurate, complete and clearly filled out.

Guidelines for safe and effective use

Voice: Please read this information first before using your Bluetooth headset. If the user makes modifications or modifications to this Bluetooth headset without permission, the user will lose the right to use the Bluetooth headset indicated in the device.

Electromagnetic interference:
Electronic devices: To avoid the effects of electromagnetic interference or configuration interference, please turn off your Bluetooth device in accordance with regulations in places with clear instructions.

Civil Aviation: After boarding the plane, please turn off your Bluetooth headset according to the flight attendant's instructions, and do not use the Bluetooth headset during flight to avoid interference with the aircraft communication system.

Battery makers:
It is strongly recommended that when you are not using the Bluetooth headset, place it in a place where it will not be exposed. Exposing may cause damage to the product or personal injury.
Children:Do not let children play with Bluetooth headsets.Some of the small parts are detachable and may be swallowed and cause danger.

Important safety tips

●Please do not disassemble or modify the product in the manual, please do not attempt to disassemble or replace any parts in the product.
●Do not use the product in high temperature environments, it is prohibited to microwave, Puncture, or dismantle the battery. If there are abnormal phenomena such as excessive temperature, smoke, explosion, or leakage, please immediately stop using the product and place it in a place with sunlight. Do not use the battery after it has been immersed in water or in high-temperature environments, and do not place it in a place with high heat, such as near a heat source or exposed to direct the sunshine in a hot car. Do not place sharp objects, such as knives, sharp scissors, or other high-temperature and high-pressure objects on the product. Do not use the battery in a place where static electricity is generated and discharged for a limited number of times and exceed the age. If the battery is used abnormally, please stop using the product and contact the manufacturer or the seller in time. If the battery is damaged, please immediately stop using it and replace it. It can only be replaced by an alternative service provider recommended by the manufacturer or seller.
●When the product is used and scrapped, do not throw the product into a fire.The waste should be handed over to the relevant recycling institutions for recycling and processing in accordance with the relevant laws and regulations.
●Please do not use or disassemble the product in a place where static electricity or a series of interferences such as other wireless products, Bluetooth signals, WiFi signals, etc., the headphones are used in a place where static electricity or a series of interferences such as other wireless products, Bluetooth signals, or disconnection. If this happens, please reconnect the headphones or stop using them temporarily.
●When charging, please use a charging device with an output voltage of DC 5V-1A. You must choose a charging device that meets the requirements of the battery specifications. If the battery is not fully charged, the charging time is shorter than the specified charging time. Do not use a charging device that exceeds the specified charging time. Do not use a charging device that exceeds the specified charging time. Do not use it.

Enjoy the company of MINISO