TMR-RF985R Location of nameplate

The nameplate is located on the center of bottom exterior.