SPK-796

Mini Bluetooth Stereo Speaker

User's Manual

Index

Mini Bluetooth stereo speaker SPK—796 Overview 3
Getting Started 3
Talk & Standby Time 3
Nominal Charging Time 3
Charging Your Speaker 3
Low Battery 3
Turning Your speaker On and Off 4
Pairing Your speaker 4
Using your speaker 4
Adjusting the volume 5
Track forward 5
Track reverse 5
Pause and play 5
Answering a Call 5
Answering a Call when Listening to stereo Audio 6
Ending a Call 6
Rejecting a Call 6
Dialing from your mobile handset 6
Redial last number 6
Last Number Redialing from Your speaker 6
Enjoying Stereo Audio from Your PC/Device 6
Line in mode 6
Care and Maintenance 7
Safety Information 7
Troubleshooting 8
Specifications 8
Declaration of Conformity 9

Dear Sir/Madam

Thank you for choosing the Mini Bluetooth stereo speaker SPK—796, we hope you will enjoy the convenience we are bringing to you. The Mini Bluetooth stereo speaker SPK—796 offers many functions, please read this manual before getting started.

Overview

The Mini Bluetooth stereo speaker SPK-796 is a wireless stereo portable speaker based on the Bluetooth wireless technology. It complies with Bluetooth 2.0 protocol, supporting speakerphone and Handsfree A2DP+AVRCP profile. Mini Bluetooth stereo speaker SPK-796 has 4 buttons:

■ Getting Started

- Insert your Mini Bluetooth stereo speaker SPK—796, please follow the steps:
  - Ensure your headset is fully charged
  - Pair your speaker with a Bluetooth enabled mobile handset or music player or PC.

■ Talk, standby & Music playing Time

Fully charged battery offers up to 8 hours of talk time or 4 hours of music playing time, and 200 hours of standby time. When no calls are in progress, the speaker remains turned on and in standby mode.

■ Nominal Charging Time

Fully charged battery takes about 3.5 hours approximately 4 hours. The LED will turn off when the battery is fully charged – now disconnect the charger from AC power and turn on your speaker. Please refer to Turning your speaker on and off. For pairing, please refer to Pairing your speaker.

■ Charging Your Speaker

The speaker is designed with a built -in rechargeable battery. It is recommended that battery should be fully charged for the first time to ease Connect the USB cable to your PC(laptop) for charging or connect an AC adapter with the USB cable to the power for charging. Charging available in your package.

Remarks: Charge stabilization will be delayed for severe seconds when the first time to use, or, the speaker has not been used for a long time, or, the battery is drained.

■ Low Battery

The LED will flash red when the speaker is on and the battery becomes low – at this point you should recharge its battery.

■ Turning your speaker on and off

> Turning on the speaker

Push down the power switch, a lower blue led will be flashed to indicate that the speaker is turned on. Or, touch and hold the MFB for 4 seconds until you hear a short beep. The speaker will be in pairing mode when the blue led flashes fast and alternately. Or the LED will flash blue when the speaker becomes connected with last paired devices.

Remarks: Touch the MFB again each time you turn on the speaker to reactivate pairing so that the connection between the speaker and the mobile handset is resumed. For pairing, please refer to "Pairing your speaker".

> Turning off the speaker

Touch and hold the MFB for 4 seconds until LED flash red. Or turn off the power switch.

Remarks: To disconnect the Bluetooth connection, please firstly turn off your speaker by holding the MFB key.

■ Pairing your speaker

In the first pairing process, you must pair it with a Bluetooth®-enabled mobile handset or music player or PC(Bluetooth enabled Device) as follows:

1. Place the speaker and the Bluetooth device between 1 meter range of each other without any obstructions.
2. Ensure the speaker is OFF.
3. Push down the power switch – it has just paired device is found within 10 seconds, the speaker will switch to pairing mode when the LED of speaker flashes blue and red.
4. Activate your Device's Bluetooth function.
5. Set the Device to search for Bluetooth devices within 1 meter range, then select Mini Bluetooth stereo speaker SPK—796 from the list.
6. Enter the default password '0000' and press 'OK' to pair your speaker and the Device.
7. Go back to the main menu of Device, and you can enjoy stereo music via Bluetooth, or make a call, and a call and speak a call with both headsets.

Remarks:

A if the pairing can not be completed within 2 minutes when pairing mode is activated, the speaker will turn off. Please repeat step 1 to 7 to pair the speaker and the mobile handset again.

B Speaker pairing procedure is subject to different modes of handsets and mobile handset.

■ Using your speaker

> Adjusting the volume

Push down the volume button down button repeatedly to obtain ideal levels of sound.

> Track forward

Touch the volume down button for 2 seconds to track forward while playing music.

> Track reverse

Touch the volume up button for 2 seconds to track reverse while playing music.

> Pause and Play

Touch the MFB to pause music and once again to continue playing.

> Answering a call

When there is an incoming call you will hear ringing through the speaker, use your mobile handset to accept a call or please see below.

> Answering a call while listening to stereo audio

Incoming call will pause the music, you will hear a call waiting tone, to audio, music will automatically resume after a call.

Remarks: On play stereo audio from your mobile handset or PC/Device, please make sure your device is connected with Bluetooth stereo A2DP profile. Music can not automatically continue after a call for some Bluetooth phones.

> Ending a call

Touch the MFB for 2 seconds and hold 1 sec or send the call via your mobile handset as normal.

> Rejecting a call

To reject an incoming call, touch and hold the MFB key for 2 seconds.

> Dialing from your mobile handset

Make calls to your mobile handset in the normal way.

> Redial last number

Touch and hold the MFB key for 4 seconds to transfer the call from speaker to mobile handset. Press the MFB once again to use the speaker.

> Last number redialing from your speaker

Touch and hold the Volume Up button for 2 seconds on your speaker and the last number will be redialed.

Remarks

The volume functions are only applicable to mobile handsets with Bluetooth Handsfree Profile. Functionality varies depending on the mobile handset. For additional information, please refer to the User Guide of your mobile handset.

■ Enjoying stereo audio from your PC/Device

If your PC/laptop/device is Bluetooth enabled,you can enjoy stereo audio from your PC/laptop/device.

■ Line in with music player

> Power on

Make sure the power is on. The speaker will transfer to line-in mode automatically when the 3.5 mm down line cable is plugged in. The speaker is ready for music playing with blue LED flashing slowly and alternately.

> Power off

The speaker will be in standby mode when the 3.5-line cable is unplugged.

■ Care and Maintenance

> Exterior

- Turning your speaker off before plugging it into your pocket or bag. If the MFB is accidentally touched, your mobile handset may make an unintended call.
- Do not expose the speaker to liquid, moisture or humidity as it is not waterproof.
- Do not use abrasive cleaning solvents to clean the speaker.
- Do not expose the speaker to extremely high or low temperatures.
- Do not dispose of the speaker in a fire and it will result in explosion.
- Do not expose your speaker to contact with sharp objects as this will cause scratches and damage.

- Do not place or poke anything inside the speaker as this may damage internal components.
- Do not attempt to disassemble the speaker as it can cause injury.
- Do not place the speaker on a vibrating surface.
- If you do not use the speaker for a long time, ensure you store it in a dry place, free from extreme temperatures and dust.

> Built-in Battery

- Do not attempt to replace the speaker's battery by yourself as it is built into the device and is non-chargeable.
- Charge the battery in accordance with the instruction from this User Guide.

> Charging

- Only use the charger that manufacturer supplied when charging the speaker.
- Do not disassemble the charger as it may expose you to dangerous voltages or other risks.
- Incorrect reassembly will cause an electric shock when the speaker is subsequently used.
- Do not use the charger outdoors or in damp areas where exposed to the elements.
- Only charge the speaker's built-in battery in a dry environment. Refer to the User Guide.
- Avoid charging the speaker in extreme high and low temperature conditions.

■ Safety Information

Please read carefully and follow the safety information and handling for driving. If you use the speaker while driving, ensure 100% of your attention and focus remains on the road — please drive responsibly.

Never allow children or infants to play with the speaker – small parts may be a choking hazard. Adult supervision is advised at all times.

Pay attention to all signs that require an electric device to RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.

Turn off your speaker before boarding an aircraft. Do not use your speaker in an aircraft. Never mount or store your speaker into any air bag deployment area as serious injury may result on air bag deployment.

Do not open or touch the built-in battery.

Dispose of batteries according to local regulations. Do not dispose as household waste.

Dispose of the packaging of the product in accordance with the latest provisions.

■ Troubleshooting

If you are unable to connect your speaker and mobile handset, please try as follows:

- Make sure your speaker is turned off and is properly charged.
- Make sure the speaker is within your mobile handset.
- If you do not see the speaker for a long time, ensure you store it in a dry place, free from extreme temperatures and dust.
- Make sure both devices are within 0.5 meter range of each other, where there are no obstructions, such as walls or other electronic devices.

If your speaker will cannot connect to your mobile handset after the above steps, please recharge the speaker and remove the memory of your mobile handset for a while. The Mini Bluetooth stereo speaker SPK—796 is compliant with and adheres the Bluetooth Specification 2.0. However, interoperability between the speaker and other Bluetooth enabled products is not guaranteed because it depends on compatibility. For more information on the compatibility of your Mini Bluetooth stereo speaker, please contact the manufacturer, or contact the customer service department.

■ Specifications

- Bluetooth Specification: Version 2.0 class 2
- Output 2.5W
- Bluetooth profile supported: Speakerphone Handsfree and A2DP + AVRCP
- Range of frequency: 20Hz-20KHz
- Dimensions: 90mm(W)*34mm(H)*90mm
- Nominal Charging Time: About 4 hours
- Talk Time: Up to 8 hours
- Music Playing Time : Up to 4 hours
- Standby Time: Up to 200 hours
- Weight: 200g(net)

Remarks: Talk time & Music playing time or Standby Time may vary due to users operation and mobile phone settings.

■ Declaration of Conformity

We, declare that the following product:

Product Name: Mini Bluetooth stereo speaker SPK—796

is in conformity with the following essential requirements of Council Directive 1999/5/EC

(referred to as R&TTE Directive)Article 3.1a, 3.1.b and 3.2, and the product is manufactured in accordance with following standards:

CE FC

EN 300 328 V1.7.1 (2006-10)
EN 301 489-17 V1.3.2 (2008-04)

This equipment complies with the essential requirements of the Council Directive 1999/5/EC. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. (Example— use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with FCC rip with RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This equipment complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

This equipment is marked to CE6 is recognized for firmware to only operate on 2.4G channel 7th