VERSATILE
EASILY PERFORMS STUNTS AND WHEELIES

COMPETITIVE
AVAILABLE IN 2 FREQUENCIES FOR TWO PERSON PLAY

WIRELESS
REMOTE CONTROL FOR FULLY FUNCTIONAL RACING ACTION

360° WHEELIES

Car requires 4 "AA" 1.5V alkaline batteries (not included). See bottom panel for additional battery information. Colors and styles may vary.

THE BLACK SERIES™

radio controlled 360° rally car
thunder tumbler®

THE BLACK SERIES™

radio controlled 360° rally car
thunder tumbler®

BOX CONTAINS THE FOLLOWING FREQUENCY:
☐ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE
BATTERIES NOT INCLUDED
AGES 6 AND UP

⚠ **WARNING!**
CHOKING HAZARD - Small parts. Not suitable for children under 3 years.

TWO FREQUENCIES FOR COMPETITIVE RACING

360 DEGREE SPINS AND OTHER STUNTS

REAL LED LIGHTS!

radio controlled 360° rally car
thunder tumbler®

stunts, wheelies & LED lights!

THE BLACK SERIES™

radio controlled 360° rally car
thunder tumbler®

360° WHEELIES

radio controlled 360° rally car
thunder tumbler®

OPERATING INSTRUCTIONS

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from package.
2. Locate the battery compartment on the back of car and insert batteries as shown.
3. Swivel latches on bottom of car to release battery pack and insert batteries.
4. Switch both car and remote buttons to "ON" position.
5. For outdoor use, use tire ons on hard surfaces such as concrete.

REMOTE CONTROL ASSEMBLY

USE ONE 9V BATTERY (NOT INCLUDED)

ON/OFF SWITCH

BATTERY DIAGRAM

ON/OFF SWITCH

USE 4 "AA" 1.5V ALKALINE BATTERIES (NOT INCLUDED)

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

GENERAL CONTROLS



Reverse
Press both control sticks backward.

Forward
Press both control sticks forward.

Spinning Action
Press and hold the control sticks in opposite directions.

Action Button
Press and hold the action button to have the car spin with its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)



1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

NOTE: The car moves in a clockwise or counterclockwise direction depending on which way it faces when the action button is pressed. This is a function of physics. Pursuant to Part 15 of the CFR Title 47, these limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or lightning.
- Do not use near power lines or other electrical equipment.
- Do not submerge car or controller in water.
- Do not use near pets or other small animals.
- Never operate your car in a crowded or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep your hands and other objects away from the tires, gears and motor while the car is switched to "ON".
- Do not place your car near sources of heat or under direct sunlight for long periods of time.
- Remove batteries from car if you do not intend to use it for an extended period of time.
- Do not operate your car outside overnight. Dampness is harmful to electronic components.
- Remove all batteries from car prior to your accustomed operation.
- Use only batteries specified in this manual. Do not mix old and new batteries.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries as per polarity diagram in battery compartment.
- Remove batteries from toy when not in use for an extended period of time.
- Do not short circuit the battery terminals or attempt to recharge the batteries.
- Do not dispose of batteries in fire. Batteries may explode or leak.
- Remove any broken or weak batteries from the toy.
- Only use batteries specified in this manual. Do not use batteries of different types, such as alkaline and carbon zinc, or rechargeable batteries.
- Remove batteries from toy when not in use.
- Remove batteries from toy before disposal.
- Do not short circuit the battery terminals or attempt to recharge the batteries.
- Do not dispose of batteries in fire. Batteries may explode or leak.
- Remove any broken or weak batteries from the toy.
- Only use batteries specified in this manual. Do not use batteries of different types, such as alkaline and carbon zinc, or rechargeable batteries.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

164/1807 (xxxxx)

SAMPLE

Made in China

©2010 Mattel/Boonco, LLC. The Black Series, Thunder Tumbler and all associated logos are trademarks of Mattel/Boonco, LLC. All Rights Reserved.

Patent Pending. Patent No. 2,320,230,320.0001.

For technical support, please visit www.mattelhelpcenter.com or call 1-800-374-2244.

The product and design of this product are protected by US copyright laws and may not be reproduced, distributed, or transmitted in any form or by any means, electronic or mechanical, without the express written permission of Mattel. Mattel does not accept ideas, creative concepts or suggestions for new toy ideas.

100	60	0	0
100	20	10	0
100	0	0	0
100	90	10	0

Black
Cyan
Magenta
Yellow