# maxell

# Lecture Capture Station

# MA-XL1

IC ID:25103-MAXL1 FCC ID:2ABGQ-MA-XL1

# User's Manual (concise)

Please read through this manual before using this product, in order to use safely and utilize well the product.

# 使用说明书(简易版)

为了您能够更安全舒适地使用本产品,请在使用本产品前请仔细阅读本说明书。



# **Lecture Capture Station MA-XL1**

# **User's Manual (concise)**

Thank you for purchasing this Lecture Capture Station.

This is the basic manual on the product. Visit our website to get the detailed manuals (**Safety Guide, Operating Guide**) and the latest information on the product.

Check them before using the product, for safe use and utilization of the product.

Our website: Please see the attached sheet

#### **⚠ WARNING**

- Before using this product, be sure to read all manuals for the product. After reading them, store them in a safe place for future reference.
- Heed all the warnings and cautions in the manuals or on the product.
- Follow all the instructions in the manuals or on the product.

(Page no.)

# **Contents**

First of all	02
Graphical symbols explanation	02
Important Safety Instructions	03
Disposal of Old Equipment and Batteries Only for European Union	
and countries with recycling systems	03
Note for the battery symbol (bottom symbol)	04
About Electro-Magnetic Interference	04
Package accessories	05
Placement	06
Product connection	07
Connecting the power supply	08
Product setup	09
Connection	09
Basic operations	11
Turning on the power	11
Turning off the power	11
Specifications	12
Manufacturing year and month	14

# First of all

# **Graphical symbols explanation**

The following entries and graphical symbols are used for the manuals and the product as follows, for safety purpose. Know their meanings beforehand and heed them.

<b>⚠ WARNING</b>	This entry warns of a risk of serious personal injury or even death.	<u> </u>	Warning / Caution
		(h)	Turns the power on/off
	This entry warns of a risk of		Starts recording
♠ CAUTION personalinjury or physical damage.	personalinjury or physical		Stops recording
	7	Switches channel	
NOTICE	This entry notices of fear of causing trouble.	(i)	Information
	· ·		Projector power on/off
			Audio output

### **Important Safety Instructions**

The followings are important instructions for safely using the product. Be sure to follow them when handling the product. The manufacturer assumes no responsibility for any damage caused by mishandling that is beyond normal usage defined in these manuals of this product.

#### ♠ WARNING

- Never use the product in or after an abnormality (for example, giving off smoke, smelling strange, finding a foreign object inside, and so on.) If an abnormality should occur, unplug the product urgently.
- This product is suitable for adults who have the ability to operate this machine. Situate the product away from children and pets.
- Keep small parts away from children and pets. If swallowed, consult a physician immediately for emergency treatment.
- Do not use the product during electrical storms.
- Unplug the product from the power outlet if the product is not being used.
- Do not open or remove any portion of the product, unless the manuals direct it. For internal maintenance, leave it to your dealer or their service personnel.
- Use only the accessories specified or recommended by the manufacturer.
- Do not modify the product or accessories.
- Do not let any things or any liquids enter to the inside of the product.
- Do not get the product wet.
- Do not place the product where any oils, such as cooking or machine oil, are used. Oil may harm the product, resulting in malfunction, or falling from the mounted position.
- Do not apply a shock or pressure to this product.
  - Do not place the product on an unstable place such as the uneven surface or the leaned table.
  - Ensure the product is stable. Place the product so that it does not protrude from the surface where the product is placed on.
  - Place your hands on the grip on the bottom of the product when carrying it.
  - Remove all the attachments including the power cord and cables, from the main device when carrying it.
- Do not approach the exhaust vents, while the product is on.

# Disposal of Old Equipment and Batteries Only for European Union and countries with recycling systems



The above mark is in compliance with the Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE). The mark indicates the requirement NOT to dispose the equipment including any spent or discarded batteries as unsorted municipal waste, but use the return and collection systems available. If the batteries or accumulators included with this equipment display the chemical symbol Hg, Cd, or Pb, then it means that the battery has a heavy metal content of more than 0.0005% Mercury, or more than 0.002% Cadmium or more than, 0.004% Lead.

### Note for the battery symbol (bottom symbol)



This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

### **About Electro-Magnetic Interference**

This is a Class A product. In a domestic environment this device may cause radio interference in which case the user may be required to take adequate measures.

This device may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

# CE

Hereby, Maxell, Ltd., declares that the radio equipment type Lecture Capture Station is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

http://www.maxell.eu/uploads/docs/PJ-DoC.pdf

#### **CAUTION**


- the ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.:
- no naked flame sources, such as lighted candles, should be placed on the apparatus;
- attention should be drawn to the environmental aspects of battery disposal;
- the use of apparatus in tropical climates.

the instructions for use shall state that the apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

## **Package Accessories**

Your product should come with the items shown below. Check that all the items are included. Contact your dealer immediately if any items are missing.

- 1 Power adaptor
- 2 Power cord \*
- 3 Bluetooth Antenna
- 4 Balance line connector (2 units)
- 5 DIDO connector
- 6 USB number keyboard stickers
- 7 Rack mount bracket (1 pair) + M4 x 6mm screw (8 units)
- 8 User's manual (concise)\*\*
- 9 URL sheet
- \* The number of power cords varies depending on the region.
- \*\* This concise is a basic manual. For details, consult the **"Operating Guide"** from our website before using. ( 1)



#### **⚠ WARNING**

• Keep small parts away from children and pets. Take care not to put in the mouth. If swallowed, consult a physician immediately for emergency treatment.

#### **NOTICE**


• Keep the original packing materials for future reshipment. Be sure to use the original packing materials when moving the product.

#### **Placement**

Please set this product to level. This product can be mounted into a rack (for 19-inch rack) with the

provided "rack mount bracket". When attaching the rack mount bracket to the main unit, be sure to use the provided screws. For details, consult the **Operating Guide**.  $(\square 1)$  Please follow the manual of the rack to mount.

Please take a distance of more than 2 cm between the product and the wall.



#### **⚠ WARNING**

- Install the product where you can access the power outlet easily.
- Do not install the product near thermally conductive or flammable things.
- Do not place the product in a place where it may get wet.
- Do not place the product where any oils, such as cooking or machine oil, are used. Oil may harm the product, resulting in malfunction, or falling from the mounted position.
- Install the product in a stable horizontal position.
  - Do not put the product on its side, front or rear position
  - Do not attach nor place anything on the product unless otherwise specified in the manual.
- Do not block the intake vents and exhaust vents of the product. If the intake vents and exhaust vents of the product are blocked, the accumulated inside heat may cause fire.
- When attaching the rack mount to the main unit, be sure to use the provided screws. Using other screws may cause failure, fire, or electric shock.

#### **A** CAUTION

- Place the product in a cool place with sufficient ventilation.
  - Do not stop up, block nor cover the product's vent holes.
  - Do not place the product at places that are exposed to magnetic fields, doing so can cause the cooling fans inside the product to malfunction.
- Avoid placing the product in smoky, humid or dusty place.
  - Do not place the product near humidifiers.

#### NOTICE

• Do not place the product in a place where radio interference may be caused.

#### **Product connection**

Before connecting the product to a device, consult the manual of the device to confirm that the device is suitable for connecting with this product and prepare the required accessories, such as a cable in accord with the signal of the device.

Consult your dealer when the required accessory did not come with this product or the accessory is damaged.

After making sure that this product and the devices are turned off, perform the connection, according to the following instructions.

For details, consult the **Operating Guide.**  $(\square 1)$ 

#### **!** WARNING

- Use only the appropriate accessories. Otherwise it could cause a fire or damage the product and devices.
  - Use only the accessories specified or recommended by this product's manufacturer. It may be regulated under some standards.
  - Neither disassemble nor modify this product and the accessories.
  - Do not use the damaged accessory. Be careful not to damage the accessories. Route a cable so that it is neither stepped on nor pinched.

#### **⚠** CAUTION

- Before connecting this product to a network system, be sure to obtain the consent of the administrator of the network.
- Do not connect the WAN/LAN port to any network that might have the excessive voltage.
- If you use the product connected to the network, there is a risk of information leakage via the product. Also, since there is a fear of illegal operation, please be sure to perform network security measures including the following countermeasures under the responsibility of the customer.
  - Use the product on a network that is secured with a firewall etc.
  - When using the product on a system to which a PC is connected, it checks and removes infections of computer viruses and malicious programs on a regular basis.
  - Change the password of admin / director / video manager, and limit the users who can login. For details, consult the Operating Guide.  $(\Box 1)$
  - Do not leak video data, authentication information (user name, password), various server information, etc. on the network.
  - Do not install the product or its cable in places where it can be easily change connection.

#### NOTICE


- Do not turn on or off this product while connected to a device in operation, unless that is directed in the manual of the device.
- Some input ports are selectable in the use. For details, consult the **Operating Guide**. (🖺1)
- Be careful not to mistakenly connect a connector to a wrong port.

# Connecting the power supply

- 1. Connect the power cord to the Power adaptor.
- 2. Put the DC plug of the power adaptor into the DC 24V connector of the product.
- 3. Firmly plug the power cord's plug into the outlet. In a couple of seconds after the power supply connection, the **POWER** indicator lights up in steady red.

Power button / indicator





#### **⚠ WARNING**

- Use extra caution when connecting the power cord, as incorrect or faulty connections may result in fire and/or electrical shock.
  - Do not touch the power cord with a wet hand.
  - Only use the Power cord and the Power adaptor that came with the product. If it is damaged, consult your dealer to get a new one. Never modify the power cord and the Power adaptor.
  - Only plug the power cord into an outlet whose voltage is matched to the power cord. The power outlet should be close to the product and easily accessible. Remove the power cord for complete separation.
  - Do not distribute the power supply to multiple devices. Doing so may overload the outlet and connectors, loosen the connection, or result in fire, electric shock or other accidents.
  - Connect the terminal for the AC inlet of power adaptor to the power outlet of the building using an appropriate power cord (bundled).
  - When multiple power cords are included, please use the power cord that matches the outlet shape.

#### **NOTICE**

 This power adaptor is also designed for IT power systems with a phase-to-phase voltage of 220 to 240 V.


#### **Product setup**

The input port assignment must be set up from web browser by the administrator. For details, consult the Operating Guide.  $(\square 1)$ 

#### **Connection**

Please turn off this product when hook up other devices. For how to turn off the power, consult the "Turn off the power".

Consult the below wiring schematic.



#### **CAUTION**

- Consult the administrator of Network before connecting to WAN/LAN port.
- Do not connect the LAN port to any network that might have the excessive voltage.
- Incorrect connection may cause the malfunction. Please connect cables with care.
- Turn off the speaker and this product at connection to avoid unexpected large volume flow.
- Adjust volume with care when using an amplified speaker.

#### **NOTICE**

- Before connecting, consult the manual of device that is using with this product.
- The Length of LAN cable must be equal or less than 100m. When the length is over 100m, it may cause the quality loss on the image/sound or malfunction on network communication.
- The Length of BNC cable must be equal or less than 100m.
- Use RJ-45 connector when connecting to WAN/LAN port.
- For details, consult the **Operating Guide.** (🕮1)

#### RSS-Gen Issue 4 8.4

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Industry Canada ICES-003 Compliance Label:

CAN ICES-3 (\*)/NMB-3(\*)

\* Insert either "A" or "B" but not both to identify the applicable Class of ITE.

#### 15.19 (All FCC application)

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### 15.105 (Part 15B unintentional radiator / including composite device)

digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### 15.21 (All FCC application)

Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

ENGLISH

# **Basic operations**

### Turning on the power

- 1. Make sure that the Power adaptor and power cord is firmly and correctly connected to the product and the outlet.
- 2. Make sure that the **POWER** indicator is lighted in steady red.
- 3. Press the (1) (power) button on the product.





Press the power button to start automatically.

When the power button is pressed, the power indicator lights red and green alternately. When startup is completed, the indicator lights in steady green.

#### **NOTICE**

- Turn on any connected devices prior to the product.
- After turning off the power, if the indicator is light in red it is possible to turn on the power.

# **Turning off the power**

- 1. Press the POWER button on the product. The message "Shutdown?" appears on the screen for about 10 seconds.
- 2. Press the POWER button again while the message appears. the POWER indicator will begin blinking in red. Then the POWER indicator will stop blinking and light in steady red when shutdown completed.

Power button / indicator



#### **MARNING**

- Remove the power cord for complete separation.
- Turn off any connected devices prior to the product power off.


# **Specifications**

Item	Specification
Product Name	Lecture Capture Station
Model Name	MA-XL1
Dimension	Approx. 430 mm(W) x 60 mm(H) x 206 mm(D) (without rackmount) Approx. 480 mm(W) x 60 mm(H) x 206 mm(D) (with rackmount)
Weight (mass)	Approx. 3.0 kg
Power Requirement	DC: 24V/2.5A AC: 100~240V/1.5A
Power Consumption (Max.)	60W (Max.)
Operating Temperature / Humidity	0°C ~ 40°C / 10% ~ 90% RH
WAN, LAN	10 / 100 / 1000Mbps
Ports	Front audio output

(continued on next page)

# Specifications (continued)

# Front



Back



No.	Name	Brief introduction
1	Audio volume meter	Display audio level
2	Bluetooth pairing indicator	Show Bluetooth connection status
3	USB indicator	Show front USB storage status
4	Recording start button	Recording start and pause
5	Recording stop button	Recording stop
6	Video switch button	Video source switch; cycling switch for each assigned source
7	Information button	Short push: Information list appears and USB mouse control switch back from PC to the product Long push: Approx. 2 sec. Bluetooth pairing start
8	Projector power button	Power on / off button of PJLink compatible projector or Hitachi / Maxell projector.
9	Main power button	Power on / off button for MA-XL1
10	Power connector	DC: 24V / 2.5A
11	Reset button	Press about 15 seconds to Reset all settings to factory default value
12	Security bar	Security bar

# Manufacturing year and month

The manufacturing year and month of this product is indicated as follows in the serial number of the rating label on the product. Example:

#### T9AW00001

☐ Manufacturing month: A=January, B=February, ... L=December ☐ Manufacturing year: 9=2019, 0=2020, 1=2021, ...

#### NOTICE

- The information in this manual is subject to change without notice.
- The illustrations shown in this manual are example only. Your product may differ from the illustrations.
- The reproduction, transfer or copy of all or any part of this document is not permitted without express written consent.

# 智能录播一体机

# MA-XL1

# 使用说明书(简易版)

承蒙您购买本产品,谨向您表示衷心的感谢。

本说明书仅对基础使用进行说明,请访问我们的网站取得本产品之详细说明书(操作指南及安全指南),了解本产品的最新信息。

为了您能够更安全舒适地使用本产品,请在使用本产品前仔细阅读所有说明书。

#### 欢迎访问我们的网站:网址请参阅附件

#### **小警告**

- 使用本产品前, 务必阅读本产品的所有说明书。阅读后, 请妥善保管以备日后参考。
- 请阅读说明书中或产品上的警告和注意事项。
- 请遵守说明书中或产品上的所有说明。

🚇 (页码)

	02
条目与图示符号解释	02
安全指示要点	03
关于废弃电气和电子设备	03
电池标志要点	03
关于电磁干扰	04
物品清单	05
布置	06
连接各个设备	07
连接电源	08
设定	
连接	09
基本操作	11
开启电源	11
关闭电源	11
规格	12
制造年月	14

# 首要

# 条目与图示符号解释

以下条目和图示符号均用于安全目的,在本说明书和本产品中的使用如下。请预先了解这些条目和图示符号的含义,并予以留意。

△警告	本符号用于警告有严重人身伤害甚至 死亡的危险。		警告 / 注意
△注 意	本符号用于警告有人身伤害或是物质 受损的危险。	•	开启 / 关闭电源 启动录像
通告	本条目用于告知可能会导致故障。		停止录像频道切换
		<u>(i)</u>	信息
			开启 / 关闭投影机电源
			音频输出

#### 安全指示要点

以下是关于安全使用本产品的重要指示。在操作本产品时,请务必始终按照这些指示。对于因超出 此产品说明书所述的正常使用范围之外的不当操作而引起的任何损失,生产商恕不承担责任。

#### ↑ 警告

- •请勿在异常(例如:冒烟、异昧、内部有液体或异物、破裂等)发生时或发生之后使用本产品。如果发生异常现象,应立即拔下本产品之电源插头。
- 本产品仅限具备能力操作本产品之成人使用,请将本产品放置在远离儿童和宠物的地方。
- 请将小零件放置在远离儿童和宠物的地方。如果吞下,立即咨询医生以进行紧急治疗。
- 请勿在雷电情况下使用本产品。
- 如果当前不使用本产品,请将本产品插头从电源插座上拔下。
- 请勿擅自打开或拆卸本产品的任何部分,除非本说明书有所指示。内部维护应交给您的经销商或其服务人品。
- 请使用制造商指定或推荐的附件。
- 请勿擅自己改装本产品及其附件。
- 请勿使任何物体或液体进入本产品内部。
- 请勿弄湿本产品。
- •请勿将本产品放置在使用任何油品(如烹饪油或机油)的地方。油品可能会损坏本产品,导致故障或从安装位置掉落。
- 请勿敲击或挤压本产品。
  - 请勿将本产品放置在不平稳的地方,例如不平坦的表面或倾斜的桌面等。
  - 请勿不平稳地放置本产品。放置本产品时,请勿使本产品超出其放置的表面。
  - 搬运本产品时,请将手放在产品底部。
  - 搬运本产品时,应拆下本产品上的所有附件,包括电源线和电缆。
- 本产品运作时,请勿靠近出风口。



#### 关于废弃电气和电子设备

标志符合废电机电子设备指令 2012/19/EU(WEEE) 的规范。标志要求,不要将包括废旧电池、 损坏电池或蓄电池在内的设备当作一般城市废物来处理,而是要使用可用的回收和采集系统。如果 该设备包含的电池或蓄电池显示了化学符号 Hg、Cd或 Pb,表示电池含有高于 0.0005% 汞、 高于 0.002% 镉或高于 0.004% 铅的重金属成分。



#### 电池标志要点

本标志可与化学标志结合使用。在这种情况下,它符合有关化学品的指令规定要求。

## 关于电磁干扰

这是 A 类产品。 在家庭环境中,本设备可能引起无线电干扰,在这种情况下,可能要求用户采取适当的措施。

如果在住宅区使用,本设备可能会造成干扰。 除非用户采取特殊措施减少电磁辐射以防止干扰无 线电和电视广播的接收,否则必须避免于住宅区使用。

# CE

因此, Maxell, Ltd. 公司声明无线电设备类型 Lecture Capture Station 符合指令 2014/53/EU。

欧盟符合性声明的全文可在以下网址获取:

http://www.maxell.eu/uploads/docs/PJ-DoC.pdf


#### **企注意**

- 不得用报纸、桌布、窗帘等物品盖住通风口。
- 不得在设备上放置裸露火源,如点燃的蜡烛。
- 应注意电池处理的环境方面规定。
- 在热带气候中使用设备。
- 说明书中应描述设备不可暴露在滴水或溅水的环境中,且不得在设备上放置装有液体的物体,如花瓶。

## 物品清单

请小心打开包装,并检查是否包含下列所有物品。如果缺少任何物品,请立即与本产品销售商联系。

- 1 电源适配器
- 2 电源线 \*
- 3 蓝牙天线
- 4 平衡音频线连接器 (2个)
- 5 DIDO 连接器
- 6 USB 数字键盘贴纸
- 7 机柜支架 (一对)+M4 x 6mm 螺丝钉(8个)
- 8 使用说明书(简易版)\*\*
- 9 URL 说明页
- \* 电源线的数量因地区而异。
- \*\* 本说明书仅对基础使用进行说明,使用前请访问我们的网站并阅读本产品之"操作指南"(💵1)



⚠ 警 告

•请将小零件放置在远离儿童和宠物的地方。注意勿将小零件放入嘴巴,如果不小心吞下,请立即咨询医生以进行紧急治疗。

#### 通告

• 请妥善保管员包装材料以便将来重新包装。搬运本产品时,请务必使用原包装材料,搬运时请小心避免碰撞。


#### 布置

请将本产品平放安装。

本产品可利用"机柜支架"安装在机柜中,将机柜支架安装到本产品时,请务必使用本产品提供的螺丝钉详细说明请参阅操作指南。(Ш1)

请参考机柜之手册进行安装。

请在本产品和墙壁之间保持2厘米以上的空间。



#### ⚠ 警告

- 将产品安装在容易连接电源插座的位置。
- 请勿将本产品安装在导热或易燃物品附近。
- 请勿将本产品安装在任何可能受潮的地方。
- •请勿将本产品放置在使用任何油品(如烹饪油或机油)的地方。油品可能会损坏本产品,导致故障或从安装位置掉落。
- 将本产品安装在稳定的水平位置。
  - 请勿将本产品之正面、背面或侧面朝下放置。
  - 除非手册中另有说明,否则请勿在本产品上粘贴或放置任何物品。
- •请勿将任何物品放在进风口和排风口附近。否则可能导致高温并引发火灾或冒烟。
- 将机柜支架安装到本产品时,请务必使用本产品提供的螺丝钉,使用其他螺丝钉可能会导致故障,火灾或触电。

#### ⚠ 注 意

- 请将本产品放在凉爽的地方,并确保有充足的通风。
  - 请勿堵住、堵塞或以其他方式遮盖本产品的通风口。
  - 请勿将本产品放置在暴露于磁场的地方,否则将导致产品内部的冷却风扇发生故障。
- 请避免将本产品放在多烟、潮湿或多尘的地方。
  - 请勿将本产品放在加湿器附近。

#### 通告

• 请勿将本产品放置在可能会导致无线电干扰的地方。

# 连接各个设备

将本产品连接至设备前,请阅读该设备的说明书确认其可以与本产品连接,并准备好所需配件,如 与设备信号相匹配的电缆等。

如果本产品未附带所需配件或配件损坏,请咨询经销商。

确保本产品和设备的电源已关闭,并请按照以下说明执行连接。

请参考本产品之详细操作指南。(□1)

#### ♠ 警告

- 请使用适宜的配件,否则会导致火灾或设备和本产品损坏。
  - 请使用本产品制造商指定或推荐的配件。如果本产品没有配套提供所需的配件或配件损坏,请咨询您的经销商。可能会按照某些标准进行管理。
  - 请勿拆卸或改动本产品和配件。
  - 不要使用己损坏的配件。小心不要损坏配件。应确保电缆的铺设路线不会被踩到或压到。

#### **① 注** 意

- 将本产品连接至网络前, 务必获得网络管理员的同意
- 请勿将 WAN/LAN 端口连接到任何有可能产生过高电压的网络。
- 如果您将本产品连接到网络,则存在透过本产品泄漏信息的风险。此外,由于担心非法操作,使用者必须负担网路安全责任,请务必执行包括以下对策在内的网络安全措施。
  - 在具有防火墙等保护措施的网络上使用本产品
  - 利用 PC 连接并使用本产品时,请定期检查并清除 PC 内的病毒感染和恶意程序。
  - 更改 admin / director / video manager 的密码 , 并限制可以登录的用户。详细信息请参阅操作指南。(Q1)
  - 请勿泄露网络上的视频数据,验证信息(用户名,密码),与各种服务器信息等。
  - 请勿将本产品或其网络电缆安装在容易被更换连接的位置。


#### 通告


- 本产品连接至运行中的设备時,如果该设备的说明书未予说明,请勿打开或关闭本产品电源。
- 部分输入接口必须在特定条件下方可使用,请参考本产品之详细操作指南。(□1)
- 小心不要将连接器连接至错误的端口。

# 连接电源

- 1. 将电源线与电源适配器连接
- 2. 将电源适配器的 DC 直流电源端子插入本产品之 DC 24V 电源插孔。
- 3. 将电源线插头牢牢插入插座。插入电源插头数秒钟后,电源指示灯将亮起呈稳定的红色。

电源按钮 / 指示灯





#### **小警告**

- 连接电源线时,请格外小心,因为不正确或不妥当的连接可能会导致火灾和/或电击。
  - 切勿用湿手触摸电源线。
  - 只能使用本产品附带的电源线与电源适配器。如果电源线与电源适配器损坏,请与经销商联系,重新换正确的电源线与电源适配器。切勿改动电源线与电源适配器。
  - 只能将电源线插入电压与电源线中相符的插座。电源插座应该位于本产品附近以便使用。若要彻底分开,请拔下电源线。
  - 不要把电源分配给多个设备。这样做可能会使插座和连接器过载,使连接松动,或造成火灾、触电与其他事故。
  - 使用适当的电源线将本产品附带的电源适配器的 AC 端子连接到建筑物的电源插座。
  - 如果本产品包装盒内附带多根电源线,请使用与插座形状相匹配的电源线。

#### 通告


• 本产品附带的电源适配器设计用于相间电压为 220-240V 的 IT 供电系统。

### 设定

本产品之输入端口分配必须由管理员在 Web 浏览器中进行设置。请参考本产品之详细操作指南。(41)

# 连接

连接其他设备时,请确保本产品的电源已关闭。 请参考本说明书之关闭电源章节。 请参考以下接线示意图。



#### 连接(续)

#### **企注意**

- 将本产品连接至网络前, 务必获得网络管理员的同意。
- •请勿将 WAN/LAN 端口连接到任何有可能产生过高电压的网络。
- 连接错误可能导致故障。 请小心连接电缆。
- 连接前请先关闭音箱和本产品电源,以避免意外声响。
- 使用放大音箱时请注意调节音量。

#### 通告

- 在连接之前,请阅读用在本产品上的设备说明书。
- LAN 电缆的长度必须等于或小于 100 米。电缆长度超过 100 米时,可能会导致视频 / 音频质量下降或网络通信出现故障。
- BNC 电缆的长度必须等于或小于 100 米。
- 连接到 WAN / LAN 端口时请使用 RJ-45 连接器。
- 请参考本产品之详细操作指南。

# 基本操作

# 开启电源

- 1. 电源线须正确、牢固地与本产品、电源适配器和电源插座相连接。
- 2. 请确认电源指示灯亮起呈稳定的红色。
- 3. 按下本产品的 (开启/关闭电源)按钮。





按下电源按钮本产品将自动启动。

电源启动过程指示灯将呈红灯和绿灯交替闪烁。当电源完成开启时,指示灯将停止交替闪烁,呈稳 定的绿色。

#### 通告

- 开启本产品电源之前,请先开启与本产品连接的其他装置的电源。
- 关闭电源后,若电源指示灯已呈稳定的红色,则可以再次打开电源。

# 关闭电源

- 1. 按下本产品的 (开启/关闭电源)按钮。"关机?"的确认信息将显示约10秒时间。
- 2. 当讯息出现时,请再按一次(开启/关闭电源)按钮。电源关闭时指示灯将呈红灯和绿灯交替闪烁。当电源完成关闭时,指示灯将停止交替闪烁,呈稳定的红色。

#### 电源按钮 / 指示灯



#### ⚠ 警告

- 拔下电源线插头以完全断开电源。
- 在关闭本产品电源之前,请先关闭与本产品连接的其他装置的电源。


# 规格

项目	规格
品名	智能录播一体机
型 <del>号</del>	MA-XL1
外形尺寸	約 430 mm(宽) x 60 mm(高) x 206 mm(深) (不含机柜支架) 約 480 mm(宽) x 60 mm(高) x 206 mm(深) (含机柜支架)
重量(净重)	约 3.0 kg
电源	直流 DC: 24V/2.5A 交流 AC: 100~240V/1.5A
功率 (最大值)	60W (Max.)
使用温度 / 湿度范围	0°C ~ 40°C / 10% ~ 90% RH
WAN, LAN	10 / 100 / 1000Mbps
端口	前置 audio output 3.5 mm (stereo) mini jack x1 SDI IN 1 BNC jack x1 SDI IN 2 BNC jack x1 SDI IN 3 BNC jack x1 SDI IN 3 BNC jack x1 HDMI IN 1 HDMI connector x1 HDMI IN 2 HDMI connector x1 HDMI IN 3 HDMI connector x1 HDMI IN 4 HDMI connector x1 COMPUTER IN D-sub 15 pin mini jack x1 MONITOR OUT D-sub 15 pin mini jack x1 HDMI OUT HDMI connector x1 AUDIO IN 3.5 mm (stereo) mini jack x1 MIC IN 3.5 mm (stereo) mini jack x1 AUDIO OUT 3.5 mm (stereo) mini jack x1 AUDIO IN(L,R) 可拆卸接线端子 x1 AUDIO OUT(L,R) 可拆卸接线端子 x1 USB TYPE A USB TYPE A USB TYPE A USB TYPE A IUSB TYPE B 1 USB TYPE B x1 USB TYPE

(下一页继续)

# 规格(续)

# Front



# Back



No.	名称	功能简介
1	音量条	显示音量
2	蓝牙配对指示灯	显示蓝牙连接状态
3	USB 指示灯	显示前置 USB 装置读写状态
4	启动录像按钮	开始/暂停录像工作
5	停止录像按钮	停止录像工作
6	频道切换按钮	影像来源切换;根据设定之影像频道循环切换
7	信息按钮	<b>短按:</b> 显示信息窗口,同时会将 USB 鼠标控制权从计算机切换回本产品 <b>长按:</b> 2 秒钟將开始蓝牙装置配对
8	投影机开启 / 关闭按钮	开启 / 关闭 PJLink 兼容投影机或 Hitachi/Maxell 投影机电源
9	电源按钮	开启 / 关闭 MA-XL1 电源
10	DC 直流电源输入	直流 DC: 24V / 2.5A
11	重置按纽	长按 15 秒可将 MA-XL1 回复至出厂设定状态
12	安全条	连接商用防盗链或防盗锁

# 制造年月

### T9AW00001


└ 制造月份 : A= 一月 , B= 二月 , ... L= 十二月 ── 制造年份 : 9=2019, 0=2020, 1=2021, ...

#### 通告

- 本说明书如有更改,恕不另行通知。
- 本说明书中显示的插图仅为示意图 , 您的产品可能与插图有所不同。
- 未经明确的书面同意,不得重印、转让或复制本文件的全部或任何部分。


# Lecture Capture Station MA-XL1 User's Manual (concise) - Supplement

# **Connection**



(continued on next page)

# **Dimensions**



#### About license etc.



- HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and/ or other countries.
- THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://WWW.MPEGLA.COM

# License agreement of each software

#### **GNU GENERAL PUBLIC LICENSE Version 2, June 1991**

Copyright © 1989, 1991 Free Software Foundation, Inc.

51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

#### **Preamble**

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

#### GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language.

(Hereinafter, translation is included without limitation in the term

"modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee

- 2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
  - a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
  - b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
  - c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the

# License agreement of each software (continued)

other work under the scope of this License.

- 3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
  - Accompany it with the complete corresponding machinereadable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or.
  - b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or.
  - c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

- 4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
- 5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
- 6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
- 7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you

cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all.

For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be torefrain entirely from distribution of the Program. If any portion of this section is held invalid or unenforceable underany particular circumstance, the balance of the section is intended toapply and the section as a whole is intended to apply in othercircumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

- 8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
- 9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### **NO WARRANTY**

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

# License agreement of each software (continued)

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

program `Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989
Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

#### **END OF TERMS AND CONDITIONS**

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found

<one line to give the program's name and a brief idea of what
it does.>

Copyright © <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston,

MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright © year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items— whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the