



# Operational Description

## ***Section 1 : Overall installation procedure***

1. Connect fingerprint identification device or wheel mouse to the system.(for mouse, USB port must be connected in advance of PS/2)
2. A message of inserting CD will appear by operation of Window 98 Plug & Play when it senses new hardware.
3. Insert 'Zimuni 2.0' CD into CD ROM Drive, and then follow hardware installation wizard to install fingerprint identification device or wheel mouse.
4. When driver installation is finished, run setup.exe file to install Zimuni 2.0 program.
5. Restart the system after installation, and logon with name and password typed during installation.
6. Authentication method can be changed to fingerprint, password or both by using the Zimuni administrator.

## ***Section 2 : Connection***

1. Connect to **USB Port – Connect this first**
2. Connect to **PS/2 Port – Connect this second**

## ***Section 3 : Device driver Installation***

1. Click <Next> in the 'Add New Hardware Wizard' window.
2. Select<Search for the best driver for your device > and then click 'Next'.
3. Insert CD and select 'CD ROM Drive' and then click 'Next'.
4. Installation will start if you click 'Next'.
5. Click 'Finish'.

***Section 4 : Fingerprint Mouse Installation***

1. After program installation, a window asking you to install wheel mouse will be appeared. Click 'OK', and then the installation will be proceeded.
2. Select 'English' and click 'Next'.
3. You can install mouse application, mouse driver or both. If you want only application, select 'Mouse application' If you want only mouse driver, select 'mouse driver' and if you want both, select 'Both', Click 'Next'.
4. Select 'PS2 Port' and click 'Next'.
5. Click 'Next' if you want to install in said folder, if not, click 'change folder'.
6. The system will restart by clicking 'Finish' button and all fingerprint identification mouse installation process will be completed.