

## REMOTE CONTROL MANUAL (FOR MOBILE)




## How To Use:


- \*Open the phone camera and click (photo button)to take a picture.
- \*Turn on any video camera, click (photo button) to shoot the video. if it doesn't work, follow this steps:
- 1.Hold the adjust button for 3 seconds ,then the blue light flashing to start adjust.
- 2.Click any direction button(up/down/left/right) to adjust the screen dot/pointer position.
- 3.Click the adjust button to finish.


Finally, Click the adjust button to shoot the video successfully.











The iPhone needs to turn on the auxiliary touch and tracking sensitivity (Setting- Auxiliary functions - Touch -Open auxiliary touch - Glide to find sensitivity- Slightly pull the progress bar - Click the photograph button until the small dot is centered)

## FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority

to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.