3. Press the SEND button on the screen or the key on the steering wheel controller to connect the call.

Note

- Pressing and holding the SEND button or key will redial the most recent number.
- You can delete digits by pressing the Delete or END button on the screen.
- The Delete button will delete one digit at a time while the END button will erase all digits.
- When placing international calls, press and hold the " * ". A " +" sign is displayed, allowing you to place an international call.

Contact list

1. Downloading contact list (from mobile phone)

You can store a list of names and phone numbers in the system contact list. The contact list can support up to 2,000 entries. The contact list is only available when a handset device is connected to the handsfree system. In some phones, the system will automatically download contacts upon pairing.

1. While in Phone mode, press the Contacts button.

2. Press the spell you wish to find.

3. Press the Download button.



4. The contacts from the currently paired handset device will automatically be downloaded.

Note

- You can search your contacts to conveniently find the desired person.

Searching your contacts

If you have many contacts downloaded in the device from your handset device, you can make searches of your contacts to conveniently find the desired person.

1. By alphabet

1. While in Phone mode, press the Contacts button.

2. Press the spell you wish to find.

3. Press the Sort by button.

4. Press the spell you wish to find.

5. Press the contact you want to connect the call.

2. By name

1. While in Phone mode, press the Contacts button.

2. Press the spell you wish to find.

3. Press the Search button.



4. Press the Search by name .

5. Enter the name you wish to find and press the Done button.



6. Press the contact you want to connect the call.

Note

- When searching contacts by name, you do not need to enter the entire name to conduct the search.

3. By number

1. While in Phone mode, press the Contacts button.

2. Press the spell you wish to find.

3. Press the Search button.



4. Press the Search by number button.

5. Enter the number you wish to find and press the Done button.
6. Press the contact you want to connect the call.

Note

- When searching contacts by number, you do not need to enter the entire number to conduct the search.

Checking missed calls

1. While in Phone mode, press the Recent Calls button.

2. Press the Sort by button.



3. Press the Missed button.

4. The list of missed calls will be displayed.

Favorites

1. Placing a call by favorites

1. While in Phone mode, press the Favorites button.



2. Select the contact you want to call from the list.

Note

- To save a favorite, contacts should first be downloaded.
- Contact saved in Favorites are not automatically changed even if the information was changed in the mobile phone. In this case, delete it and save the new information.

2. Adding favorites

1. While in Favorites screen, press the Add button.



2. Select the contact you want to add from the list.



3. Press the ★ button to add favorite.

3. Deleting favorites



1. While in Favorites screen, press the Edit button.

2. Select the contact you want to delete from the list.
3. Press the Delete button.

SMS

1. Downloading SMS messages (from mobile phone)

When a mobile phone is paired with the system, unread messages will automatically be downloaded to the system. While you will not be able to check SMS messages through the system due to legal regulations, the system will read back messages for you for added convenience. The SMS read back is also possible when the vehicle is in motion.

2. Checking an SMS message

1. Press the key on the steering wheel.
2. Say the command 'Read SMS'.
3. The system will read back the new message.

Note

- To listen to the message again, say 'Read again'. To listen to the next message, say 'Next'. To send a reply, say 'Reply'. To call the sender, say 'Call'.
- When a mobile phone has been paired with the system, new incoming messages will automatically be notified through the system.

- When the notification window is displayed, press the Yes button to check the new incoming message.

3. Sending an SMS message (Custom Messages)

The UVO system allows you to respond to incoming messages through voice commands.

1. After listening to a received message, say 'Reply'.
2. The UVO system will provide information pertaining to the 6 Custom Messages.
3. Select the desired message to send a response.

Note

- You can modify custom messages through Phone Settings.
- The SMS function may not be supported in some handset devices.

4. Editing Custom Messages

1. In the 'Phone' Screen, press the Settings button.
2. Press the Edit button next to the Custom Messages menu.
3. From the 6 messages, select the message you wish to edit.

Caution

- The Editing Custom Messages feature is supported only when the vehicle is parked. If you need to edit custom messages, first park your vehicle in a safe and legal location.

Switching the call

1. Switching the call between handsfree and handset device

When you receive an incoming call, you have the option of using the handsfree or talking privately by using the handset device.

2. Transferring the handsfree call to your Handset device

1. After pressing the Accept button for an incoming call, the following screen will be displayed.



2. Press the Private button. The call will be transferred to the handset device.

Note

- Accepting a call with the handset device will automatically connect the call in Private mode.

3. Transferring a call on your Handset device to handsfree

1. If an incoming call is accepted with the handset device, the call will be connected with the handset device while the UVO system will display the following screen.
2. Press the Use handsfree button to transfer the call to the handsfree.



Phone settings

Setting Phone Volume

1. Press the PHONE key.

2. Press the Settings button.



3. Use the ◄, ► buttons to control the volume to the desired level.

Note

- Press the Default button to restore the default setting.
- Call volume can be operated separately from the audio volume, allowing you to change the call volume without changing the audio volume.

SMS

This feature allows you turn the SMS feature on or off within the system. When turned on, the SMS feature will download unread incoming messages to provide a read back of new messages.

1. While in Phone Settings, press the Settings button.



2. Press the On or Off button next to the SMS menu.

Note

- Press the Default button to restore the default setting.
- Changes are saved as they are made. In other words, once you change a setting, the new setting will become saved.

Changing passkey

The passkey is the authentication code needed whenever you pair a new handset device.

1. While in Phone Settings, press the Settings button.



2. Press the 0000 button next to the passkey menu.



3. Input the new passkey and press the Done button to save.

Note

- The default passkey is “0000” .
- The passkey can be set only when the vehicle is parked.

Mobile Phone Compatibility

Depending on the manufacturer, product and product specification, some mobile phones functions may not be supported or may not operate to specification. Carefully read the cautions listed below.

Caution

- The occurrence of problems upon using mobile phones may be caused by the mobile phone and not by the Audio unit.
- Even mobile phones which support *Bluetooth*® wireless technology function may not operate properly if the mobile phone connection has been locked. Release the connection lock and try connecting the mobile phone with the system again.
- The mobile phone battery icon and signal strength icon may not be properly displayed depending on the type of mobile phone.
- Call waiting is supported only when connected mobile phones support this feature. The call waiting pop-up may not be displayed in some mobile phones.
- Streaming audio mode will operate only when a *Bluetooth*® wireless technology enabled phone has been connected. Connecting or disconnecting a *Bluetooth*® wireless technology enabled phone while audio streaming is operating will stop music play.
- The audio streaming function may not be supported in some mobile phones.
- The phonebook may take a prolonged period of time to download or may not operate in some mobile phones.
- The quality of *Bluetooth*® wireless technology handsfree calls may differ depending on the mobile phone.
- SMS read back function may not be supported in some handset devices.

PART 4 VOICE COMMANDS

Conditions for voice command system

The voice control system includes a special handsfree microphone mounted above the driver's seat of your car which helps filter out ambient noise and helps allow you to operate system features through voice commands. There are still a few points you should observe to help reduce noise interference.

- Keep doors, windows and the sunroof closed to help avoid noise interference from outside the car. Voice command performance can be improved if the cabin environment is quiet.
- Press the voice recognition button and say the voice command after the sound of the beep.
- Speak continuously and at normal volume, avoiding unnatural emphasis and pauses between words.
- Avoid causing background noise in the car while you are speaking, and ask your passengers not to speak while you are giving voice commands.
- As the handsfree microphone is positioned to pick up the driver's voice, commands by other occupants may be understood with less accuracy, and passengers are advised to use the handset when making calls.

The Kia Voice Recognition System may have difficulty understanding some accents or uncommon names. When using Voice Recognition to place a call, speak in a moderate tone, with clear pronunciation. To help maximize the use of Voice Recognition, consider these guidelines when storing contacts:

- Do not store single-name entries (e.g., “Bob”, “Mom”, etc.). Instead, always use full names (including first and last names) for these contacts
- Do not use special characters (e.g., ‘@’, ‘-’, ‘*’, ‘&’, etc.)
- Do not use abbreviations (i.e., use “Lieutenant” instead of “Lt.”) or acronyms (i.e., use “County Finance Department” instead of “C. F. D.”. Be sure to say the name exactly as it is entered in the contacts list.

Operating Voice Command

Using Voice Command

1. Press the key on the steering wheel controller. A display will be shown at the top of the screen followed by a “Please say a command after the beep” system comment.
2. Once the Listening.... icon becomes displayed, say the desired voice command (ex: “What's Playing”)

Note

- Press the key shortly to interrupt the system command feedback and enter a voice command.
- To terminate the voice control system, either say “Exit” or press the key for over 0.8 second.
- The system voice comment “Please say a command after the beep” will not be stated when the Command Feedback option is turned off.
- For more information on the various voice commands supported by the system, refer to the “Command Help” or the “Voice Command List” section.

Voice Command Help

The Voice Command Help section provides you with lists of commands that can be used in each mode, adding ease and convenience using voice commands.



1. Press the Voice button.



2. Press the Help button.



3. Press the mode to view a list of related Voice Commands.

Note

- The “help” command can be used even while voice recognition dialogue is operating. At such time, help instructions appropriate to the state of the dialogue will be provided.

Turning Command Feedback On and Off



1. Press the Voice button.



2. Press the On or Off button next to the Command Feedback menu.

Note

- Press the Default button to restore the default setting.
- Changes are saved as they are made. In other words, once you change a setting, the new setting will become saved.

Adjusting Voice Command Volume



1. Press the Voice button.

2. Use the ◀, ▶ buttons to adjust the voice command volume.
3. Press the ⮌ button to return to the Setup screen.

Note

- Press the Default button to restore the default setting.
- Changes are saved as they are made. In other words, once you change a setting, the new setting will become saved.

Voice Command List

The voice commands for this system are divided into Global commands and Local commands.

- Global commands (●) : Commands that operate in all modes.
- Local commands (○) : Commands that operate only in corresponding modes or when screens of corresponding modes are displayed.

Command List - General Commands

Command		Operation
●	Exit / Quit / Cancel	Terminate the voice control system
○	Go back	Returns to the previous step.
●	Repeat	Repeats the system prompt.
●	Help	Provides instruction on the voice command necessary for the current situation.
●	Voice command feedback {on, off}	Turns command feedback on/off.
●	Tutorial	Provides guidance on how to use voice recognition and Bluetooth connections

Command List - Audio Commands

1. FM/AM Radio

	Command	Operation
●	Radio	Plays the most recent frequency for the most recent band
●	Radio {FM, AM}	Plays the most recent frequency for the corresponding Band.
●	Radio {87.5 - 107.9} FM	Plays the selected FM band frequency.
●	Radio {530 - 1710} AM	Plays the selected AM band frequency.
●	Radio FM preset {1 - 12}	Plays the selected FM preset.
●	Radio AM preset {1 - 6}	Plays the selected AM preset.
○	What's playing?	Reads back Radio station information.

2. SIRIUS™

	Command	Operation
●	SIRIUS™	Plays the most recent SIRIUS™ channel.
●	SIRIUS™ preset {1 - 18}	Plays the selected SIRIUS™ preset.
●	SIRIUS™ channel {0 - 223}	Plays the selected SIRIUS™ channel.
●	SIRIUS™ channel {name}	Plays the channel searched through the SIRIUS™ channel name.
●	SIRIUS™ category {name}	Plays the channel searched through the SIRIUS™ category name.
○	What's playing?	Reads back SIRIUS™ channel information.

3. MEDIA

	Command	Operation
●	Play {zune®, iPod®, USB, CD}	Plays the selected media mode.
●	Play {Bluetooth® audio, AUX}	Plays the selected media mode.
●	Play artist {artist name}	Plays songs of the selected artist.
●	Play album {album name}	Plays songs of the selected album.
●	Play track {track name}	Plays the selected track.
●	Play playlist {playlist name}	Plays songs of the selected playlist.
●	Play genre {genre}	Plays songs of the selected genre
●	Play audiobook {title}	(iPod® only) Plays the selected audiobook.
●	Play podcast {podcast}	(iPod® only) Plays the selected iPod® podcast.
●	Play composer {composer}	Plays songs for the selected composer.
○	What's playing?	Reads back the current song information.
○	Repeat {on, off}	Turns the repeat feature on or off.
○	Shuffle {on, off}	Turns the shuffle feature on or off.
●	Play {CD, zune®, iPod®, USB} artist {name}	Plays songs for the selected artist in the selected media mode.
●	Play {CD, zune®, iPod®, USB} album {name}	Plays songs for the selected album in the selected media mode.
●	Play {CD, zune®, iPod®, USB} track {name}	Plays the selected track in the selected media mode.
●	Play {CD, zune®, iPod®, USB} playlist {name}	Plays the selected playlist in the selected media mode.
●	Play {CD, zune®, iPod®, USB} genre {genre}	Plays songs for the selected genre in the selected media mode.
●	Play {CD, zune®, iPod®, USB} composer {name}	Plays songs for the selected composer in the selected media mode.
●	Play iPod® audiobook {title}	(iPod® only) Plays the selected iPod® audiobook.
●	Play iPod® podcast {podcast}	(iPod® only) Plays the selected iPod® podcast.

4. JUKEBOX

	Command	Operation
●	Play JUKEBOX	Plays the JUKEBOX mode.
●	Play JUKEBOX Favorites	Plays songs of JUKEBOX Favorites
●	Play artist {artist name}	Plays songs of the selected artist
●	Play album {album name}	Plays songs of the selected album.
●	Play track {track name}	Plays the selected track.
●	Play genre {genre}	Plays songs of the selected genre
●	Play composer {composer}	Plays songs of the selected composer.
○	What's playing?	Reads back the current song information.
○	Add to favorites	Adds the current song to favorites.
○	Remove from favorites	Removes the current song from favorites.
○	Repeat {on, off}	Turns the repeat feature on or off.
○	Shuffle {on, off}	Turns the shuffle feature on or off.
●	Play JUKEBOX artist {artist name}	Plays songs of the selected JUKEBOX artist.
●	Play JUKEBOX album {album name}	Plays songs of the selected JUKEBOX album.
●	Play JUKEBOX track {track name}	Plays the selected JUKEBOX track.
●	Play JUKEBOX genre {genre}	Plays songs of the selected JUKEBOX genre.
●	Play JUKEBOX composer {name}	Plays songs of the selected JUKEBOX composer.

5. PANDORA Radio

	Command	Operation
●	Play PANDORA	Plays the PANDORA Radio mode
●	Play PANDORA Station {station name}	Plays the station searched through the PANDORA Radio station name.
○	Shuffle	Turns the shuffle feature on
○	Skip	Moves to the next song.
○	Thumbs Up	Approves the song and keep it in your playlist.
○	Thumbs Down	Disapproves the song and prevents that song from playing again.
○	Bookmark this track	The current track is bookmarked on the currently connected device.
○	Bookmark this artist	The current artist is bookmarked on the currently connected device.
○	What's playing	Reads back the current song information.

Command List - UVO eServices Commands(Optional)

	Command	Operation
●	eServices	Displays UVO eServices mode.
●	Roadside Assist	Makes call to Roadside Assist agent.
●	eServices Guide	Receive guidance on methods of using UVO eServices.
●	Vehicle Diagnostics	Starts the Vehicle Diagnostics process.

Command List - Phone Commands

Command		Operation
●	Call {name}	Calls the desired name.
●	Dial {number}	Dials the desired number.
●	Call {name} at home	Calls the desired person at the home number.
●	Call {name} in office	Calls the desired person in the office number.
●	Call {name} on mobile	Calls the desired person on the mobile number.
●	Call {name} on Other	Calls the desired person on the other number
●	Dial by number	Starts dial by number operation.
●	Call a contact	Starts call by name operation.
●	Phone	Turns on Phone mode screen.
●	Dial international	Starts international call operation.
●	Phone connections	Turns on Phone connections screen.
●	Phone settings	Turns on Phone settings screen.
●	SMS	Reads back new SMS message for *Bluetooth*® wireless technology SMS capable phones.
●	Read SMS	Reads back new SMS message for *Bluetooth*® wireless technology SMS capable phones.
●	Recent calls	Turns on Recent Calls list screen.
●	Redial	Calls the last dialed call.

PART 5. UVO eServices (Optional)

Using UVO eServices and Cautions

- Download the UVO eServices App and install it on your smartphone. The app can be downloaded from the Apple App Store or Google Play.

- Pair and connect your smartphone with the vehicle. For information on connecting your Bluetooth® device, refer to the smartphone user's manual and instructions on the Phone Help screen on your radio. Up to 5 Bluetooth devices can be paired with the vehicle.

- Login and activate the UVO eServices App on your smartphone.

- UVO eServices is fully compatible within some smartphones but may not operate properly within incompatible smartphones.
  To view the list of compatible smartphones, please visit MyUVO.com.

- Communication between the vehicle and smartphone app may temporarily disconnect depending on the phone state.

- If the feature is not operating properly, you may need to reset the UVO eServices App or the smartphone to try again according to the following steps.
  1. Try again
  2. Reset smartphone app
  3. Re-connect Bluetooth®
  4. Reset smartphone
  5. Delete Bluetooth® device and pair again

- Some services use the customer's mobile phone data plan for data communication. and thus the features will function in accordance with the cellular plan.

- Use of the most up-to-date app version is recommended.

- For smartphone related inquiries, please visit MyUVO.com.

Warning

- Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

The 911 Connect feature may not operate in the following situations.

- When the vehicle ignition is not turned on
- When the phone Bluetooth® feature is set to off
- When the phone Bluetooth® cannot be connected or becomes disconnected
- When there are no phones paired with the vehicle
- When cellular service is unavailable
- When the power turns off due to phone power (battery) issues
- When a Bluetooth® device without phone feature support has been connected, such as an MP3 device
- When the system is booting
- When the system power supply is unstable
- When the attempted call is blocked due to user operations
- When the 9-1-1 call is unstable due to phone or other communication network issues
- When the call feature is not operating due to phone settings set by the user
- When the phone cannot be controlled via Bluetooth® due to phone specifications or characteristics

About UVO eServices

UVO eServices provides the following features through *Bluetooth*® wireless technology communication between the vehicle and your Smartphone.

UVO eServices is compatible with many popular smartphone devices. Please see MyUVO.com for phone compatibility.

UVO eServices is an optional feature available in select models, on select trims.

Name		Details
1	911 Connect	If an airbag deploys, your vehicle can automatically initiate a call to 9-1-1 and sends your vehicle's location information to the 9-1-1 Operator.
2	Roadside Assist	If a diagnostic issue exists, you can connect with a Roadside Assist agent.
3	Vehicle Diagnostics	Informs you if certain diagnostic issues are found in your vehicle. If an issue is found, you can contact a call center through Roadside Assistance or reserve an appointment with your preferred Kia dealer through Schedule Service.
4	Parking Minder	Save the location of your parked vehicle on your UVO eServices app. You can check where your vehicle is parked through the UVO eServices App on your smartphone.
5	My Car Zone	Keep track of pre-defined triggered alerts such as Speed Alert or Curfew Alert from the My Car Zone feature.
6	eServices Guide	Receive guidance on how to use UVO eServices.

To use UVO eServices, the following conditions must be met.

1. The UVO eServices smartphone app must be installed and you must log in using your MyUVO account credentials.
2. The smartphone must be connected via *Bluetooth®* wireless technology.
3. Once this is complete, eServices must be activated (from the eServices Settings screen).

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.

24-hour Roadside Assistance is a service plan provided by Kia Motors America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. For access to Enhanced Roadside Assistance, a connected mobile phone via Bluetooth® within the cellular service coverage area is required.

Vehicle Diagnostics do not take the place of regularly scheduled maintenance. Feature checks powertrain, chassis, and airbag systems only. For factory-recommended maintenance schedule, see the Maintenance Feature of UVO eServices or the Owner's Manual.

911 Connect activates after an airbag deployment. Feature requires a connected mobile phone via Bluetooth®. Dependant on cellular service coverage.

Warning

- Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Before using UVO eServices

Installing the UVO eServices App on your Smartphone

1. Download and install the UVO eServices App on your smartphone.
   The app can be downloaded from the Apple App Store or Google Play.
2. Register your vehicle and account at MyUVO.com.
   Note: MyUVO.com is accessible from your smartphone's browser.
3. Start the UVO eServices App on your smartphone and log in.

Connecting *Bluetooth*® wireless technology

1. Press the PHONE key on the UVO eServices system.



2. Press the Connections icon on the touch screen.
3. Press the Add Device button to display the Add Device screen.

4. Turn on the *Bluetooth*® wireless technology feature on your smartphone's Bluetooth® settings screen.
5. Wait for "KIA MOTORS" to appear on your smartphone's Bluetooth® settings screen.
6. Select "KIA MOTORS" from your phone and enter the passkey shown on the touch screen. The default passkey is "0000".

If your phone supports SSP (Secure Simple Pairing), confirm the passkey on your phone.

Note

- To learn more about *Bluetooth®* wireless technology features, refer to the 'PART 3 PHONE' section.

Activating UVO eServices

1. Press the eServices key.

2. Press the Settings icon on the touch screen.



3. Press the Activate button on the touch screen.



4. After reading the UVO eServices terms of use displayed on the touch screen, press the Activate button.
   Before pressing the Activate button, ensure that you are running UVO eServices app on your smartphone and are logged in.



5. After pressing the Activate button on the touch screen, the UVO eServices activation process will begin.

6. Once UVO eServices activation is complete, 'UVO eServices activated' will be displayed at the bottom of the UVO eServices main screen.

911 Connect

If an airbag deploys, your vehicle can automatically initiate a call to 9-1-1 and will read your vehicle's location information to the 9-1-1 Operator.

The 911 Connect feature is available only when the mobile phone is connected via *Bluetooth®* wireless technology. By default, this feature is turned off. To turn it on, you must turn it on in the eServices Settings menu. By enabling this feature, you are agreeing the 911 Connect terms of use.

An * icon is displayed at the top of the touch screen as shown below when 911 Connect is enabled and a mobile phone is connected via *Bluetooth®* wireless technology.

Note

- For more information on setting the 911 Connect feature, refer to '911 Connect Setting'.

Initiating a 9-1-1 Call

1. If an airbag deploys, the following screen is displayed and a call is automatically placed to 9-1-1 after 10 seconds.



2. Once a call is connected with a 9-1-1 Operator, it is possible to request emergency services to be dispatched to your location.

3. The 9-1-1 Operator may request information on the current location of your vehicle. When the 9-1-1 Operator requests your vehicle location, the following icon is displayed on the screen and the vehicle location is automatically sent to the 9-1-1 Operator.



4. If the 9-1-1 Operator attempts to call the driver again, the following icon is displayed and allows the driver to speak with the 9-1-1 Operator.



Roadside Assist

If a diagnostics issue is found, you can connect with a Roadside Assist agent.

Enhanced Roadside Assistance feature can be used only when your phone is connected via *Bluetooth®* wireless technology.

1. Press the eServices key.

2. Press the Roadside Assist icon on the touch screen to connect with a Roadside Assist agent.



Vehicle Diagnostics

Conducting Vehicle Diagnostics

Vehicle Diagnostics is available only when the ignition is turned on and the vehicle is parked. It also requires that UVO eServices is activated, and the Phone is connected through *Bluetooth*® wireless technology before starting Vehicle Diagnostics.

1. Press the eServices key.

2. Press the Vehicle Diagnostics icon on the touch screen.



3. The Vehicle Diagnostics process will begin. When a diagnostics check is in progress, keep the vehicle in park with the ignition on. To cancel diagnostics, press the Cancel button on the touch screen or any key.



4. Once vehicle diagnostics is complete, the diagnostic results are displayed on the screen.

5. If diagnostic issues are found, press the Send Report button to send the diagnostics results to your MyUVO account or press the Schedule Service button to schedule an appointment with your preferred or nearby Kia dealer.

6. When scheduling an appointment using the Schedule Service button, pressing the Preferred Dealer button will allow you to request an appointment with your preferred Kia dealer and send your vehicle's diagnostics information.
   Pressing the Nearest Dealer button will allow you to request an appointment with the nearest Kia dealer and your vehicle's diagnostics information.

7. Even if diagnostic issues are not found after Vehicle Diagnostics, it is recommended that you send the diagnostic results to your MyUVO account.
   Press the Send Report button to send the diagnostics results to your MyUVO account.

Scheduled Diagnostics

If you have set up Scheduled Diagnostics on your UVO eServices app, a vehicle diagnostics check will automatically start on the day you selected.

1. On the day of the Scheduled Diagnostics, the following window will be displayed.



2. Press the Yes button on the touch screen to proceed with a diagnostics check.

Note

- If you didn't use eService via smartphone app frequently, scheduled diagnostics may start at date you didn't set.

Conducting Auto Diagnostics

If a critical diagnostics issue with your vehicle's powertrain is detected, the vehicle will automatically start the diagnostics.



Parking Minder

Sending Parking Location

The location where your vehicle is currently parked can be sent to your smartphone.

The Parking Minder feature is only available when the ignition is turned on and the vehicle is parked.
Ensure that the UVO eServices system is activated and the Phone is connected via *Bluetooth*® wireless technology with the UVO eServices app running on your smartphone before using this feature.

1. After parking the vehicle, press the eServices key.

2. Press the Parking Minder icon on the touch screen to send the vehicle's location to your smartphone.

3. Once the parking location has been sent, you can view your vehicle's location from the UVO eServices app on your smartphone.



Note

- When the parking location is being sent, do not drive the vehicle or turn off the ignition.
- Parking Minder feature operates with certain smartphone devices with activation of App. Normal cellular service rates apply.

My Car Zone

My Car Zone is a feature that provides alerts and driving history for Curfew Limits and Speed Alerts set by the user.

Name	Description
Curfew Limit Alert	Curfew Limit Alerts are alerts that are triggered when a driver is driving within a pre-defined time range.
Speed Alert	Speed Alerts are alerts that are triggered when a driver exceeds the pre-defined maximum speed.

My Car Zone feature is supported only when UVO eServices has been activated.

1. Press the eServices key.

2. Press the My Car Zone icon on the touch screen.

Curfew Limit Alert

You can check the Curfew Limit Alert History for a list of past triggered curfew alerts.



1. Press the Curfew Limit Alert button on the touch screen.

2. Press the corresponding alert to view detailed alert information.

Name	Description
1 Phone	Name of phone connected upon triggered Curfew Limit
2 Alert Time	Initial alert time
3 Duration	Total duration of driving while Curfew Limit was triggered
4 Driving Time	Total driving time from turning ignition on until turning ignition off

Speed Alert

You can check the Speed Alert History for triggered speed limit alerts of the vehicle.



1. Press the Speed Alert button on the touch screen.



2. Press the corresponding alert to view detailed alert information.



Name	Description
1 Phone	Name of phone connected upon triggered speed limit alert
2 Max. Speed	Maximum vehicle speed upon triggered speed limit alert
3 Alert Time	Time from first triggered alert until last triggered alert
4 Duration	Total triggered alert time from turning ignition on to turning ignition off

To check My Car Zone alert history from your smartphone, you must first send the alert history to your MyUVO account.



1. Press the Send Data button on the touch screen.



Note

- Before using Send Data, ensure your phone is connected via *Bluetooth*® wireless technology.

eServices Guide

eServices Guide provides guidance on how to use UVO eServices.

This feature is only available when the mobile phone is connected via *Bluetooth*® wireless technology.

1. Press the eServices key.

2. Press the eServices Guide icon to receive guidance on how to use UVO eServices.



UVO eServices Settings

Within the eServices Settings screen, UVO eServices related features can be set, such as activating UVO eServices.

Warning

- Settings can not be adjusted while driving. Park the vehicle in a safe and legal location before making any changes to your Settings.

UVO eServices Activation

1. Press the eServices key and then the Settings button on the touch screen.



2. If UVO eServices has not yet been activated, press the Activate button to start the process.

Note

- For more information on UVO eServices activation, refer to 'Activating UVO eServices'.

911 Connect Setting

1. Press the eServices key and then the Settings button on the touch screen.

2. To enable 911 Connect, ensure that the On button is selected. To disable this feature, ensure the Off button is selected.



3. When enabling this feature, you must first agree to the 911 Connect terms of use. After reading the terms of use, press the Agree button on the touch screen to accept.

Trip Info Sync Reminder Setting

UVO eServices sends trip information (i.e. Driving Distance, Driving Speed, Driving Time and etc.) to MyUVO.com regularly.

Trip Info Sync Reminder feature is the function that give a notice when trip information needs to be transmitted to MyUVO.com.

1. Press the eServices key and then the Settings button on the touch screen.

2. To enable Trip Info Sync Reminder, ensure that the On button is selected. To disable this feature, ensure the Off button is selected.

My Car Zone Setting

This feature is used to set My Car Zone (Curfew Limit, Speed) alert conditions.

My Car Zone Setting is unavailable when UVO eServices has not been activated.

1. Press the eServices key and then the Settings button on the touch screen.



2. Press the My Car Zone setting button.



3. The PIN must be entered to use My Car Zone Settings.

4. Press the Change button to change Curfew Limit and Speed Alert conditions.



Within Curfew Limit Alert Settings, you can set the Start and End Time for Curfew Limit. You can also set alert interval of Curfew Limit.

To enable Curfew Limit Alert, ensure that the On button is selected.



Within Speed Alert Settings, you can set the vehicle speed limit. You can also set alert interval of the speed limit.

To enable Speed Alert, ensure that the On button is selected.

Change PIN

This feature is used to change the PIN to enter My Car Zone Settings.

1. Press the Change button of PIN.



2. Enter new 4 digit PIN.



3. After changing the PIN, press the Change button to transmit the new PIN to your MyUVO.com account.

Time Zone Setting

This feature is used to set Time Zone for My Car Zone.



1. Press the Time Zone setting button.



2. Select the Time Zone that you want to set.

Daylight Saving Setting

This feature is used to set Daylight Saving Time for My Car Zone.



To enable Daylight Saving, ensure that the On button is selected.

Restore Factory Settings

This feature is used to restore all My Car Zone alert history and settings back to default state.



1. Press the Restore button.

PART 6 Rear Camera Display

Rear Camera Display

- The UVO system is equipped with a Rear Camera Display.
- The Rear Camera Display System uses an exterior camera integrated to the rear of the vehicle that sends video to the UVO system.
- Regardless of the mode you are in, placing the gear shifter is set to Reverse, or "R", will automatically display the rear view camera screen.

1. Place the transmission in Reverse " R ".



2. The Rear Camera Display will activate.

Warning

Check surroundings for your safety

- The Rear Camera Display is equipped with an optical lens necessary to help acquire a wider field of vision and may result in a display which differs from the actual distance.

Always check the rear and left/right directions when driving in reverse.

- The Rear Camera Display is not a substitute for proper and safe backing-up procedures. The Rear Camera Display may not display every object behind the vehicle. Always drive safely and use caution when backing up.

PART 7 Troubleshooting guide

Troubleshooting guide

Before thinking the product has malfunctioned

1. Errors which occur during the operation or installation of the device may be mistaken as a malfunction of the actual device.
2. If you are having problems with the device, try the suggestions listed below.
3. If the problems persist, contact your point of purchase or the nearest service center.

Problem	Function
There are small red, blue, or green dots on the screen	Because the LCD is manufactured with technology requiring high point density, a pixel deficiency or lighting may occur within 0.01% of total pixels.
The sound or image is not working	• Has the Switch for the vehicle been turned to [ACC] or [ON]? • Has the SYSTEM been turned OFF?
The sound is not working	• Has the volume been set to a low level? • Has the volume been set on mute?
When the power is turned on, the corners of the screen are dark	• The display looking somewhat darker after prolonged periods of use is normal with LCD panels. • If the screen is very dark, contact your point of purchase or the nearest service center.
Sound is working from only one speaker	• Is the position of FAL/BAL sound controls or volume adjusted to only one side?
Sound does not work in AUX mode	Is the audio connector jacks fully inserted into the AUX terminal?

Troubleshooting

Problem	Possible Cause	Solution
The power does not turn on.	The fuse is disconnected.	Replace with a suitable fuse. If the fuse is disconnected again, please contact your point of purchase or service center.
	Device is not properly connected.	Check to see that the device has been properly connected.
The sound does not work.	• The volume level is set the lowest level. • The connector is not properly connected. • The device is currently fast-forwarding, rewinding, scanning, or playing in slow mode.	• Adjust the volume level. • Check the connection state. • The sound will not work when the device is fast-forwarding, rewinding, scanning, or playing in slow mode.
The sound quality is low.	• The DISC is dirty or scratched. • Vibration is occurring from the position in which the conversion switch has been installed.	• Wipe off water or dirt from the DISC. Do not use a disc which has been scratched. • The sound may be short-circuited and the image distorted if the device begins to vibrate. The device will return to normal operation once the vibration has stopped.

Problem	Possible Cause	Solution
The USB does not work.	• USB memory is damaged. • USB memory has been contaminated. • A separately purchased USB HUB is being used. • A USB extension cable is being used. • A USB which is not a Metal Cover Type USB Memory is being used. • A HDD type, CF, SD Memory is being used. • There are no music files which can be played.	• Please use after formatting the USB into FAT 12/16/32 format. • Remove any foreign substances on the contact surface of the USB memory and multimedia terminal. • Directly connect the USB memory with the multimedia terminal on the vehicle. • Directly connect the USB memory with the multimedia terminal on the vehicle. • Use a standard USB Memory. • Use a standard USB Memory. • Only MP3,WMA file formats are supported. Please use only the supported music file formats.
The iPod® is not recognized even though it has been connected.	• There are no titles which can be played. • The iPod® firmware version has not been properly updated. • The iPod® device does not recognize downloads.	• Use iTunes® to download and save MP3 files into the iPod®. • Use iTunes® to update the firmware version and reconnect the iPod® with the device. • Reset the iPod® and reconnect with the device.

PART 8 INDEX

INDEX

0~9

911 Connect Setting 5-18

A

About iPod® 2-27
About PANDORA 2-43
About UVO eServices 5-4
About zune® 2-31
Activating UVO eServices 5-7
Adding Favorites 2-39, 3-18
Adjusting Voice Command Volume 4-5
Answering an incoming call 3-10
AUDIO CD Mode Screen and Features 2-13
Automatic Brightness Control 1-11
AUX Mode Screen 2-34

B

Before Starting PANDORA 2-43
Before thinking the product has malfunctioned 7-2
BT Mode Screen and Features 2-35
By alphabet 3-14
By Artists, Albums, Genres, Song, Composers 2-17, 2-39
By Artists, Albums, Genres, Songs, Podcasts, Composers, Audiobooks 2-29
By contact list 3-12
By dialing a number 3-12
By Folders, Artists, Albums, Genres Songs, Composers 2-24
By name 3-15
By number 3-16
By recent calls 3-11
By Songs, Genres, Albums, Artists, Playlists 2-33

C

Call waiting 3-10
Caution 9
Cautions upon handling Audio CDs 2-11
Cautions upon handling MP3 CD 2-15
Cautions upon handling USB MP3 2-20
Changing passkey 3-21
Checking an SMS message 3-19
Checking missed calls 3-17
Checking System Information 2-41
Command List - Audio Commands 4-7
Command List - General Commands 4-6
Command List - Phone Commands 4-11
Command List - UVO eServices Commands(Optional) 4-10
Common Features 2-9
Conditions for voice command system 4-2
Conducting Auto Diagnostics 5-12
Conducting Vehicle Diagnostics 5-11
Connecting a handset device 3-6
Connecting an AUX media device 2-34
Connecting *Bluetooth*® wireless technology 5-6
Connecting your iPod® device 2-27
Connecting your USB device 2-22
Connecting your zune® device 2-31
Contact list 3-13
Contacts Sync 3-21
Control Panel 1-2
Copying songs from list 2-19
Copying songs from list 2-26
Copying songs into JUKEBOX 2-18, 2-25
Copying the current song 2-18, 2-25
Curfew Limit Alert 5-14

D

Deleting a paired handset device 3-5
Deleting all files 2-42
Deleting favorites 3-18
Deleting JUKEBOX 2-41
Display Settings 1-11
Downloading contact list

(from mobile phone) 3-13
Downloading SMS messages
(from mobile phone) 3-19
E
Editing Custom Messages 3-19
Ejecting a Disc 2-13
eServices Guide 5-17
Explore CD 2-18
Explore USB 2-24
F
FADER/BALANCE 1-9
Favorites 3-17
FCC Information 8
FM/AM Mode Screens and Features 2-2
FM/AM Radio 4-7
I
Initializing the system 1-8
Initiating a 9-1-1 Call 5-8
Inserting a Disc 2-13
Inserting/Ejecting a Disc 2-13
Installing the UVO eServices App on your Smartphone 5-6
iPod® Mode Screen and Features 2-28
J
JUKEBOX 4-9
JUKEBOX Mode Screen and Features 2-37
Jump 2-10
L
Listening to an Audio CD 2-14
Listening to an MP3 CD 2-16
Listening to AUX media 2-34
Listening to JUKEBOX 2-38
Listening to music from your *Bluetooth®* wireless technology enabled device 2-36
Listening to the FM/AM radio 2-3
Listening to the SIRIUS™ radio 2-5
Listening to USB music 2-23
Listening to your iPod® 2-28
Listening to your PANDORA 2-44
Listening to your zune® 2-32
M
Manual Brightness Control 1-11
MEDIA 4-8
MP3 CD Mode Screen and Features 2-16
My Car Zone Setting 5-20
P
Pairing a *Bluetooth®* wireless technology enabled device for the first time 3-4
PANDORA MODE 2-43
PANDORA Mode Screen and Features 2-44
PANDORA Radio 4-10
Phone Mode Screens and Features 3-8
Placing a call 3-11
Placing a call by favorites 3-17
Play/Pause 2-9
Playing Favorites 2-40
Precautions upon handling USB 2-21
R
Rear camera display 6-2
Rejecting an incoming call 3-10
Resetting and Initializing UVO system 1-7
Resetting the system 1-7
REW/FF 2-9
REW/FF a song 2-36
Roadside Assist 5-10
S
Safety Symbols 8
Scanning FM/AM broadcast frequencies 2-4
Scheduled Diagnostics 5-12
Searching your contacts 3-14
Select Display Language 1-7
Selecting a broadcast frequency 2-3
Selecting a CD track 2-14
Selecting a JUKEBOX song 2-38

Selecting a SIRIUS™ channel 2-5
Selecting a song 2-36
Selecting an MP3 CD song 2-17
Selecting from MP3 list 2-17
Selecting from the list 2-24, 2-29, 2-32, 2-38
Selecting iPod® music 2-29
Selecting PANDORA station 2-45
Selecting through channel search 2-6
Selecting through manual search 2-4, 2-6, 2-14, 2-17, 2-23, 2-29, 2-32, 2-38
Selecting through preset 2-6
Selecting through SEEK 2-3, 2-5
Selecting through SIRIUS™ category list 2-7
Selecting through song Up/Down 2-17, 2-23, 2-29, 2-32, 2-38
Selecting through Track Up/Down 2-14
Selecting USB music 2-23
Selecting zune® music 2-32
Sending an SMS message (Custom Messages) 3-19
Sending Parking Location 5-13
Setting Brightness 1-11
Setting Phone Volume 3-21
Setting Priority 3-7
SIRIUS™ 4-7
SIRIUS™ Mode Screen and Features 2-5
Smart driving practices 3-3
SMS 3-19, 3-22
Sound Settings 1-9
Speed Alert 5-15
Speed Dependent Volume Control 1-10
Steering Wheel 1-4
Storing presets 2-4, 2-8
Switching the call 3-20
Switching the call between handsfree and handset device 3-20
System Power 1-6

T

The 911 Connect feature may not operate in the following situations 5-3
TONE 1-10
Touch Screen Beep 1-10
Trademark 2-27, 2-31
Transferring a call on your Handset device to handsfree 3-20
Transferring the handsfree call to your Handset device 3-20
Trip Info Sync Reminder Setting 5-19
Troubleshooting 7-3
Turn Streaming Audio On and Off 3-22
Turning Command Feedback On and Off 4-4
Turning Display On and Off 1-12
Turning System Power Off 1-6
Turning System Power On 1-6

U

USB Mode Screen and Features 2-22
Using Repeat 2-10
Using Shuffle 2-10
Using Skip 2-7
Using UVO eServices and Cautions 5-3
Using Voice Command 4-3
Using your *Bluetooth®* wireless technology Handsfree system 3-2
UVO eServices Activation 5-18

V

Viewing FM/AM Station information 2-4
Viewing SIRIUS™ channel information 2-8
Viewing song information 2-18, 2-25, 2-30, 2-33
Voice Command Help 4-3

W

Warning 9
When a mobile phone is connected 3-8
When making a call 3-8

When on a call 3-9
When receiving an incoming call 3-9

Z

zune® Mode Screen and Features 2-31

UVO

Powered by Microsoft

A9EUF10

UVO SYSTEM USER'S MANUAL

SEDONA

KIA The Power to Surprise

Congratulations on the Purchase of your new UVO system!

Your new UVO system allows you to enjoy various audio and multimedia features through the main audio system.
For the latest information about this product or other Kia products and accessories, visit http://www.Kia.com
Please read this manual to get the full benefit of the system.
These operating instructions are designed to help ensure that you can operate the UVO system in a convenient way.
We recommend that this manual be kept in the car so that it will be easier for you to find information in case of an emergency.
If you cannot find the information you need in this manual or in the "Troubleshooting" section, your local authorized retailer will be pleased to help you with the system or operations.
Kia motors recommends the use of only parts and accessories that have been tested and approved by Kia motors in terms of function, safety and suitability.

iPod®

iPod®, iPhone® and iTunes® are registered trademark of Apple, Inc.

Bluetooth®

The *Bluetooth®* word mark and logos are registered trademarks owned by *Bluetooth®* SIG, Inc. and any use of such marks by Kia is under license.
A *Bluetooth®* enabled cell phone is required to use *Bluetooth®* wireless technology.

Microsoft®

Microsoft is a registered trademark of Microsoft Corporation in the United States and/or other countries.

zune®

zune® is a registered trademark of Microsoft Corporation in the United States and or other countries.

SIRIUS

Sirius™, XM and all related marks and logos are trademarks of Sirius XM Radio Inc.

SIRIUS Bluetooth® MP3 COMPACT disc DIGITAL AUDIO

Copyright(c) 2011 Kia motors. All Rights Reserved.
Warning: The making of unauthorized copies of copy-protected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offense. This equipment should not be used for such purposes.

Table Of contents

Controls and Features 2

Sound Settings 6

Display Settings 7

Listening to the FM/AM radio 8

Listening to the SIRIUS™ radio 10

Listening to an Audio CD 11

Listening to an MP3 CD 12

Listening to USB music 14

Listening to music from your *Bluetooth*® wireless technology enabled device 16

Listening to JUKEBOX 17

Pairing a *Bluetooth*® wireless technology enabled device for the first time 19

Answering an incoming call 20

Placing a call 21

SMS 23

Operating Voice Command 24

Voice Command List 25

Control Panel

※No Infinity will be shown if the exterior Amplifier feature is not supported.

1 DISC EJECT

Ejects the inserted disc.

2 FM/AM

Turns on FM/AM mode. Each press of the FM/AM key will change the band in the order of FM → AM → FM.

3 SAT

Turns on SIRIUS™ mode.

4 MEDIA

Turns on MEDIA mode. Each press of the MEDIA key will change the mode in the order of CD → USB/iPod®/zune® → JUKEBOX → AUX → BT Audio → PANDORA → CD.

5 POWER/VOL

Push : Turns Power On/Off. Dial : Turns Volume Up/Down.

6 ∨ **SEEK/TRACK** ∧

Short (under 0.8 seconds)

In FM/AM mode, automatically searches and plays the previous or next frequency.

In SIRIUS™ mode, automatically searches and plays the previous or next channel.

In MEDIA mode (CD, MP3, USB, iPod®, zune®, BT AUDIO), plays the previous or next track, song, or file.

In PANDORA Radio, PANDORA Radio skip (Seek up).

In JUKEBOX mode, plays the previous or next track.

Long (over 0.8 seconds)

In FM/AM mode, quickly moves through the frequencies when the button is pressed and held. Once released, automatically searches and plays the previous or next frequency.

In SIRIUS™ mode, quickly moves to the previous or next channel.

In MEDIA mode (CD, MP3, USB, iPod®, zune®, BT AUDIO), REW/FF the current track, song, or file.

In JUKEBOX mode, REW/FF the current track.

7 ∨ **CATEGORY** ∧

In SIRIUS™ mode, moves to the previous or next SIRIUS™ category.

8 **TUNE/ENTER**

In FM/AM mode, turn the knob to manually search for frequencies.

In SIRIUS™ mode, turn the knob to manually search for channels. Press the knob to receive the selected channel.

In MEDIA mode (CD, MP3, USB, iPod®, zune®), turn the knob to manually search for the previous or next track, song, or file. Press the knob to receive the selected track, song, or file. In PANDORA Radio, searches PANDORA Radio stations.

In JUKEBOX mode, turn the knob to manually search for the previous or next track. Press the knob to receive the selected track.

9 **SETUP**

Displays SETUP mode.

10 **PHONE**

Displays *Bluetooth*© wireless technology Phone mode.

11 **eServices(Optional)**

Displays UVO eServices mode.

12 **JUKEBOX**

Displays JUKEBOX mode.

13 **DISP**

Turns off the screen.

14 **RESET**

Reset the system to be used if system is acting abnormally.

Steering Wheel



1 ∨ **SEEK/TRACK** ∧

Short (under 0.8 seconds)

In FM/AM mode, automatically searches and plays the previous or next preset frequency.

In SIRIUSTM mode, automatically searches and plays the previous or next preset channel.

In MEDIA mode (CD, MP3, USB, iPod®, zune®, BT AUDIO), plays the previous or next track, song, or file.

In PANDORA Radio, PANDORA Radio skip (Seek up).

In JUKEBOX mode, plays the previous or next track.

Long (over 0.8 seconds)

In FM/AM mode, quickly moves through the frequencies when the button is pressed and held. Once released, automatically searches and plays the previous or next frequency.

In SIRIUS™ mode, quickly moves to the previous or next channel.

In MEDIA mode (CD, MP3, USB, iPod®, zune®, BT AUDIO), REW/FF the current track, song, or file.

In JUKEBOX mode, REW/FF the current track.

2 **+ VOLUME -**

Turns Volume Up/Down.

3 **MODE**

Short (under 0.8 seconds)

Changes the mode. Each press will change modes in the order of FM → AM → SIRIUS™ → CD → USB/

iPod®/ zune® → JUKEBOX → AUX → BT Audio → PANDORA → FM.

Long (over 0.8 seconds)

While the system is off, turn the system on.

While the system is on, turn off the system.

4 **MUTE**

Mutes the sound.

5 **Voice Command**

Short (under 0.8 seconds)

If Voice recognition is off, turns on Voice recognition.

If system is speaking, interrupts speaking and enters listening mode.

Long (over 0.8 seconds)

If Voice recognition is on, turns off Voice recognition.

6 **SEND (*Bluetooth*® wireless technology Phone)**

Pressing this key will receive an incoming call. If the Audio is on, the *Bluetooth*® wireless technology phone screen will be displayed.

When a SMS message is received, reads back message.

7 **END (*Bluetooth*® wireless technology Phone)**

Pressing this key will reject an incoming call. If pressed during a call, the current call will be ended.

When a SMS message is received, ignores message.

Sound Settings



Press the Sound button on the main screen of each audio mode (FM/AM, SIRIUS™, MEDIA, PANDORA Radio, JUKEBOX) to enter Sound Setup.

1. FADER/BALANCE

1. Press the Fader/Balance setting button.

2. Use the ▲, ▼, ◀, ▶ buttons to make adjustments to the sound position.
3. Press the ⮌ button to return to Sound Setup.

Note

- Press the Default button to restore the default setting.

2. TONE

1. Press the Tone setting button.



2. Use the ◀, ▶ buttons to make adjustments to the Treble, Middle and Bass. Press the ⮌ button to return to Sound Setup.

3. Touch Screen Beep

1. In Sound Setup, press the On or Off button next to the Touch Screen Beep menu to turn the feature on or off.

4. Speed Dependent Volume Control

1. Press the On or Off button next to the Speed Dependent Volume Control menu to turn the feature on or off.

Display Settings

1. Press the SETUP key on the control panel.



2. Press the Display button to enter Display Setup mode.

1. Setting Brightness

- **Automatic Brightness Control**

When the Display brightness is set to automatic, the brightness will be controlled automatically by assessing the amount of ambient light.

1. Press the Automatic button.

- **Manual Brightness Control**



1. Press the Daylight or Night buttons.
2. Use the ◀, ▶ buttons to make adjustments to the display brightness.

Turning Display On and Off



1. Press the Display off button.
2. Press any key on the control panel or steering wheel mounted controls to turn the display back on.

Listening to the FM/AM radio

1. Press the FM/AM key on the control panel. The most recently played FM/AM radio band will automatically begin playing.
2. Press the FM/AM key to switch to the desired radio band.

1. Selecting a broadcast frequency

- **Selecting through SEEK**

  Press the SEEK TRACK ^ or SEEK TRACK v keys on the control panel for under 0.8 seconds. As SEEK operates, the previous or next radio broadcasts with sufficient reception will automatically be searched and played.

- **Selecting through manual search**

  1. Turn the TUNE knob on the control panel in clockwise or counter-clockwise direction. Each click will increase or decrease the frequency by 1 step (FM: 0.2MHz, AM: 10kHz).
  2. When you find the desired radio broadcast, stop turning the TUNE knob to listen to the selected frequency.

- **Storing presets**

  Presets are a way for you to save your favorite radio broadcasts. Up to 12 presets can be saved in FM mode while up to 6 frequencies can be saved in AM mode.

  1. Select the desired radio broadcast.

  2. From the preset list, press and hold (over 0.8 seconds) the preset number button to which you wish to save.
  3. The current radio broadcast will automatically be saved to the preset number. A beep will signify that the preset has been saved if the beep is set to ON in the sound settings.

2. Scanning FM/AM broadcast frequencies

Radio broadcasts can be scanned to conveniently find radio broadcasts with high quality reception. Each radio broadcast will be played for 5 seconds. This feature is particularly useful when traveling in new areas.

1. Press the Scan button.

Note

- When scanning has completed an entire revolution, the scan function will terminate automatically and the previously played frequency will be restored.

3. Viewing FM/AM Station information

When listening to an RDS radio station, you will be able to view station information.

1. Press the Info button
2. Information about the current station (frequency, station, artist, title) will be displayed.

Listening to the SIRIUS™ radio

Press the SAT key on the control panel. The most recently played SIRIUS™ channel will automatically begin playing.

1. Selecting a SIRIUS™ channel

- **Selecting through SEEK**

  Press the SEEK TRACK ^ or SEEK TRACK v keys on the control panel for under 0.8 seconds. As SEEK operates, the previous or next SIRIUS™ channel will automatically be searched and played.

- **Selecting through manual search**

  1. Turn the TUNE knob on the control panel in clockwise or counter-clockwise direction. Each click will display the corresponding channel information.
  2. When you find the desired SIRIUS™ channel, press the TUNE knob to listen to the selected channel.

- **Selecting through preset**

  1. Press the Presets button.

2. Select the desired preset and press the button to start listening.

- **Selecting through channel search**

  1. Press the Search button. The channel search screen will be displayed.

2. Input the desired channel number and press the Done button. To delete entries, press the Delete button.

- **Selecting through SIRIUS™ category list**



1. Press the List button.
2. Select the desired channel to start listening or press the Category List button to display the channels in the selected category

Listening to an Audio CD

1. Insert a CD or press the MEDIA key on the control panel if the CD has already been inserted.



2. When a track is playing and you wish to pause, press the ⏸ button next to the progress bar. Press the ▶ button to restart the track.

Selecting a CD track

1. Selecting through Track Up/Down

1. Press the SEEK TRACK ∧ or ∨ SEEK TRACK keys on the control panel or the ∧ or ∨ keys on the steering wheel controller to play the desired track.
2. The previous or next track will begin playing.

2. Selecting through manual search

1. Turn the TUNE knob on the control panel in clockwise or counter-clockwise direction. Each click will display information about the selected track.
2. Press the TUNE knob to play the selected track.

Listening to an MP3 CD

1. Insert an MP3 CD or press the MEDIA key on the control panel if the CD has already been inserted.

Selecting an MP3 CD song

1. Selecting through song Up/Down

1. Press the SEEK TRACK ^ or SEEK TRACK v keys on the control panel or the ^ or v keys on the steering wheel controller to play the desired track or song.

2. By Artists, Albums, Genres, Songs, Composers

1. Press the Menu button.



2. Choose the category through which you wish to select the song. MP3 CD mode allows you to select by Playlists, Artists, Albums, Genres, Songs, and Composers.

Viewing song information

When listening to an MP3 CD song, you can browse through song details and information.



1. Press the Album art icon.
2. The song information (Artist, Title, Album, Genre) for the current MP3 song will be displayed.
3. Press the button to return to the previous screen.

Copying songs into JUKEBOX

1. Copying the current song

The UVO system allows you to copy songs from an MP3 CD into JUKEBOX.

1. Press the **Copy** button.

2. Once copying is complete, you can listen to stored music in JUKEBOX mode.

2. Copying songs from list

Copying MP3 songs from lists allows you to simultaneously select several songs to copy into JUKEBOX.

1. Press the **Menu** button.



2. Press the **Now Playing** button.



3. Press the **Edit** button.



4. Select the songs you wish to copy. When selected, a ☑ will be displayed next to the song. To select all songs in the list, press the **Select All** button.
5. After selecting the desired songs, press the **Copy** button.

6.Once copying is complete, you can listen to copied music in JUKEBOX mode.

Listening to USB music

1. Connect a USB device or press the MEDIA key on the control panel if a USB device has already been connected.

2. When a song is playing and you wish to pause, press the ⏸ button next to the progress bar. Press the ▶ button to restart the song.

Selecting USB music

1. Selecting through song Up/Down

Press the SEEK TRACK ^ or SEEK TRACK v keys on the control panel or the ^, v keys on the steering wheel controller to play the desired song.

2. By Folders, Artists, Albums, Genres, Songs, Composers

1. Press the Menu button.



2. Choose the category through which you wish to select a song. USB Mode allows you to select by Playlists, Artists, Albums, Genres, Songs, and Composers.

Viewing song information

When listening to USB music songs, you can browse through song details and information.



1. Press the Album art icon.



2. The song information(Artist, Title, Album, Genre) for the current USB song will be displayed. Press the ⮌ button to return to the previous screen.

Copying song into JUKEBOX

1. Copying the current song

The UVO system allows you to copy songs from your USB device into JUKEBOX.

1. Press the Copy button.

2. Once copying is complete, you can listen to copied music in JUKEBOX mode.

2. Copying songs from list

Copying USB music songs from lists allows you to simultaneously select several songs to copy into JUKEBOX.

1. Press the Menu button.



2. Press the Now Playing button.



3. Press the Edit button.



4. Select the songs you wish to copy. When selected, a ☑ will be displayed .next to the song. To select all songs in the list, press the Select All button.
5. After selecting the desired songs, press the Copy button.

6. Once copying is complete, you can listen to copied music in JUKEBOX mode.

Listening to music from your *Bluetooth*® wireless technology enabled device

1. Pair your *Bluetooth*® wireless technology enabled device to the handsfree system. *For more information on pairing your *Bluetooth*® wireless technology enabled devices, refer to the 'Pairing a *Bluetooth*® wireless technology enabled device for the first time' section.
2. Press the MEDIA key on the control panel to turn on BT audio mode.
3. When streaming music from your *Bluetooth*® wireless technology enabled device and you wish to pause, press the ▶II button next on the screen. Press the ▶II button to restart music.

Note

- While music saved in the *Bluetooth*® wireless technology enabled device may automatically begin playing after converting to the BT Audio screen, this music player function may not be supported in some *Bluetooth*® wireless technology enabled devices.
- If music does not begin playing even after displaying the BT Audio screen, try starting the music directly from the *Bluetooth*® wireless technology enabled device.

Selecting a song

1. Press the SEEK TRACK ^ or SEEK TRACK v keys on the control panel or the ^, v keys on the steering wheel controller to play the desired song.
2. The previous or next song will begin playing.

Note

- File selection may not be supported by some *Bluetooth*® wireless technology enabled devices.