The manager can delete ekey, reset ekey, send and adjust the ekey, meanwhile he can search the lock record.





E Passcode management

After inputting the passcode on the keyboard of the lock, press the unlock button to unlock. Passcodes are classified into permanent, time-limited, one-time, empty, oop, custom, etc. The password that has been set can only be unlocked, but cannot be locked

a Permanent passcode

The permanent passcode must be used within 24hours after it is generated, otherwise it will automatically expire.






b Time-limited passcode

The time-limited passcode can own an expiration date, which is a minimum of one hour and a maximum of three years. If the validity period is within one year, the time can be accurate to the hour; if the validity period is more than one year, the accuracy is month when the time-limited passcode is valid, it should be used within 24hours, otherwise it will automatically expire.

The Passon of the Control of the Con



One-time passcode can only be used for onetime, and which is available for 6 hours. It will automatically expire.



d Erase passcode

Erase Passcode is VALID for 24 Hours from the Current Time. Caution -All Passcodes used on this Lock will be DELETED on using this Passcode.



e Custom passcode

You can Configure your own Passcode. It needs to be between 6-9 Digits in Length. You can Configure the Customized Passcode via Bluetooth or Remotely via a Gateway.



f Recurring passcode

The Recurring password can be reused within a specified time period, including daily type, weekday type, weekend type, and more.



g Passcode sharing

The system add new communication ways of Facebook Messenger and Whatsapp to help users share the passcode.



h Passcode management

All generated passcodes can be viewed and managed in the password management module. This includes the right of changing the password, deleting the password, resetting the password, and unlocking the password.



F Card management

You need to add the RFID card first. The whole process needs to be done via the app beside the lock. The validity period of the IC card can be set, either permanent or time-limited.



All RFID cards can be queried and managed through the RFID card management module. The remote card issuance function is displayed in the case of a gateway. If there is no gateway, the item is hidden.



a Add a RFID card

Click "Cards", then click "Add card"





There are three options for you. Select "permanent", "timed" or "recycling" as needed. Enter the name of the RFID card, and click "OK". Then the RFID card can be successfully added when it is close to the card sensing area of the lock for 2-3 seconds.







To add an RFID card again, click on the upper right corner of the "Cards" homepage, click "Add Card". Then repeat the operation of adding RFID card.





b Delete RFID cards

Click on the upper right corner of the "Cards" homepage and click "Clear Card" to delete all RFID cards.





We can also choose a single RFID card to delete.





G Fingerprint management

Fingerprint management is similar to IC card management. After adding a fingerprint, you can use the fingerprint to unlock the door.

a Add Fingerprint

Click "Fingerprint", then click "Add Fingerprint".





There are three options for you. Select "permanent", "timed" or "recycling" as needed. Enter the name of the Fingerprint, and click "OK". Then click "Start" and you will be required to Place and Remove your Finger from the Sensor 4 Times.







b Delete Fingerprint

Click the fingerprint you want to delete, then click "Delete".





G Records

It records who comes and goes, and when for 24/7 access logs, get all records about the door unlock/lock anytime and anywhere.






H Setting

In the system settings, it includes touch unlock switch, group management, gateway management, security settings, reminder, transfer smart lock and so on.



a User management

The user name and phone number can be seen in the user list. Click the customer you want to view to get the door lock information.





Gateway management

(Gateway needs to be purchased separately)

The Smart lock is directly connected via Bluetooth, that is why it is not attacked by the network. The gateway is abridge between smart locks and home WIFI networks. Through the gateway, the user can remotely view and calibrate the lock clock, read the unlock record. Meanwhile, it can remotely delete and modify the password.



Gateways are added via an app before they can be used. Here are the steps:


- (1) open the TTLOCK APP;
- (2)Touch the "≡" icon on the top left of the screen;
- (3)Select [Gateway];
- (4)select the "G2";
- (5)Plug in the Gateway and power it on;
- (6)While the light is flashing alternately in red and blue, press "+" sign;
- (7)Add Gateway;
- (8) Select the network and input your WiFi password

 $\ensuremath{\triangle}$ Notice: If the above process times out, please power off and try again.










When the smart lock is opening, the screen will brighten up and "beep" to warn that the battery is low power.


Emergency Power



If the lock is low power and unable to operate, there is a Micro USB power socket at the bottom of lock for power supply.

Factory Default Settings

Settings	Factory Default
Master Code	123456
Auto Lock	Disabled
Silent Mode	Disabled
Wrong Code Entry Limit	5 times
Shutdown Time	5 mins



Restore on APP



Select "Settings" in the APP



Select "Delete" and insert user login password

Restore on lock

- 1. Press and hold the Reset button.
- 2. Keep holding the Reset button for 6 seconds, until you

hear the sound of beep.

Note: This operation IC wired and battery need to be installed. This button is behind the Interior assembly.



Troubleshooting

The turnpiece cannot rotate or operate the lock.
Remove and re-install the lock, making sure that the turnpiece is in right position.

The lock cannot be locked or unlocked by the keypad.

Make sure that the codes are not disabled. If needed, restore the lock's default settings.

The keypad doesn't respond when touched (no lights are visible and no beeping is heard).

Make sure the cables are properly connected, and make sure the batteries are new and installed correctly.

I forgot my Master Codes.

Perform a reset in order to erase all passcodes. Once the reset is complete, all passcodes will be erased and the Master code will return to the default value (123456).

The lock cannot connect APP via bluetooth
Please make sure the bluetooth is on. The APP is ready to
search the lock. If needed, restore the lock's default setting.

Multiple attempts unlock the door also failed to open Use the key to open the lock and change the battery. If needed, please contact customer service.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and(2)this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.--Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

GEONFINO

Dear customer,

Greetings!

Thank you very much for your purchasing! We are so honored to have you as our customer, and we have great confidence to provide you with premium products and friendly service.

About GEONFINO

As an innovative and high technology corporation, GEONFINO is dedicated to R&D, designing, producing and marketing of Smart lock products. Our top-guns in the Smart lock field have constantly developed a series of products with features like fashion, human care, energy efficiency, and environment protection. And we highly value concepts of "People Oriented, Practical and Innovative." a professional seller in the smart lock field will always be a nice company to your life!

Warranty

GEONFINO not only provides a 1-year warranty for all our products but also offers high-level after-sales service. Please kindly contact us immediately and we will supply a replacement or refund if you encounter any of the followings:

- 1. Receving defective items;
- 2. Short packaging;
- 3. Parts are broken in transit;
- 4. Item stops working within warranty;
- 5. Wrong order.

Importance

Valuable Customers, if you like our products and service, please share your wonderful experience with us and other customers, we will be very grateful. If you're dissatisfied with what you get, before writing negative feedback, please contact us, we will try our best to solve the issue to your satisfaction. Thanks for your vote of confidence again! Wish you a very happy life!

Best regards!

Customer Service E-mail: geonfino@afterservice.vip

Scan here to contact us [24Hrs Online]



https://geonfino.afterservice.vip

