
Wireless AV Sender 2.4GHz ISM Frequency




User Manual

Transmitter(TX) 2.4G Antenna Channel Display Channel Button

Video Input Power Input Audio Input Power


Panel Description




Receiver(RX)

Put the transmitter near to STB and other AV output devices, connect the AV cable with the audio video output signal of STB corresponding to colors(Red, White, Yellow).

Back of STB/DVD





Pressing the power switch can switch on or off the power to the transmitter or receiver, and enable it to transmit or not transmit the signal.

©

0

Attention: To ensure that the product can be used normally, the product should be connected when power off In case the product be damaged. Switch on when finish connection and never plug in or out at will. Please turn off the product if long time not use it.

Press the Channel button can be free to choose 2.4GHz transmission channel. AV signal can be transmitted normally only when the transmitter and the receiver are on the same channel.


ė

•

ė

RX

Channel selection



DC 5V=1000mA

1 Vp-p(PALZNTSC)

1 Vp-p(PAUNTSC) 1.5Vp-p (dual channel)

1.5Vp-p (dual channel)

1. How Can I Transmit To Multiple TVs?
The sender does support multiple receivers. If you wish to transmit to a second TV additional receivers are available. Keep Transmitter and receiver setting at the same channel, it can support 1 transmitter and more receivers at the same time.

2. The image is interfered.

A). Please adjust the angle of the antenna for 2.4GHz transmitter and the receiver.

B). Please try to change the 2.4GHz transmission channel for the transmitter and the receiver.

C). If allowed, please put the transmitter and the receiver in a higher place to strengthen the wireless transmission.

CONTENTS

User's Manual x1



USB Cable x2

Power Adapter x2

3. Why Is My Video Black and White? If the image transmits in Black & White, the video cable may be connected to a Component Video input: these are Red, Blue, and Green. Some TVs will have a Yellow RCA connection built into the Green Component connection. It may be necessary to change your TV settings to enable the Video input option. To find information that is specific to your TV, please check your TV's user manual If the channel display do not light up and there is no image. A). Please check the power connection of the transmitter and receiver, open A). Please check the power connection of the transmitter and receiver, open the power switch. B). Please try to change the 2.4GHz transmission channel for the transmitter and the receiver. C). Please check if the transmitter and the receiver are connected correctly (Refer to installation instruction). 5. What If They Don't Connect? A). Please ensure that the transmitter and receiver are within the range of each other. If the signal pass through walls and floors, the transmission distance will reduce to 32.8ft/10m only. Line of sight is recommended as obstacles can reduce the transmission distance. B). Confirm that both power switches are set to the ON position and that the channel selection switches are set to the same number. C). Test each channel to improve signal strength and avoid interference. D). All wireless devices may be subject to interference, which may result in a loss of signal, or intermittent signal. To correct interference issues we recommend adjusting the antennas or the position of the transmitter and receiver by moving them away from sources of interference. Sources of interference can be devices such as cordless phones, wireless routers and microwaves.

Power input:

Video input:

Audio input:

Video output:

Audio output:

6. How Can I Connect The sender To My Coaxial, BNC, or HDMI Source Device? Device?
The sender requires an RCA connection for operation. If you wish to connect to another connection type you will need an adapter (Coaxial to RCA, BNC to RCA) or a converter (HDMI to RCA). Many adapters and converters are available for different connection types.

Note: If trying to connect to a Coaxial or HDMI TV an adapter or converter can still be used but must be the reverse type (RCA to HDMI, RCA to Coaxial).

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.