


4GLTE
Broadband Router

FIRSTNUM


USER MANUAL



Thanks for choosing our product, please read this instruction manual carefully before using, use the steps to operate this product. Keep it in safe place for future use after reading.


*Para configurar a conta e senha, consulte a etiqueta traseira do CPE

Device picture



FIRSTNUM

Device button description



Power key: the power key is self-locking. Press the power key to turn on the device; Press the pop-up power key to turn off the device


WPS key: press and hold the WPS key for 3 seconds; Activate WPS function

WiFi key: press and hold for 3 seconds to close / open WiFi; Click a short press to refresh WiFi

Reset key: press the reset key for 3 seconds with the pen tip or needle ; Device reset and restart (please keep the battery power above 30% or plug in the power adapter for operation)

FIRSTNUM

Definition of Indicator light



Indicator light of Power

Indicator light of WiFi

Indicator light of WPS

Indicator light of Signal

Indicator light of Ethernet port

Power indicator: (red and blue)

1 The power key is self-locking. The power on that light is on and the shutdown light is off.

2 Use power adapter instead of battery; Turn on the machine and the blue light is on for a long time Use batteries instead of power adapters; Power on.

3 Use battery instead of power adapter; Power on.

3 -1. The battery power is 7.2V higher than the low power, and the blue light is on for a long time.

3 -2. The battery power is 7.2V lower than the low power, and the red light is on for a long time.

4 Use battery and power adapter; Power on.

4 -1. When the battery power is lower than 8.4v of full power, the device is charged and the blue light flashes.

4 -2. When the battery reaches full power of 8.4v, the device is not charged and the blue light is on for a long time.

Indicator Light of WiFi: (blue)

1 . After normal power on, the blue light flashes when no equipment is connected;

When the equipment is connected, the blue light is on for a long time, and the shutdown light is off.

FIRSTNUM

2 . Press and hold the WiFi key for 3 seconds; Turn off WiFi hotspot and the blue light is off.

Press and hold the WiFi key for 3 seconds; Turn on the WiFi hotspot and the blue light will be on for a long time WiFi key click; Refresh WiFi hotspot, blue light flashes 3 times.

Network port indicator: (green blue)

1. It is detected that the network cable connection light is on in the startup state, otherwise the light is off.

2. when there is a SIM card, only the output network cable is connected normally and the green light is on;

The signal is normal and in communication, and the green light flashes.

3 . If there is a SIM card and an input network cable, the connection is normal and the blue light is on;

The signal is normal and the blue light flashes .

4. during communication (Internet access via network cable is preferred) When there is no SIM card, there is an input network cable, and the connection is normal; The blue light is on for a long time; The signal is normal and in communication, and the blue light flashes.

Indicator status during startup:

1 . During startup: power supply, WiFi, WPS, signal, network port indicator: Red light on for a long time - green light on for a long time - blue light on for a long time (frequency 5 seconds) - off - start

2 . After normal startup, the equipment works normally: All indicator lights are on according to the status RJ45_ Network cable socket indicator: (green yellow)

There are two indicators next to the crystal head slot.

Connection indicator (green)

Signal indicator (yellow)

The two lights may have three states: on, flashing and off.

The green light indicates that the line connection is normal.

The yellow light flashes, indicating that the signal is normal and communication is in progress;

If the yellow light is off, there is no communication;

The yellow light is on for a long time, which means the network cable is short circuited.

FIRSTNUM

FCC:

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.