

User Manual

TX001



A button, the mode function, when product power on, push A, it is steady on function. then push A again, it becomes the 1st flash mode. keep push , each time it appears one flash mode, total nine mode for option. when nine mode finished, push again, it returns back to the 1st steady mode.

all these operate in a circle way.

B button, the speed up function, when product set up with a kind of flash mode, if you need this flash speed be quicker, then push the B button, push one time, the speed increase with a step.until the speed reach its quickest way , then you should stop. the B button use for total 8 flash mode except for the 1st steady on mode

C button, the speed reduction function, when the product set up with a kind of flash mode, if you need this flash speed to be slower, then push the C button, push one time, the speed decrease with a step,until the speed reach its slowest way, then stop. the C button use for total 8 flash mode except for the 1st steady on mode.

When the product set up with any one of the 8 flash mode, directly push B or C button to control the speed what you need.

D Button, the power off function.

whensoever, whatever the product under what mode, if you want to turn off the sign, directly push D button is ok.

anytime, when you want the product to be start from the first mode , push the D button to turnoff the product, then push A button to start a new and whole mode way.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference

to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of FCC RF Rules. Operation is subject to the following two conditions:

- 1) This device may not cause interference and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.